Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lytmi Lytmi-Cozyclip

Lytmi-CozyClip Open Ear Headphones User Manual

Model: Lytmi-Cozyclip

Brand: Lytmi

Introduction

Thank you for choosing Lytmi-CozyClip Open Ear Headphones. These headphones are designed to provide a comfortable and immersive audio experience while keeping you aware of your surroundings. This manual provides essential information on how to set up, operate, and maintain your new headphones.



Figure 1: Lytmi-CozyClip Open Ear Headphones and Charging Case. The image displays the two black earbuds and their compact charging case, highlighting their sleek design.

What's in the Box

Please ensure all items are present before proceeding:

- Lytmi-CozyClip Open Ear Headphones (Left and Right Earbuds)
- Charging Case
- USB-C Charging Cable

- User Manual (this document)

Product Overview

The Lytmi-CozyClip headphones are engineered for comfort, sound quality, and convenience.

Key Features:

- **Adjustable Comfort:** Featuring an adjustable C-bridge design made from skin-friendly silicone, these clip-on earbuds adapt to various ear shapes, ensuring all-day comfort and stability.
- **Environmental Awareness:** Lytmi open ear earbuds increase awareness of your environment for safer movement, easy interaction at work, and staying connected at home without missing an important sound.
- **Premium Sound:** Equipped with eco-friendly speakers and enhanced audio technology to deliver premium stereo sound, while Bluetooth 5.4 ensures fast, stable connections with no audio delay.
- **Feather-Light Design:** Each earbud weighs just 0.18 oz (5.3g), making them ultra-lightweight for extended wear without discomfort.
- **Easy Controls:** Built-in touch controls offer intuitive management of audio playback and calls.
- **Extended Playtime:** Enjoy up to 6 hours of playtime per charge, extended to 22 hours with the compact charging case.




Figure 2: Diagram illustrating the comfortable and secure fit of the earbud on the ear. The soft memory steel frame applies gentle pressure for a stable fit.

Setup & Pairing

Follow these steps to connect your Lytmi-CozyClip headphones to your device:

1. **Initial Charge:** Before first use, ensure the earbuds are fully charged. Remove any protective films from the charging contacts on the earbuds.

2. **Power On:** Open the charging case. The earbuds will automatically power on and enter Bluetooth pairing mode. The LED indicator will flash alternately blue and white.
3. **Pairing:** On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings. Search for "Lytmi CozyClip" in the list of available devices and select it to connect.
4. **Confirmation:** Once successfully paired, the LED indicator on the earbuds will turn off, and you will hear an audible confirmation.

The headphones support multi-device connection, allowing easy switching between two paired devices.




Figure 3: A user seamlessly connecting their Lytmi-CozyClip headphones to both a smartphone and a laptop, demonstrating multi-device compatibility.

Operating Instructions

Your Lytmi-CozyClip headphones feature intuitive touch controls on each earbud. The touch area is located on the outer surface of the earbud.

Touch Controls:

Action	Control
Power On	Touch and hold for 2 seconds
Power Off	Touch and hold for 5 seconds
Answer / End a Call	Double tap (L/R)
Reject a Call	Touch and hold for 2 seconds (L/R)
Play / Pause	Double tap (L/R)
Activate Voice Assistant	Triple tap (L/R)
Previous Track	Touch and hold for 2 seconds (L)

Action	Control
Next Track	Touch and hold for 2 seconds (R)

Charging

To charge your Lytmi-CozyClip headphones:

1. Place the earbuds into the charging case, ensuring they are correctly seated. The earbuds will begin charging automatically.
2. Connect the charging case to a power supply using the provided USB-C charging cable.
3. The charging case has an indicator light to show charging status. A low battery tone will sound when the earbuds' battery is running low.

The earbuds offer up to 6 hours of playtime on a single charge, and the charging case extends total playtime to 22 hours.



Figure 4: The Lytmi-CozyClip charging case open with earbuds inside, illustrating the charging process and extended battery life.

Comfort & Fit

The Lytmi-CozyClip headphones are designed for maximum comfort and stability:

- **Adjustable C-bridge:** The flexible C-bridge design allows the earbuds to conform to various ear shapes, ensuring a secure and comfortable fit for all-day wear.
- **Lightweight:** Weighing only 0.18 oz (5.3g) per earbud, they are designed to be barely noticeable, allowing you to focus on your activities.
- **Open-Ear Design:** This design allows you to remain aware of your surroundings, making them ideal for outdoor activities or environments where situational awareness is important.

Audio Quality

Experience clear and rich audio with your Lytmi-CozyClip headphones:

- **Deep Bass & Highs:** The headphones deliver powerful bass and crisp high notes for a balanced and immersive sound experience.
- **Advanced Audio Chip:** Integrated Realtek Audio-Chip and advanced Digital Processing ensure perfect sound delivery.
- **Bluetooth 5.4:** The latest Bluetooth technology provides a stronger connection, lower latency, better battery life, and longer distance coverage.




Figure 5: Diagram highlighting the integration of Bluetooth 5.4 technology within the earbud, emphasizing its benefits for connectivity and performance.

Water Resistance

The Lytmi-CozyClip headphones are designed with durability in mind:

- **IPX4 Water Resistant:** These earphones are rated IPX4, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts, running, and use in light rain.

Note: The charging case is not water-resistant. Do not expose it to liquids.



Figure 6: A man in light rain, wearing the Lytmi-CozyClip earbuds, illustrating their IPX4 sweat and water resistance for active use.

Maintenance

To ensure the longevity and optimal performance of your Lytmi-CozyClip headphones:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the headphones to extreme temperatures, high humidity, or direct sunlight for prolonged periods.
- **Charging Contacts:** If charging issues occur, gently clean the charging contacts on both the earbuds and the case with a dry cotton swab.

Troubleshooting

If you encounter issues with your Lytmi-CozyClip headphones, refer to the following common solutions:

No Sound / Disconnection:

- Ensure the earbuds are charged.
- Verify Bluetooth is enabled on your device and the headphones are paired.
- Try unpairing and re-pairing the headphones with your device.
- Move closer to your device to ensure you are within Bluetooth range.

Earbuds Not Charging:

- Ensure the charging cable is securely connected to both the case and the power source.
- Check if the charging contacts on the earbuds and case are clean and free of debris.

- Confirm the charging case itself has power.

Touch Controls Not Responding:

- Ensure your fingers are clean and dry when touching the control area.
- Try restarting the earbuds by placing them in the case and closing it, then reopening.

If problems persist, please contact customer support.

Specifications

Feature	Detail
Model Name	Lytmi-Cozyclip
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Ear Placement	Open Ear
Form Factor	Over Ear
Control Type	Touch Control
Battery Life (Single Charge)	6 Hours
Total Playtime (with Case)	22 Hours
Water Resistance Level	IPX4 Water Resistant
Item Weight (each earbud)	0.18 Ounces (5.3g)
Frequency Range	20 Hz - 20,000 Hz
Material	Soft memory steel frame, Plastic

Warranty & Support

Lytmi products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Lytmi website.

© 2025 Lytmi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DC6SJZ5T

More documents and user manuals: **https://manuals.plus/**