

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tefal](#) /

› [Tefal GV9821 Pro Express Vision Steam Generator Iron User Manual](#)

Tefal GV9821

Tefal GV9821 Pro Express Vision Steam Generator Iron User Manual

Model: GV9821

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Tefal GV9821 Pro Express Vision Steam Generator Iron. Please read all instructions carefully before using the appliance and retain this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not leave the iron unattended while it is switched on or connected to the power supply.
- Keep the iron and its cord out of reach of children.
- Never immerse the appliance, power cord, or plug in water or any other liquid.
- Unplug the iron from the electrical outlet before filling with water, cleaning, or when not in use.
- Use the iron only for its intended purpose, which is ironing garments.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the iron on a stable, heat-resistant surface when resting.
- Do not touch hot surfaces. Use handles or knobs.
- Steam is hot and can cause burns. Exercise caution when using the steam function.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Tefal GV9821 Pro Express Vision Steam Generator Iron.



An image showing the Tefal GV9821 Pro Express Vision steam generator iron. It features a black and silver design with a transparent water tank and a control panel on the base. The iron unit is docked securely on the base station, with the steam hose connected. A 'Calc Collector' knob is visible on the front of the base.

Key Components:

- **Iron Unit:** Features the Durilium soleplate and handle.
- **Base Station:** Houses the water tank, steam generator, and control panel.
- **Removable Water Tank:** Transparent tank for easy monitoring of water level.
- **Control Panel:** Buttons for power, steam settings, and indicators.
- **Steam Hose:** Connects the iron unit to the base station.
- **Calc Collector:** System for collecting limescale.
- **Lock System:** Secures the iron to the base for transport.
- **Smart LED Vision:** Integrated light for enhanced visibility during ironing.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and labels from the appliance.
2. **Positioning:** Place the steam generator iron on a stable, flat, and heat-resistant surface, such as an ironing board designed for steam generators.
3. **Filling the Water Tank:**
 - Remove the transparent water tank from the base unit.
 - Fill the tank with tap water up to the 'MAX' indicator. The tank has a capacity of 1.2 liters.

- Reinsert the water tank firmly into the base unit until it clicks into place.

4. **Connecting to Power:** Plug the power cord into a grounded electrical outlet. Ensure the outlet voltage matches the appliance's requirements.

OPERATING INSTRUCTIONS

1. **Power On:** Press the On/Off button on the control panel. The indicator light will illuminate, and the appliance will begin to heat up.
2. **Heating Time:** Wait for the iron to reach the desired temperature. An indicator light will signal when it is ready for use.
3. **Steam Activation:** Press the steam trigger located under the iron's handle to release continuous steam. The iron provides a continuous steam output of 180 g/min.
4. **Adjusting Steam and Temperature:** Use the adjustable thermostat and steam regulator on the iron or base unit to select appropriate settings for different fabric types. Refer to garment care labels.
5. **Vertical Steaming:** For delicate fabrics or to refresh hanging garments, hold the iron vertically a few centimeters away from the fabric and press the steam trigger.
6. **Smart LED Vision:** The integrated LED light automatically illuminates the ironing area, providing better visibility for precise ironing.
7. **Anti-Drip Function:** This feature prevents water droplets from staining your garments during ironing.
8. **Automatic Shut-off:** For safety and energy saving, the iron is equipped with an automatic shut-off function if left inactive for a certain period.
9. **After Use:** Press the On/Off button to switch off the appliance and unplug it from the mains. Allow the iron to cool down completely before storing.

MAINTENANCE AND CLEANING

- **Cleaning the Soleplate:**
 - Ensure the iron is cool and unplugged.
 - Wipe the Durilium soleplate with a damp cloth. Do not use abrasive cleaners or metallic scouring pads, as these can damage the soleplate.
- **Descaling (Calc Collector):**
 - The GV9821 features an Integrated Calc Collector to prevent limescale buildup.
 - Regularly check and empty the Calc Collector as indicated by the appliance or approximately every 10 uses, depending on water hardness.
 - Refer to the specific instructions in the full manual for removing and cleaning the Calc Collector.
- **Emptying the Water Tank:** After each use, or before storing for an extended period, empty any remaining water from the tank.
- **Storage:** Once the iron has completely cooled, secure the iron unit to the base using the lock system. Wrap the steam hose and power cord neatly around the designated storage areas on the base. Store the appliance in a dry, safe place.

TROUBLESHOOTING

If you encounter issues with your steam generator iron, consult the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty. Iron not heated sufficiently. Steam trigger not pressed.	Fill the water tank. Wait for the iron to reach operating temperature. Press the steam trigger firmly.
Water droplets leak from the soleplate.	Iron temperature is too low for steam.	Increase the iron's temperature setting. Wait for the iron to heat up before using steam.
Iron does not heat up.	Not plugged in. Power button not pressed.	Check power connection. Press the On/Off button.
Limescale particles appear on garments.	Calc Collector needs cleaning.	Clean the Calc Collector as per maintenance instructions.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Model: GV9821

Brand: Tefal

Power: 3000 Watts

Continuous Steam Output: 180 g/min

Water Tank Capacity: 1.2 Liters

Soleplate Material: Durilium

Cable Length: 1.6 meters

Dimensions (L x W x H): 25 x 30 x 45 cm

Weight: 1 Kilogram

Special Features: Anti-drip function, Vertical steam, Adjustable thermostat, Programmable thermostat, Removable water tank, Steam regulator, Anti-scale system (Calc Collector), Smart LED Vision, Automatic shut-off.

WARRANTY AND SUPPORT

Your Tefal GV9821 Pro Express Vision Steam Generator Iron is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.

For technical assistance, spare parts, or further information, please contact Tefal customer support in your region. Contact details can typically be found on the official Tefal website or in the warranty documentation.