amazon basics ABSBX20R

amazon basics X20R 20W Bluetooth Soundbar Instruction Manual

INTRODUCTION

The amazon basics X20R 20W Bluetooth Soundbar is designed to deliver a rich audio experience with versatile connectivity options. This manual provides instructions for its setup, operation, and maintenance, ensuring you can fully utilize its features for your audio needs.

Image: Front view of the amazon basics X20R 20W Bluetooth Soundbar.

SAFETY PRECAUTIONS

Please read and understand all safety instructions before using this product. Keep this manual for future reference.

- Do not expose the soundbar to water or moisture.
- Avoid placing the soundbar near heat sources or in direct sunlight.
- Do not attempt to disassemble or modify the soundbar.

- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1N Soundbar
- 1N Charging Cable
- 1N AUX Cable
- 1N User Manual

Image: The amazon basics X20R 20W Bluetooth Soundbar with its included accessories.

PRODUCT FEATURES

The amazon basics X20R Soundbar offers the following key features:

- **20W Audio Output:** Equipped with dual 10W drivers for a total of 20W power, providing clear and dynamic sound.
- **Enhanced Bass:** Features 2X bass reflex technology for deeper and clearer bass response.

- **Extended Playback:** Offers up to 9 hours of wireless playback at 50% volume, powered by a 2000mAh rechargeable Li-ion battery.
- **Bluetooth 5.3:** Utilizes advanced Bluetooth 5.3 for fast pairing, extended range, and stable wireless audio streaming.
- **Multiple Connectivity Options:** Supports Bluetooth, AUX, Micro SD cards, and USB flash drives for broad device compatibility.

> Your browser does not support the video tag.

Video: An overview highlighting the key features and benefits of the amazon basics X20R 20W Bluetooth Soundbar.

SETUP AND INSTALLATION

Powering On

1. Connect the provided charging cable to the 5V-1A port on the soundbar and the other end to a USB power adapter (not included).
2. Press and hold the power button on the soundbar until the LED indicator lights up.

Placement

Place the soundbar on a stable, flat surface, such as a TV stand or shelf. Ensure there are no obstructions in front of the speakers for optimal sound projection.

OPERATING YOUR SOUNDBAR

Controls Overview

The soundbar features both touch and button controls for easy operation. The blue LED indicator light provides status feedback.

Image: Close-up view of the control panel on the amazon basics X20R soundbar.

Bluetooth Pairing

1. Turn on the soundbar. It will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "amazon basics X20R" from the list.
4. Once paired, the blue LED will stop flashing and remain solid.

AUX Connectivity

1. Connect one end of the provided AUX cable to the AUX port on the soundbar.
2. Connect the other end to the audio output jack of your device.
3. The soundbar will automatically switch to AUX mode.

USB Playback

1. Insert a USB flash drive containing audio files into the USB port on the soundbar.
2. The soundbar will automatically detect the USB drive and begin playback.

Micro TF Card Playback

1. Insert a Micro TF card containing audio files into the TF card slot on the soundbar.
2. The soundbar will automatically detect the TF card and begin playback.

Image: Close-up view of the AUX, USB, and TF card ports on the amazon basics X20R soundbar.

BATTERY AND CHARGING

The soundbar is equipped with a 2000mAh Li-ion rechargeable battery, offering up to 9 hours of playback at 50% volume.

- To charge, connect the soundbar to a USB power source using the provided charging cable.
- The LED indicator will show charging status.
- A full charge typically takes approximately 3-4 hours.

Image: The amazon basics X20R soundbar, illustrating its extended playtime.

MAINTENANCE

To ensure the longevity and optimal performance of your soundbar, follow these maintenance guidelines:

- Clean the soundbar with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the soundbar in a cool, dry place when not in use.
- Avoid exposing the soundbar to extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your soundbar, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
No power	Battery is drained or power cable is not connected.	Charge the soundbar using the provided cable. Ensure the power cable is securely connected.
No sound	Volume is too low, incorrect input mode, or device not connected.	Increase volume. Check if the correct input mode (Bluetooth, AUX, USB, TF) is selected. Re-pair Bluetooth or re-connect AUX/USB/TF.
Bluetooth pairing fails	Soundbar is not in pairing mode, or device is too far.	Ensure soundbar is in pairing mode (flashing blue LED). Move device closer to the soundbar. Clear previous Bluetooth connections on your device.
Distorted sound	Volume too high, weak signal, or audio source issue.	Lower the volume. Ensure the soundbar is within Bluetooth range. Try a different audio source or cable.

TECHNICAL SPECIFICATIONS

Specification	Detail
Brand	amazon basics
Model Number	ABSBX20R
Speaker Maximum Output Power	20 Watts
Connectivity Technology	Auxiliary, Bluetooth, USB
Bluetooth Version	5.3
Audio Output Mode	Stereo
Battery Capacity	2000 mAh
Battery Average Life	9 Hours (at 50% volume)
Control Method	Touch, Button
Item Dimensions (D x W x H)	6.2D x 41.8W x 6.2H Centimeters
Item Weight	681 Grams
Compatible Devices	Desktop, Laptop, MP3 Player, Projector, Smartphone

WARRANTY AND CUSTOMER SUPPORT

This product comes with a **1 Year limited warranty** on manufacturing defects. For warranty claims or technical support, please contact:

- **Phone:** 1800-419-0416
- **Email:** amazonbrands@blubirch.com

Working hours: 10am to 6pm on Monday-Friday (except National Holidays).

Manufacturer: XOR TECHNOLOGIES LLP