

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LOQRON](#) /

› [Smart Key Lock Box, TT-LOCK APP Control Fingerprint Recognition LockBox with G2 Gateway for Remotely Control for Anywhere Access, Fingerprint Recognize & Multiple Code Type for Home, Airbnb, Realtor](#)

LOQRON TT-LOCK

LOQRON Smart Key Lock Box User Manual

Model: TT-LOCK

INTRODUCTION

The LOQRON Smart Key Lock Box with G2 Gateway provides a secure and convenient solution for managing access to keys and small items. This device integrates advanced technology, offering multiple unlocking methods and remote control capabilities through the TT-Lock APP.

Key Features:

- Five unlocking methods: App control, Fingerprint, Access Card, Password, and Manual Keys.
- Remote unlocking and management via G2 Gateway.
- Real-time monitoring of door status, battery life, and activity logs.
- Durable construction with premium zinc alloy body.



Image: The Smart Key Lock Box, G2 Gateway, and the TT-Lock mobile application interface, demonstrating the complete system.

SETUP GUIDE

Follow these steps to set up your Smart Key Lock Box and G2 Gateway for optimal performance.

1. Initial Lock Box Setup

1. **Install Batteries:** Open the battery compartment and insert the required batteries (not included).
2. **Initial Pairing:** Follow the instructions in the TT-Lock App to add the lock box as a new device.

Smart Lock Box Features



Image: Detailed view of the Smart Key Lock Box highlighting its components: premium zinc alloy body, numeric keypad, card reader area, fingerprint sensor, USB-C port for emergency unlock, and manual key access.


2. G2 Gateway Connection

The G2 Gateway enables remote control and advanced features for your lock box.

Simple Setting Gateway


Step 1: Activate the App

Open TTLock APP, press the button
Select the Gateway.



Step 2: Connect the Gateway

Plug in power, Wait for the light to flash
alternately with red and blue.



Step 3: Configure the Wi-Fi

The gateway and the smartphone should
be connected to the same Wi-Fi.




Image: Step-by-step guide for setting up the G2 Gateway, illustrating app activation, physical connection, and Wi-Fi configuration.

1. **Step 1: Activate the App.** Open the TT-Lock APP and select the Gateway option.
2. **Step 2: Connect the Gateway.** Plug the G2 Gateway into a power source. Wait for the indicator light to flash alternately with red and blue, indicating it's ready for pairing.
3. **Step 3: Configure Wi-Fi.** Ensure both your smartphone and the gateway are connected to the same 2.4GHz Wi-Fi network (5GHz networks are not supported). Follow the in-app prompts to complete the Wi-Fi configuration.

Important: The gateway should be placed within 32 feet (approximately 10 meters) of the Smart Key Lock Box for stable wireless connection.



Wireless Gateway Connection



Ensure that the distance is within 32 feet.

No More Than 32 feet.

Image: Illustration of the wireless connection between the G2 Gateway and the Smart Key Lock Box, highlighting the recommended maximum distance of 32 feet for optimal signal.

Operational State

Please add the gateway when the light to flash alternately with red and blue.



Image: Visual guide to the G2 Gateway's operational states, indicated by the color and pattern of its LED light: blue for working mode, red for network failure, and alternating red/blue for pairing mode.

OPERATING INSTRUCTIONS

The LOQRON Smart Key Lock Box offers five convenient methods for access.

5 ways to unlock



Image: Overview of the five unlocking methods available for the Smart Key Lock Box: App Control, Fingerprint, Manual Key, Access Card, and Passcode.

Unlocking Methods:

- **1. App Control:**

Open the TT-Lock App on your smartphone. Ensure Bluetooth is enabled and you are within range of the lock box (or connected via Gateway for remote access). Tap the unlock icon in the app to open the lock box.

- **2. Fingerprint Recognition:**

Place your registered finger on the fingerprint sensor located on the keypad. The lock will unlock upon successful recognition. Ensure your finger is clean and dry.

- **3. Access Card:**

Present a registered access card to the card reader area on the lock box. The lock will unlock after the card is successfully read.

- **4. Passcode:**

Enter your pre-set passcode on the numeric keypad, then press the checkmark (✓) button. The lock will unlock if the passcode is correct.

- **5. Manual Keys:**

In case of battery depletion or electronic malfunction, use the provided manual keys to unlock the lock box. The keyhole is typically located discreetly on the device.

Remote Control and Management (with G2 Gateway):

With the G2 Gateway connected, you can manage your lock box from anywhere in the world.

Remotely Control

Easily control electronic devices anytime, anywhere.




Image: Examples of remote control functionality, showing a user receiving a notification for access and another user remotely unlocking the device through the TT-Lock app.

- **Remote Unlocking:** Unlock the lock box from any location using the TT-Lock App.
- **Access Code Management:** Generate, modify, or delete temporary or permanent access codes remotely.
- **Activity Logs:** View a real-time log of all unlocking events, including method and time.
- **Battery Monitoring:** Check the current battery level of the lock box through the app.
- **Share E-keys:** Grant temporary or permanent access to others by sharing e-keys through the app.

Wi-Fi Gateway



Share E-key



Remote
Unlocking



Door Status
Notification



View
Activity Log



Image: Features enabled by the Wi-Fi Gateway, including sharing e-keys, remote unlocking, door status notifications, and viewing activity logs.

MAINTENANCE

- **Cleaning:** Wipe the lock box and keypad with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish or electronic components.
- **Battery Replacement:** When the battery level is low (indicated by the app or a warning light/sound on the device), replace all batteries with new ones of the specified type. Refer to the battery compartment for battery type.
- **Fingerprint Sensor Care:** Keep the fingerprint sensor clean and free of dirt or moisture to ensure accurate recognition.
- **Environmental Conditions:** While the lock box is designed for durability, avoid prolonged exposure to extreme temperatures or direct water immersion.



Image: The Smart Key Lock Box open, revealing its interior capacity for keys and cards, and demonstrating its robust, potentially water-resistant design.

TROUBLESHOOTING

- **Lock Box Not Responding:**

- Check battery level and replace if necessary.
- Ensure the lock box is properly powered on.
- Try using the manual key for access.

- **Fingerprint Not Recognized:**

- Ensure your finger is clean and dry.
- Try different angles or re-register your fingerprint if issues persist.

- **App Connectivity Issues:**

- Ensure Bluetooth is enabled on your phone.
- For remote access, verify the G2 Gateway is powered on and connected to a stable 2.4GHz Wi-Fi

network.

- Restart the TT-Lock App on your smartphone.

- **Gateway Not Pairing:**

- Confirm the gateway's indicator light is flashing red and blue.
- Ensure your phone and gateway are on the same 2.4GHz Wi-Fi network.
- Relocate the gateway closer to your Wi-Fi router.

SPECIFICATIONS

Feature	Detail
Brand	LOQRON
Model Number	TT-LOCK
Lock Type	Key Lock (Smart)
Material	Stainless Steel
Special Features	Keyless, Fingerprint, App Control, Remote Access
Connectivity Protocol	Wi-Fi (2.4GHz)
Controller Type	Hand Control, SmartThings (via App)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the product packaging or contact LOQRON customer service directly. Details can often be found on the official LOQRON website or through your purchase platform.

Customer Support: Please visit the LOQRON store on Amazon or their official website for contact information and frequently asked questions.

Note: Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 LOQRON. All rights reserved.

Related Documents - TT-LOCK



[Linkstyle Matrix Key Box Bundle Quick Start Guide](#)

Concise and SEO-optimized guide for setting up the Linkstyle Matrix Key Box Bundle, including app installation and device pairing instructions.

 <p>USER MANUAL Smart Door Lock</p> <p>Version 1.0</p>	<p>Smart Door Lock User Manual - Installation, Operation, and Troubleshooting Guide</p> <p>Comprehensive user manual for the Smart Door Lock, covering detailed installation steps, operation via the TT Lock App and keypad, advanced features like fingerprint and IC card access, remote unlock, and integration with Alexa. Includes troubleshooting and FAQ.</p>
 <p>Installers & User guide Keybox 3.</p> <p>igloohome</p>	<p>Igloohome Keybox 3: Installers & User Guide Smart Lock Box Manual</p> <p>Get started with your Igloohome Keybox 3. This comprehensive user guide provides detailed instructions on installation, features, app setup, security settings, troubleshooting, and car sharing integration for the smart lock box.</p>
 <p>Smart Code Key Box Installation Manual</p> <p>1</p>	<p>OKLOK Smart Code Key Box Installation Manual</p> <p>Installation guide for the OKLOK Smart Code Key Box (model MCSH10000145), detailing battery checks and various mounting methods for smooth surfaces, non-smooth walls, gates with grilles, and gates with handles. Includes instructions for using the OKLOK+ app.</p>
 <p>McGrathLocks</p>	<p>McGrathLocks MLM818 Smart Lock: Features, Specifications, and Installation Guide</p> <p>Discover the McGrathLocks MLM818, a versatile 4-in-1 smart door lock offering Bluetooth, RFID, passcode, and key access. This document details its features, technical specifications, product structure, and installation process.</p>
	<p>Puroma 4-Digit Combination Key Storage Lock Box User Manual</p> <p>Instructions and guidance for using the Puroma 4-Digit Combination Key Storage Lock Box, including opening, setting combinations, important operation checks, and mounting methods.</p>