Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- PeriPage /
- > PeriPage Pino Wireless Tattoo Stencil Printer User Manual (Model ALD-P900)

PeriPage Pino

PeriPage Pino Wireless Tattoo Stencil Printer User Manual

Model: Pino (ALD-P900)

1. Introduction

This manual provides detailed instructions for the safe and efficient operation of your PeriPage Pino Wireless Tattoo Stencil Printer. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.

The PeriPage Pino is a portable thermal transfer machine designed for creating tattoo stencils. It offers wireless connectivity via Bluetooth for smartphones and tablets, and a USB connection for computers, making it a versatile tool for tattoo artists.

2. SAFETY INFORMATION

Important Safety Precautions:

- Keep the device away from naked flames or direct heat sources.
- Do not expose the device to water or excessive moisture.
- Use only the specified power adapter and accessories.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Ensure proper ventilation during operation.

3. PRODUCT OVERVIEW

3.1 Key Features

- Easy Connectivity: Connects effortlessly via Bluetooth to smartphones and tablets, or via USB to computers (Mac and Windows).
- User-Friendly App: Control printing and customize designs through a dedicated mobile application.
- Compact & Portable Design: Lightweight and designed for mobility, allowing use in various locations.

- High-Quality Prints: Utilizes advanced thermal printing technology for precise and vibrant tattoo transfers, ensuring crisp lines and detailed shading.
- Inkless Operation: No ink cartridges required, simplifying maintenance.

3.2 Package Contents

Please verify that all items are present in the package:

- · PeriPage Pino Wireless Tattoo Stencil Printer
- USB Cable
- Power Adapter
- User Manual
- · Sample Thermal Stencil Paper

4. SETUP

4.1 Charging the Printer

Before first use, fully charge the printer using the provided power adapter and USB cable. The charging indicator light will typically change color or turn off when charging is complete.

4.2 Installing the App (for Mobile Devices)

- 1. Search for the "PeriPage" app in your device's app store (iOS or Android).
- 2. Download and install the application.
- 3. Open the app and follow any on-screen prompts for initial setup.

4.3 Connecting to a Device

4.3.1 Bluetooth Connection (Mobile Devices)

- 1. Ensure the PeriPage Pino printer is powered on.
- 2. Enable Bluetooth on your smartphone or tablet.
- 3. Open the PeriPage app. The app will guide you to search for and connect to the printer. Select "Pino" from the list of available devices.
- 4. Confirm the pairing request on your device if prompted.



Figure 1: Bluetooth Connection to Mobile Devices

4.3.2 USB Connection (PC)

- 1. Ensure the PeriPage Pino printer is powered on.
- 2. Connect the printer to your computer (Mac or Windows) using the provided USB cable.
- 3. Your computer may automatically install necessary drivers. If not, visit the official PeriPage website for driver downloads.
- 4. Once drivers are installed, the printer will be recognized as a printing device.



Figure 2: USB Connection to PC

5. OPERATING INSTRUCTIONS

5.1 Preparing the Stencil Paper

- 1. Tear off the yellow protective paper from the thermal stencil sheet.
- 2. Remove the transparent protective film from the stencil sheet.

5.2 Printing a Stencil

- 1. Turn on the PeriPage Pino printer by pressing and holding the power button.
- 2. Carefully insert the prepared stencil paper into the printer's paper feed slot. Ensure it is aligned correctly.
- 3. Using the PeriPage app (for mobile) or your computer's print function (for PC), select your desired tattoo design.
- 4. In the app, navigate to the "tattoo" function or print option. Adjust settings as needed (e.g., size, darkness).
- 5. Initiate the print command. The printer will feed the paper and print the stencil.



Figure 3: Printer Dimensions and Stencil Printing Steps



Figure 4: Printer in Operation

5.3 Transferring the Stencil to Skin

- 1. Cleanse the skin area where the tattoo will be applied using wet wipes or an appropriate skin prep solution.
- 2. Apply a thin, even layer of tattoo transfer cream to the cleaned skin area.
- 3. Carefully place the printed stencil onto the prepared skin, pressing gently without rubbing. Ensure full contact.
- 4. Slowly peel back the stencil paper to reveal the transferred stencil outline on the skin.



Figure 5: Stencil Transfer Process

5.4 Using the PeriPage App Features

The PeriPage app offers various functionalities to enhance your stencil creation:

- Personalized Editing: Adjust images, add text, and modify designs directly within the app.
- Extensive Tattoo Templates: Access a library of pre-designed templates.
- 3D Tattoo Preview: Visualize how the stencil might appear on a 3D body model.
- Image Editing: Tools for refining and optimizing images for stencil printing.




Figure 6: PeriPage App Features

6. MAINTENANCE

6.1 Cleaning the Printer

- Ensure the printer is powered off and disconnected from any power source before cleaning.
- Wipe the exterior of the printer with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface.
- Periodically check the paper feed area for any dust or debris and gently remove it.

6.2 Storage

- Store the printer in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep the printer covered to prevent dust accumulation.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your PeriPage Pino printer.

7.1 Printer Not Turning On

- Ensure the printer is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes.
- Check the power button for proper engagement.

7.2 Unable to Connect via Bluetooth

- Make sure Bluetooth is enabled on your mobile device.
- Ensure the printer is within range (typically 10 meters or 33 feet).
- Restart both the printer and your mobile device.
- Forget the device in your phone's Bluetooth settings and try pairing again through the PeriPage app.

7.3 Poor Print Quality (Blurred or Faint Stencils)

- Ensure you are using high-quality thermal stencil paper.
- Check the paper for proper insertion and alignment.
- Clean the print head if there is any visible debris (refer to Maintenance section).
- Adjust the print density settings within the PeriPage app or printer driver.
- Ensure the image resolution is adequate for printing.



Figure 7: Print Quality Comparison

7.4 Paper Jams

- · Power off the printer immediately.
- Gently pull out any jammed paper in the direction of the paper path. Avoid tearing the paper inside the
- Ensure the paper is inserted straight and not wrinkled before printing.

8. SPECIFICATIONS

Feature	Specification
Brand	PeriPage
Model Name	PeriPage-P90 Pino
Item Model Number	ALD-P900
Connectivity Technology	Bluetooth, USB

Printing Technology	Thermal
Printer Output	Monochrome
Maximum Black and White Print Resolution	600 dpi
Maximum Media Size	8.5 x 11 inches
Sheet Size	8.5 inches
Max Input Sheet Capacity	50
Output Sheet Capacity	50
Compatible Devices	PC, Smartphones
Control Method	Арр
Item Weight	1.5 pounds (0.68 Kilograms)
Package Dimensions	11.42 x 3.27 x 2.13 inches
Batteries	1 Lithium Ion battery (included)

9. WARRANTY AND SUPPORT

9.1 Limited Warranty

The PeriPage Pino Wireless Tattoo Stencil Printer comes with a limited manufacturer's warranty. For specific terms, conditions, and duration of the warranty, please refer to the product packaging or contact PeriPage customer support.

9.2 Customer Support

For technical assistance, troubleshooting, or any product-related inquiries, please visit the official PeriPage website or contact their customer service department. Contact information can typically be found on the product packaging or the official website.

© 2025 PeriPage. All rights reserved.

Related Documents - Pino



PeriPage Wireless Tattoo Transfer Printer User Manual

User manual for the PeriPage Wireless Tattoo Transfer Printer, covering setup, app connection, PC printing, charging, cleaning, and safety notes.

packing The second of the sec	PeriPage Wireless Tattoo Transfer Printer User Manual & Guide Official user manual for the PeriPage Wireless Tattoo Transfer Printer (P90). Learn setup, app connection, PC printing, charging, maintenance, and safety. Includes troubleshooting tips and FCC compliance information.
problem 	PeriPage Tattoo Transfer Printer User Manual - ALD-P920 User manual for the PeriPage Tattoo Transfer Printer (Model ALD-P920) by Xiamen iLead Tek Co., Ltd. Covers setup, operation, app connectivity, PC printing, charging, maintenance, and safety precautions.
.0	PeriPage Portable Printer Instruction Manual - Setup, Operation, and Maintenance Comprehensive instruction manual for the PeriPage portable printer by Xiamen iLead Tek Co., Ltd. Learn how to set up, connect via Bluetooth or computer, replace paper, charge, and clean your device. Includes FCC compliance information.
perpage の 使用規則等 INSTRUCTION MANUAL	PeriPage P21 Thermal Printer User Manual User manual for the PeriPage P21 thermal printer, covering setup, operation, charging, cleaning, and safety information.
perforge NSTRUCTION MANUAL	PeriPage Portable Label Printer Instruction Manual Instruction manual for the PeriPage portable label printer, covering product features, app connection, paper changing, charging, cleaning, and safety information.