

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Merax](#) /
- › [Merax Modern 55-inch Chaise Lounge User Manual](#)

Merax 55"W

Merax Modern 55-inch Chaise Lounge User Manual

Model: 55"W

PRODUCT OVERVIEW

The Merax Modern Chaise Lounge is designed for comfort and functionality, offering a stylish addition to your living space. This lounge features a robust construction, comfortable upholstery, and integrated conveniences such as a charging station and cup holders.

- **Stylish Design:** Provides a cozy place for reading, napping, or relaxation. Available in various sizes to fit different room dimensions.
- **Quality Materials:** Constructed with thick foam and polyester, upholstered in soft linen fabric for durability and comfort. Includes two matching toss pillows.
- **Space-Saving:** A functional design suitable for apartments, dorms, living rooms, bedrooms, offices, and waiting areas.
- **Integrated Features:** Equipped with a built-in charging station (dual outlets, USB, Type-C) and convenient cup holders.

SETUP AND ASSEMBLY

Assembly of the Merax Chaise Lounge is required and typically takes 10-20 minutes. It is recommended that two people assemble the unit. All necessary tools are included.

Package Contents:

- Chaise Lounge Components
- Hardware Pack
- Assembly Instructions
- Two Toss Pillows

Assembly Steps:

1. Unpack all components from the boxes. Exercise caution when opening to avoid damaging the fabric. The chaise lounge is typically delivered in 2 boxes.
2. Identify all parts and hardware using the included instruction manual.

3. Follow the step-by-step instructions provided in the manual to connect the chaise lounge sections and attach the legs.
4. Once assembled, place the seat cushion and back pillows. Note that due to compressed packaging, the seat bag and back pillows may have wrinkles upon opening. Allow 2-3 days for them to fully recover their shape naturally.

Size: inch




Figure 1: Chaise Lounge Dimensions and Packaging Information.

OPERATING INSTRUCTIONS

The Merax Chaise Lounge is designed for comfortable relaxation and includes convenient built-in features.

Using the Charge Station:

- Locate the integrated charging station on the armrest.
- Plug your electronic devices into the dual outlets, USB, or Type-C ports as needed.
- Ensure the chaise lounge is positioned near a power outlet for the charging station to function.

Using the Cup Holders:

- Place beverages securely in the designated cup holders located on the armrests.
- Avoid placing hot liquids directly without a coaster to prevent potential damage.



Figure 2: Integrated Charging Station and Cup Holders.

MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Merax Chaise Lounge.

Cleaning Instructions:

- For general cleaning, wipe the upholstery with a dry cloth.
- For spills, use a slightly damp cloth. Avoid excessive moisture.
- Do not use harsh chemicals, abrasive cleaners, or strong detergents, as these can damage the fabric.
- The pillow, backrest, and seat cushion covers are removable and washable. Refer to the care label for specific washing instructions.

General Care:

- Keep the chaise lounge away from direct sunlight to prevent fading.
- Avoid placing the sofa near open flames or high heat sources.
- Regularly fluff and rotate cushions to maintain their shape and even wear.
- Supervise children and pets around the sofa to prevent potential entrapment risks or damage.



Figure 3: Fabric and Cushion Details with Removable Covers.

TROUBLESHOOTING

This section addresses common issues you might encounter with your chaise lounge.

Wrinkles on Cushions:

Due to compressed packaging, cushions may appear wrinkled upon unpacking. This is normal. Allow 2-3 days for the foam and fabric to expand and recover their natural shape.

Charging Station Not Working:

- Ensure the chaise lounge is properly plugged into a functional wall outlet.
- Check if the power cord is securely connected to the charging station unit.
- Test the wall outlet with another device to confirm it is receiving power.

For any other issues not covered here, please contact Merax Customer Support.

SPECIFICATIONS

Feature	Detail
Brand	Merax
Model	Modern Chaise Lounge
Size	55"W
Product Dimensions (D x W x H)	49.6"D x 55"W x 35"H
Item Weight	55 Pounds
Weight Capacity	330 Pounds
Seating Capacity	1
Color	Cream
Upholstery Fabric Type	Chenille
Frame Material Type	Wood
Fill Material	Foam
Assembly Required	Yes
Recommended People for Assembly	2
Included Components	Hardware, Sofa
Additional Features	Built-in Charge Station, Cup Holders, Removable Washable Covers

WARRANTY INFORMATION

The Merax Modern Chaise Lounge comes with a **Lifetime Warranty**. This warranty covers manufacturing defects and material flaws under normal household use. Please retain your proof of purchase for warranty claims.

For detailed terms and conditions of the warranty, please refer to the official Merax website or contact customer support.

CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or encounter any issues with your Merax Modern Chaise Lounge, please do not hesitate to contact our customer support team.

For the most up-to-date contact information, please visit the official Merax website:

[Visit the Merax Store on Amazon](#)

When contacting support, please have your product model (55"W) and purchase details ready to facilitate a quicker

resolution.

