

## VUSH Empress Tidal

# VUSH Empress Tidal Clitoral Stimulator User Manual

Model: Empress Tidal

Brand: VUSH

## 1. INTRODUCTION

The VUSH Empress Tidal is a clitoral stimulator designed for targeted pleasure. It features 48 unique mode combinations, medical-grade silicone construction, and a waterproof design for versatile use. This manual provides essential information for the safe and effective operation, care, and maintenance of your device.

## 2. PRODUCT FEATURES

- **Powerful Clitoral Stimulation:** Delivers intense clitoral stimulation with precision suction and Pleasure Wave technology.
- **48 Mode Combinations:** Offers a wide range of customizable sensations.
- **Medical-Grade Silicone:** Crafted from body-safe, silky-smooth material for comfort and hygiene.
- **Magnetic USB Charging:** Convenient and secure charging mechanism.
- **100% Waterproof:** Suitable for use in wet environments, enhancing versatility and ease of cleaning.
- **Ergonomic Design:** Features a sleek, wave-like shape that fits comfortably in hand.
- **Smart Memory Technology:** Recalls your last used settings for quick access to your preferred mode.




Figure 1: VUSH Empress Tidal with labeled features, including the pleasure point, control buttons, and charging port.



Figure 2: Overview of VUSH Empress Tidal key features and benefits.

### 3. SETUP

#### 3.1 Charging the Device

Before first use, fully charge your Empress Tidal. Connect the magnetic USB charging cable to the device's charging port and plug the USB end into a compatible power source (e.g., computer, USB wall adapter). The device fully charges in approximately 90 minutes and provides up to 60 minutes of use.




Figure 3: Empress Tidal connected to its magnetic USB charging cable.



Figure 4: Benefits of magnetic USB charging.

### 3.2 First Use Preparation

Ensure the device is clean before its first use. Apply a small amount of water-based lubricant to the pleasure point for enhanced comfort and to create a proper seal for suction.

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On/Off

To turn the Empress Tidal on or off, press and hold the power button (central button) for approximately 3 seconds.

### 4.2 Adjusting Modes and Intensity

Once powered on, short press the power button to cycle through the various pleasure modes. Use the '+' button to increase intensity and the '-' button to decrease intensity. The device features 48 unique combinations of suction and pulsation patterns.

### 4.3 Positioning and Usage

Position the pleasure point over your desired area and apply gentle pressure to create a seal. Experiment with different positions and pressure levels to find what feels best for you. Starting on the lowest setting is recommended, gradually increasing intensity as desired.



**VUSH**

## DO YOU WANT TO SEAMLESSLY BLEND IT INTO YOUR LIFESTYLE?

*You wake up early, enjoy your coffee, and set the tone for the day with a little pleasure ritual. The Empress Tidal fits perfectly into your self-care routine, offering gentle morning sensations to start the day with a clear mind and a relaxed body.*

Figure 5: Steps for turning on and adjusting initial settings.

## MAGNETIC CHARGING

- **ALLOWS EASY CHARGING ACCESS**
- **COMPACT AND SAFE**
- **LETS YOU ENJOY PLEASURE WITHOUT THE WORRY OF BATTERY RUNNING OUT**



MAGNETIC USB CHARGING CABLE FOR VUSH TOYS

Figure 6: Tips for optimal positioning and lubricant use.

## 5. MAINTENANCE

### 5.1 Cleaning

Clean the Empress Tidal thoroughly after each use. Wash the device with warm water and a mild, toy-safe soap or a specialized toy cleaner. Rinse thoroughly and allow it to air dry completely before storage. Avoid using harsh chemicals or abrasive cleaners.

### 5.2 Storage

Store your Empress Tidal in a clean, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation. The included discreet storage bag is ideal for this purpose.



Figure 7: Items included with your VUSH Empress Tidal, including the storage bag.

## 6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. If the issue persists, try a different charging cable or power adapter.
- **Weak suction/vibration:** Check if the device is fully charged. Ensure a proper seal is created with the skin. Clean the pleasure point to remove any debris that might obstruct airflow.
- **Charging issues:** Verify that the magnetic connection is secure and the USB cable is properly connected to a working power source.

## 7. SPECIFICATIONS

Feature	Detail
Material	Medical-Grade Silicone
Power Source	1 Lithium Ion battery (included)
Charging	Magnetic USB
Water Resistance Level	Waterproof
Product Dimensions	7.05 x 3.82 x 2.76 inches

Weight	11.99 ounces
Manufacturer	Vush

## 8. OFFICIAL PRODUCT VIDEOS

### VUSH Empress Tidal - Clit Sucking Vibrator - 48 Mode Combos

Your browser does not support the video tag.

This video provides an overview of the VUSH Empress Tidal, showcasing its design and highlighting the 48 available mode combinations for clitoral stimulation.

### VUSH Empress Tidal - Clit Sucker for Women

Your browser does not support the video tag.

This video demonstrates the VUSH Empress Tidal in use, focusing on its suction capabilities and ergonomic design for women's pleasure.

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official VUSH website or contact their customer service directly. Keep your proof of purchase for any warranty claims.