



[Manuals.plus](#) /

› [ROPASOMIC](#) /

› ROPASOMIC i27 Open Ear Wireless Earbuds User Manual

ROPASOMIC i27

ROPASOMIC i27 Open Ear Wireless Earbuds User Manual

Model: i27

INTRODUCTION

Thank you for choosing the ROPASOMIC i27 Open Ear Wireless Earbuds. These earbuds are designed to provide a comfortable and safe listening experience, especially during activities where situational awareness is important. Featuring an open-ear hook design, Bluetooth 5.3 connectivity, touch controls, and IPX6 sweatproof rating, they are ideal for sports, daily commutes, and casual listening. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

WHAT'S IN THE BOX

- 1 Pair of ROPASOMIC i27 Open Ear Wireless Earbuds
- 1 Charging Case
- 1 USB-C Charging Cable
- 1 User Manual

360° Panoramic Crystal Sound Bluetooth 5.3

Panoramic sound at the palace level, as if immersing yourself in the scene.



Image: Contents of the ROPASOMIC i27 package, including earbuds, charging case, and USB-C cable.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Connect the provided USB-C cable to the charging port on

the case and a power source. The indicator light on the case will show charging status. A full charge takes approximately 1.5 hours.



Image: The ROPASOMIC i27 charging case being charged via its USB-C port.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "i27" from the list.
4. Once connected, you will hear a confirmation prompt, and the indicator lights on the earbuds will turn off.




Image: ROPASOMIC i27 earbuds and case demonstrating one-step Bluetooth pairing with a mobile device.

3. Wearing the Earbuds

The ROPASOMIC i27 earbuds feature an open-ear hook design for secure and comfortable wear.

1. Identify the left (L) and right (R) earbuds.
2. Place the ear hook over the back of your ear.
3. Gently rotate the earbud forward until the speaker rests comfortably outside your ear canal.
4. Adjust for a secure and comfortable fit.

Easy To Wear



1
Place the ear hook on the back of your ear.



2
Rotate the earbuds backwards along the auricle until they fit.



3
Wearing completed.

Image: Visual instructions for correctly placing the open-ear earbuds on the ear.

OPERATING INSTRUCTIONS

1. Basic Controls (Touch Control)

The earbuds feature intuitive touch controls for easy management of music and calls.

Action	Function
Single Click L/R	Play/Pause Music, Answer/End Call
Long Press L/R for 2s	Activate Voice Assistant
Long Press R	Volume Up
Long Press L	Volume Down
Double Click R	Next Track
Double Click L	Previous Track
Triple Click L/R	Reject Call
Long Press L/R for 7s (disconnected mode)	Power Off
Long Press L/R for 4s (disconnected mode)	Power On

Smart Touch Control

L R	▶️📞	Single Click L/R
L R	👆	Long Press L/R for 2s
R	⏮️	Long Press R
L	⏪	Long Press L
R	▶️	Double Click R
L	⏩	Double Click L
R	🔄	Triple Click L/R
L R	🔌 ON	Long Press L/R for 7s (disconnected mode)
L R	🔌 OFF	Long Press L/R for 4s (disconnected mode)



Image: Detailed touch control guide for the ROPASOMIC i27 earbuds.

2. Audio Features

Experience crystal clear audio with enhanced 360° Panoramic sound technology, providing an immersive listening experience while keeping you aware of your surroundings.




Image: Internal components of the ROPASOMIC i27 earbud, emphasizing 360° panoramic sound.

3. Call Features

The earbuds support HD Clear Call functionality, allowing for clear conversations. Please note that these earbuds are not designed for commercial call centers.



Image: ROPASOMIC i27 earbuds shown with a phone call interface, illustrating HD Clear Call capability.

MAINTENANCE AND CARE

- **Cleaning:** Gently wipe the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Water Resistance:** The earbuds are IPX6 sweatproof, meaning they can withstand splashes and sweat. Do not submerge them in water or expose them to heavy rain. Ensure they are dry before placing them back in the charging case.

Video: A short demonstration of the ROPASOMIC i27 earbuds' IPX6 water resistance, showing them being splashed with water.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid to activate pairing mode. Make sure Bluetooth is enabled on your device and select "i27". If issues persist, try forgetting the device on your phone and re-pairing.
- **No sound:** Check the volume levels on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and the power source. Check if the charging indicator light is active.
- **Uncomfortable fit:** Adjust the ear hooks and the position of the speaker until a comfortable and secure fit is achieved. Refer to the "Wearing the Earbuds" section.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	i27
Connectivity Technology	Wireless (Bluetooth 5.3)

Feature	Detail
Bluetooth Range	10 Meters
Ear Placement	Open Ear
Earpiece Shape	Hook
Control Type	Touch Control
Water Resistance Level	IPX6 (Water Repellent)
Battery Life (Total with Case)	Up to 40 Hours
Battery Life (Single Charge)	Up to 6 Hours
Charging Time	1.5 Hours
Audio Driver Type	Dynamic Driver
Audio Driver Size	13 Millimeters
Frequency Response	20 KHz
Sensitivity	97 dB
Impedance	16 Ohms
Item Weight	51 Grams (1.8 ounces)
Product Dimensions	2.5 x 2.5 x 1.2 inches

WARRANTY AND SUPPORT

Your ROPASOMIC i27 Open Ear Wireless Earbuds come with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact ROPASOMIC customer support.

If you encounter any issues or have questions regarding your earbuds, please contact ROPASOMIC customer support through the retailer's platform or the official ROPASOMIC website for assistance.