

SGNICS X13 Earbuds

SGNICS X13 Earbuds User Manual

Model: X13 Earbuds

INTRODUCTION

This manual provides detailed instructions for the proper use, setup, and maintenance of your SGNICS X13 Bluetooth 5.3 Earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PACKAGE CONTENTS

Verify that all items are present in your package:

- SGNICS X13 Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Eartips (S, M, L sizes)

PRODUCT OVERVIEW

The SGNICS X13 Earbuds feature an ergonomic ear hook design for secure fit during activities, a portable charging case with an LED display, and touch controls for easy operation.



Image: SGNICS X13 Earbuds with ear hooks and their charging case. The earbuds are black with a sleek design, and the charging case is also black with a glossy finish.



Image: The SGNICS X13 Earbuds placed inside their open charging case. A green LED display in the center of the case shows "100", indicating a full charge. The earbuds are securely nestled in their compartments.

Easy to Wear



Image: This image illustrates the three included eartip sizes (S, M, L) for user selection. Below, a three-step diagram demonstrates how to correctly wear the earbuds: 1) Insert the earbud, 2) Rotate to secure, 3) Adjust the ear hook for comfort.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

- 1. Charging the Case:** Connect the provided USB-C cable to the charging port on the case and to a USB power adapter (not included). The LED display on the case will show the charging progress. A full charge takes approximately 1.5 hours.
- 2. Charging the Earbuds:** Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots (L for left, R for right). The earbuds will automatically begin charging. The LED display on the case will indicate the charge level of the earbuds.

Fully charged earbuds provide up to 9 hours of playback, and the charging case extends total playtime to approximately 48 hours.



Image: A single SGNICS X13 earbud is shown being charged within its open case. A blue lightning bolt graphic indicates the charging process. The case's LED display shows "100", signifying a full charge.

2. Bluetooth Pairing

The earbuds utilize Bluetooth 5.3 for a stable and fast connection.

1. Initial Pairing:

- a. Open the charging case. The earbuds will automatically power on and enter pairing mode.
- b. Enable Bluetooth on your device (smartphone, tablet, etc.).
- c. Search for "X13 Earbuds" in the list of available Bluetooth devices and select it to connect.
- d. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

2. **Automatic Reconnection:** After initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case, provided Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Wearing the Earbuds

For optimal sound quality and comfort, choose the correct eartip size (S/M/L) and adjust the ear hooks.

- Select the eartips that provide a snug fit in your ear canal.
- Insert the earbud into your ear, then gently rotate it to secure.
- Adjust the flexible ear hook over your ear for a stable and comfortable fit, especially during sports or exercise.

Touch Controls

The earbuds feature touch-sensitive areas for controlling various functions. The exact touch patterns may vary slightly, but common functions include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

Making and Receiving Calls

The SGNICS X13 Earbuds are equipped with 4 microphones and Environmental Noise Canceling (ENC) technology to ensure clear call quality.

- Refer to the "Touch Controls" section for answering, ending, and rejecting calls.
- During a call, audio will be routed through the earbuds.

Music Playback

Experience Hi-Fi stereo sound with deep bass. Use the touch controls to manage your music.

- Refer to the "Touch Controls" section for playing, pausing, and skipping tracks.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds, eartips, and charging contacts with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX6 waterproof, protecting them from sweat and rain. However, they are not designed for submersion in water. Ensure they are dry before placing them back in the charging case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

IPX6 Waterproof & Sweatproof



Image: The SGNICS X13 Earbuds are depicted amidst water droplets, illustrating their IPX6 waterproof and sweatproof capabilities. The earbuds appear durable and resistant to moisture.

TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

- **Earbuds not pairing:**
 - Ensure earbuds are charged and removed from the case.
 - Turn off and on Bluetooth on your device.
 - Forget "X13 Earbuds" from your device's Bluetooth list and try pairing again.
- **No sound:**
 - Check device volume and earbud volume.
 - Ensure earbuds are properly connected to your device.
 - Try playing audio from a different application or source.
- **Charging issues:**
 - Verify the USB-C cable and power adapter are working correctly.

- Ensure charging contacts on earbuds and case are clean and free of debris.

SPECIFICATIONS

Feature	Detail
Model Name	X13 Earbuds
Brand	SGNICS
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.3
Water Resistance Level	IPX6 Waterproof
Earbud Playtime	Up to 9 hours
Total Playtime (with Charging Case)	Up to 48 hours
Charging Case Charge Time	Approx. 1.5 hours (USB-C)
Noise Control	Active Noise Cancellation (for calls, Environmental Noise Canceling)
Microphone Feature	Yes (4 microphones with ENC)
Form Factor	In Ear with Earhooks
Material	ABS+PC
Compatible Devices	iOS 9.0/Android 4.4 or above (Smartphones, Tablets)

SAFETY INFORMATION







Please observe the following safety guidelines:





- Do not disassemble, repair, or modify the product.
- Keep the earbuds and charging case away from extreme temperatures, direct sunlight, and open flames.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.
- Do not use the earbuds in situations where inability to hear surrounding sounds could be dangerous (e.g., driving, cycling, walking in traffic).

WARRANTY AND SUPPORT

SGNICS products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided with your purchase or visit

Related Documents - X13 Earbuds

 <p>FOYCOY</p> <p>USER MANUAL C17 Wireless Sports Headphones</p>	<p>FOYCOY C17 Wireless Sports Headphones User Manual</p> <p>User manual for FOYCOY C17 Wireless Sports Headphones, covering product overview, specifications, operations, charging, pairing, and troubleshooting for sports and everyday use.</p>
 <p>CAPOXO</p> <p>USER MANUAL X19</p>	<p>Capoxo X19 Wireless Earbuds User Manual</p> <p>Comprehensive user manual for the Capoxo X19 wireless earbuds, covering product overview, specifications, charging instructions, pairing, troubleshooting, and multi-function operations.</p>
 <p>Lakukom LA594A Bluetooth Headphones User Manual cover showing product image and specifications.</p>	<p>Lakukom LA594A Bluetooth Headphones User Manual</p> <p>User manual for the Lakukom LA594A Bluetooth headphones. This guide covers features such as deep bass, 16 hours of playtime, IPX7 waterproof rating, in-ear design with earhooks, and microphone for calls. Suitable for running and sports.</p>
 <p>H31 True Wireless Earbuds for Sports - User Guide cover showing earbuds in a case.</p> <p>User Guide for H31 True Wireless Earbuds for Sports</p>	<p>H31 True Wireless Earbuds for Sports - User Guide</p> <p>User guide for H31 True Wireless Earbuds for Sports, covering setup, functions, charging, and troubleshooting.</p>
 <p>Kuizil Q76-BY Wireless Earbuds: Quick Start Guide and Features cover with detailed text and product image.</p>	<p>Kuizil Q76-BY Wireless Earbuds: Quick Start Guide and Features</p> <p>Learn how to use your Kuizil Q76-BY wireless earbuds, including touch controls, pairing, charging, and Bluetooth connectivity. This guide provides essential information for sports and workout use.</p>
 <p>DB</p> <p>User Manual</p> <p>Customer Service Email: am@capoxo.store Web: www.capoxo.store WhatsApp: (+86) 139 2349 9475</p> <p>Packing List</p>	

Charging Case x1	Wireless Earbuds x2
Type-C Cable x1	Ear Type x2
User Manual x1	
01	
Overview	
	
*Note: Please REMOVE protective films of the LED power display screen and charging point before using them.	
02	
Product Specification	
<ol style="list-style-type: none">Model Name: D8Bluetooth Version: V5.3Supports: A2DP, HFP, HSP, AVRCPEarbuds Size/Weight: 40*30*23mm/1gCharging Case Size/Weight: 100*10*30mm/122gCharging Port: Type-CStandby Time: 148hEarbud Battery: 70mAhCharging Case Battery: 300mAhTransmission Range: 33 feet/without obstacle	
Power On/Off	
Auto Power On Take the earbuds out from the charging case, they will turn on automatically.	
Auto Power Off Put the earbuds back into the charging case, they will disconnect & turn off automatically.	
Manually Power On If the earbuds are out of the charging case and power off, then press & hold them for 5s, they will power on.	
Manually Power Off In non-music mode or standby mode, press & hold either earbud for 5s, both earbuds will power off at the same time.	
03	
Bluetooth Connection	
Prior to first use (or not in use for long time), please fully charge both earbuds and charging case.	
First Time Pairing	
Step 1 - Take both earbuds out from charging case, they will automatically power on and enter pairing mode. At this time, the indicator of power-on/standby will flash Blue & Red light alternately, and the voice earbud indicator flashes Blue 2 times every 2s.	
Step 2 - Activate the Bluetooth setting on your phone, search and connect "D8".	
Once connected, the Red light of both earbuds goes off.	
	
*Note: If the earbuds are not connected to your device over 5 minutes, the earbuds will power off automatically.	
04	
For Second Time Use	
If the earbuds have already connected with your device, and the Bluetooth setting of this device is on, in the second time using, when you take out the earbuds from the charging case, they will connect with your device automatically.	
Pair with Other Device	
D8 sports earbuds have memory function, they usually auto connect with the last paired device. Thus, if you want to pair them with other device, you should disconnect "D8" from the last paired device. Also forget the pairing record on the last device. Then try to connect it to a new device, it should work properly.	
Mono Mode (Only Left/Right Earbud is being Used)	
You can use one earbud alone, leave another earbud in the charging case. • When in Dual mode, put one earbud into the charging case. • Or only take one earbud out of the charging case, then search & connect "D8" on your device.	
	
05	
Factory Restore Settings	
When should I reset?	
<ol style="list-style-type: none">Only one earbud plays music.Both earbuds can not work with together.Occur connection issues.	
Follow Steps Below to Reset Earbuds	
Step 1 Delete the pairing name "D8" on your phone and deactivate the Bluetooth setting of your device used by the earbuds.	
Step 2 Put the two earbuds in the charging case, keep them in the charging state.	
Step 3 Press the MFB button for 5 seconds, then the earbud will flash red & blue light alternately for 2 seconds, which means the both earbuds have reset completely.	
Step 4 Then, pick up the earbuds to turn them on, activate the Bluetooth setting on your phone search and select "D8" to connect, it should work properly.	
If not, please put the earbuds back to the charging case and repeat the steps above.	
*Note: After resetting, the pairing record between the earbuds and all your devices will be cleared. In case there is any unsuccessful message in your device, please consider to delete the historical record of "D8" and try the pairing process again.	
06	
Earbuds Charging	
To Charge Earbuds Insert the Earbuds into charging case properly, they will power off & get charged.	
Flash during charging: Turn off once fully charged.	
Earbud's LED light Red light up means "being charged", Red light off means "fully charged".	
Low Battery Alarm	
When the battery is less than 10% (and the voltage is lower than 3.4V), a prompt voice "Please charge" will be advised, announce once every 5 minutes and 5 times in total, and then the earbuds will power off as normal.	
*Tip: If the earbuds don't charge or even can't turn on, that may because there is a substandard type or something else on the charging connector or charging pin. You can solve this problem by cleaning the magnet connector on the earbuds and charging pins on the charging case with alcohol wipes.	
07	
Charging Case Charging	
Type-C Charging	
There is a Type-C charging cable in the small black paper box inside the packing box. Please use the provided Type-C Cable with a 10V/1A adapter (not included) to charge the charging case.	
	
During charging, the charging case power display will show the battery in real time. The number will be displayed as 100 when fully charged.	
Wireless Charging	

D8 Wireless Earbuds User Manual

User manual for the D8 Wireless Earbuds, detailing features, setup, operation, and troubleshooting. Includes information on Bluetooth pairing, charging, call and music controls, and safety precautions.

Easy to charge your charging case without cables, just put the charging case on a wireless charging pad.
If the charging case doesn't start to charge, please try to reposition it.
(Wireless Charging Pad Not Included)



04

To Charge Your Phone

Fully charged charging case supports charging your mobile phone, connect it to your mobile phone with your charging cable.



Multi-Function Operations



For Call

Answer Call: Click Once
End Call: Click Once
Reject Call: Long Press 2S



"L" or "R" Earbud
Both ON



Voice Assistant

Voice assistant: Quick Triple-Click

*Note: Must in non-music mode or standby mode.



"L" or "R" Earbud
Both ON

05



For Music

(Functions on "R" Earbud)

Play/Pause: Click Once
Next Track: Quick Double-Click
Volume + : Long Press & Hold



"R" Earbud

(Functions on "L" Earbud)

Play/Pause: Click Once
Previous Track: Quick Double-Click
Volume - : Long Press & Hold



"L" Earbud

*Note: In music mode, "R" earbud only supports next song and volume +. You have to go back to the previous song by your phone.
*Note: In music mode, "L" earbud only supports next song and volume -. You have to go back to the previous song by your phone.

How to Wear the Earbuds Correctly?

Choose best fit ear

Then gently push the earbuds into your ears and adjust them to get a comfortable fit.



06

Safety Attention

1. Do not use the earbuds while driving a car, operating machinery or performing other activities that require hearing surrounding sounds.
2. Using earbuds at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety.
3. Please avoid use in thundering and raining days to prevent damage or electrical shock.
4. Please keep the earbuds out of extreme heat or humidity, do not use any corrosive cleaner(s) to clean the earbuds.
5. Please avoid disassembly/reassembly the product in case of failure or fire accident.
6. Please keep beyond the reach of kids or pets.
7. Please stop using the device if it causes any discomfort or pain.
8. As the Bluetooth signal cannot transmit in water, it is not suitable for swimming or diving. It is designed in water, do not turn the earbuds on until completely dried.

How to Place the Earbuds?



07

How to Sync Volume on Android?

To protect users from potential hearing damage, Android's limit on max volume is quite low for Bluetooth audio device.

If you feel the volume is too low, please access developer options and enable absolute volume, so you'll be able to use the system at your own will and to the full capabilities of your Bluetooth earbuds.



(Please scan this QR code to watch a video to learn more details.)

Find Build Number Firstly

Android 4.1 and lower: the Developer options screen is available by default.

Android 4.2 and higher: the Developer options in Android phones are hidden, you must enable this screen through Build Number.

Android 7.0 and lower: Settings > About Phone > Build Number
Android 8.0 and Android 8.1: Settings > System > About Phone > Build Number

Enable Developer Options

Locate the Build number and tap it about 7 times in succession to enable Developer options. You may also have to tap to your PIN for verification. Once developer options are activated, you will see a message that reads "You are now a developer".

08

Go back to the Settings pane, search Developer options as an entry. At the top of the Developer options screen, you can toggle the options as Figure 1.



(Figure 1)

Enable Absolute Volume

Scroll down until you reach the Networking section. Once there, enable (toggle ON) the absolute volume option as Figure 2.



(Figure 2)

*Note: These options in the figures may be different from the device you're using. Typically, the choices depend on the type and model of the device you are working with.

09