

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ingenuity](#) /

› [Ingenuity Prepare to Potty 3-in-1 System Instruction Manual \(Model 17143\)](#)

Ingenuity 17143

Ingenuity Prepare to Potty 3-in-1 System Instruction Manual

Model: 17143

INTRODUCTION

The Ingenuity Prepare to Potty 3-in-1 System is designed to assist toddlers aged 18 months and up through various stages of potty training. This versatile system transitions from a standalone potty seat to an adult toilet topper and a double step stool, offering multiple solutions in one compact unit.



Image: The Ingenuity Prepare to Potty 3-in-1 System, illustrating its primary configurations as a potty and a step stool.

SETUP AND ASSEMBLY

The Ingenuity Prepare to Potty 3-in-1 System is designed for easy assembly. It typically arrives in a few main components that snap together without the need for tools.

1. **Base Assembly:** Ensure the main base unit is placed on a flat, stable surface.
2. **Potty Bowl Insertion:** Insert the removable potty bowl into the designated slot within the base.
3. **Potty Topper Placement:** Place the soft potty topper onto the potty bowl. It should fit securely.
4. **Lid Attachment:** Attach the lid to the back of the base unit, ensuring the hinges are properly aligned and secured.

For a visual guide on assembly and functionality, please refer to the official product video below:

Video: Official product demonstration of the Ingenuity Prepare to Potty 3-in-1 System, showcasing its assembly and various uses.

OPERATING INSTRUCTIONS

The 3-in-1 system offers three distinct modes to support your child's potty training journey:

1. Potty Seat Mode

Use the complete unit as a standalone potty. The removable pot features a pour spout for easy and hygienic cleanup.



Image: A toddler using the Ingenuity Prepare to Potty in its standalone potty seat configuration.

2. Potty Topper Mode

When your child is ready to transition to an adult toilet, simply remove the potty topper from the base and place it securely onto most standard adult-sized toilets (round, elongated, and D-shape). The topper includes an integrated splash guard and handles for added security and comfort.

Removable potty
topper fits most
round and oval
adult toilets



Image: The removable potty topper positioned on an adult toilet seat.



Image: A toddler utilizing the potty topper on an adult toilet, with the base serving as a step stool.

3. Double Step Stool Mode

Close the lid on the base unit to convert it into a double step stool. This allows your child to reach standard adult-sized toilets and bathroom sinks independently. The step stool features a non-skid bottom for enhanced safety.



Image: The Ingenuity Prepare to Potty base transformed into a double step stool.



Double step for growing toddlers

Image: A child using the step stool to access a bathroom sink, with adult supervision.

MAINTENANCE AND CLEANING

Regular cleaning is essential for hygiene and product longevity.

- **General Cleaning:** Wipe clean with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the plastic.
- **Removable Pot:** The inner pot is easily removable for quick disposal of contents and thorough cleaning. Its pour spout facilitates mess-free emptying.



Image: Close-up view highlighting the removable pot and ease of cleaning for the potty system.


TROUBLESHOOTING

If you encounter any issues with your Ingenuity Prepare to Potty 3-in-1 System, please refer to the following common concerns:

- **Lid is difficult to open:** Ensure the lid is not jammed or obstructed. Apply gentle, even pressure when opening. If the issue persists, check for any debris in the hinge mechanism.
- **Potty topper feels unstable on adult toilet:** Verify that the potty topper is correctly positioned on the adult toilet seat. It is designed to fit most standard round, elongated, and D-shape toilets. Ensure the adult toilet seat itself is stable.
- **Step stool slides on floor:** The step stool features a non-skid bottom. Ensure the floor surface is clean and dry to maximize grip. Avoid using on wet or excessively slippery surfaces.

SPECIFICATIONS

Feature	Detail
Model Number	17143
Color	Green
Material	100% Plastic
Item Weight	2.86 Pounds
Product Dimensions	14.57 x 12.6 x 10.43 inches
Additional Features	Slip Resistant Step, Removable Pot with Pour Spout, Integrated Splash Guard and Handles on Topper
Care Instructions	Wipe clean with mild soap



WARRANTY AND SUPPORT

© 2025 Ingenuity. All rights reserved.

Related Documents - 17143





linguistbaby.com



lingersaltysbaby.com



the following: *Grass with:*