

[Manuals.plus](#) /

> [Mastela](#) /

> Mastela Swing H Multi-Motion Baby Cradle (Model MM02) User Manual

## Mastela MM02

# Mastela Swing H Multi-Motion Baby Cradle (Model MM02) User Manual

Model: MM02 | Brand: Mastela

## IMPORTANT SAFETY INFORMATION

---

Read all instructions before assembly and use of the Mastela Swing H Multi-Motion Baby Cradle. Keep this manual for future reference. Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the restraint system.
- Never leave child unattended.
- Do not use this product if it is damaged or broken.
- Maximum weight capacity: 15 kg.
- Ensure the cradle is placed on a flat, stable surface.
- Keep away from open flames and other heat sources.

## PRODUCT OVERVIEW

---

The Mastela Swing H Multi-Motion Baby Cradle is designed to provide a safe and soothing environment for infants and toddlers from birth up to 36 months (or 15 kg). It features multiple swing motions, built-in melodies, and app connectivity for enhanced control.



Figure 1: Front view of the Mastela Swing H Multi-Motion Baby Cradle, showcasing its comfortable seating and five-point harness system.

## SETUP AND ASSEMBLY

---

The Mastela Swing H Multi-Motion Baby Cradle comes largely pre-assembled. No complex assembly is required.

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the cradle on a firm, level, and stable surface. Ensure there is sufficient space around the cradle for safe operation.

3. **Power Connection:** Connect the power adapter to the cradle's power input port and then plug it into a suitable electrical outlet.
4. **Canopy and Toy Bar Attachment:**



Figure 2: The baby cradle with its canopy and mosquito net fully extended, providing protection and a serene environment.

Attach the canopy by aligning the connectors and pressing firmly until it clicks into place. The mosquito net can be extended from the canopy for added protection.

5. **Harness Adjustment:** Adjust the five-point harness to securely fit your child. Ensure straps are snug but not too tight.

## OPERATING INSTRUCTIONS

---

The cradle features a gentle touch control panel and can also be controlled via a mobile application.

### Control Panel Functions

- **Power Button:** Press to turn the cradle on or off.
- **Motion Selection:** Choose from five pre-set swing motions: 3 up-to-down and 3 side-to-side. Press the motion button repeatedly to cycle through options.
- **Motion Combinations:** The cradle supports customizable motion combinations. Refer to the on-screen display for active motion patterns.
- **Timer Settings:** Set the operating time to 15, 30, 45 minutes, or a default of 60 minutes. The cradle will automatically stop after the selected duration.
- **Melody Selection:** Access twelve built-in melodies. Press the music button to cycle through tunes.
- **Volume Control:** Adjust the melody volume using the dedicated volume buttons.

## App Connectivity

Download the official Mastela app from your device's app store. Once installed, pair your mobile device with the cradle via Bluetooth. The app allows you to:

- Play music from your device.
- Adjust motion types and speed.
- Control melodies and volume.

## Converting Modes (Bed Mode / Seat Mode)

The cradle offers convertible modes to adapt to your child's needs.



Figure 3: The cradle configured in a reclined bed mode, suitable for newborns and sleeping.



Figure 4: The cradle adjusted to an upright seat mode, ideal for older infants who can sit unassisted.

To switch between bed and seat mode, locate the recline adjustment mechanism, typically on the side or back of the seat. Follow the indicators to adjust the backrest to the desired position. Ensure it locks securely before placing your child in the cradle.

## MAINTENANCE AND CARE

---

Regular maintenance ensures the longevity and safety of your Mastela Baby Cradle.

- **Cleaning Fabric Parts:** The dense mattress and other removable fabric parts are machine washable. Use a gentle cycle with cold water and mild detergent. Air dry thoroughly.
- **Cleaning Frame:** Wipe the plastic and metal frame components with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check all parts for wear, damage, or loose fasteners. Discontinue use if any damage is found and contact customer support.
- **Storage:** When not in use, store the cradle in a clean, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

If you encounter issues with your Mastela Swing H Multi-Motion Baby Cradle, refer to the following common solutions:

Problem	Possible Cause	Solution
Cradle does not power on.	Power adapter not connected or faulty outlet.	Ensure power adapter is securely plugged into both the cradle and a working electrical outlet. Test the outlet with another device.
Swing motion is not working.	Motion setting not activated or obstruction.	Press the motion button on the control panel or via the app. Check for any objects obstructing the swing mechanism. Ensure child's weight does not exceed 15 kg.
No sound from melodies.	Volume is too low or muted.	Increase the volume using the control panel or the app. Ensure no external audio source is overriding the built-in melodies.
App cannot connect to cradle.	Bluetooth is off or cradle is out of range.	Ensure Bluetooth is enabled on your mobile device. Move your device closer to the cradle. Restart both the app and the cradle.

## SPECIFICATIONS

Feature	Detail
Model Number	MM02
Brand	Mastela
Color	Green
Product Dimensions (L x W x H)	78L x 45.5W x 80H Centimeters
Item Weight	4.5 Kilograms
Material	Metal, Plastic, Polyester
Maximum Weight Recommendation	15 Kilograms
Age Recommendation	Birth to 36 Months
Swing Motions	5 pre-set (3 up-to-down, 3 side-to-side), customizable combinations
Timer Settings	15, 30, 45, 60 minutes
Melodies	12 built-in with volume control
Connectivity	App control (Bluetooth)
Harness	Five-point harness
Care Instructions	Machine Washable (removable parts)
Assembly Required	No

## WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer.

Warranty terms may vary by region and retailer.

## Customer Support

If you require further assistance or have questions not covered in this manual, please contact:

- **Manufacturer:** Guangzhou Mastela commodity,Co. Ltd
- **Importer (India):** TrucareKidz India Pvt Ltd
- Refer to your purchase receipt or the product packaging for specific contact details.

