

Manuals.plus /

› HYTRIC /

› HYTRIC Travel Electric Kettle MC31G User Manual

HYTRIC MC31G

HYTRIC Travel Electric Kettle MC31G User Manual

Model: MC31G

1. INTRODUCTION

Thank you for choosing the HYTRIC Travel Electric Kettle. This compact and versatile appliance is designed for convenience, allowing you to enjoy hot beverages and meals wherever you go. Its foldable design, dual power control, and safety features make it an ideal companion for travel, camping, dormitories, and offices. Please read this manual thoroughly before use to ensure safe and optimal operation.



Image: The HYTRIC Travel Electric Kettle showcasing its portable and foldable design, with dimensions for both states.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the kettle is filled with water between the MIN and MAX marks before operating to prevent dry boiling.
- The kettle features automatic shut-off and boil-dry protection for your safety.
- The inner lid and liner are made of 304 food-grade stainless steel, and the product is BPA-Free and Non-Toxic.

3. PRODUCT FEATURES

- **Portable & Foldable Design:** The kettle collapses for easy storage and transport, making it ideal for travel. Folded size: 5.9 inch x 7.87 inch; Unfolded size: 7.48 inch x 7.87 inch. Includes a storage bag.
- **Dual Mode Control:** Offers two settings: 'Boil & Keep Warm' (Mode I) for automatic boiling and temperature maintenance (reheats if temperature drops below 80°C), and 'Constant Heating' (Mode II) for continuous heating, suitable for cooking noodles or eggs.
- **Fast Boiling:** Heats 650ml of water in approximately 6 minutes.
- **Premium Materials:** Inner lid and liner are constructed from 304 food-grade stainless steel, ensuring healthy drinks and preventing odors. The kettle is BPA-Free and Non-Toxic.
- **Enhanced Safety:** Equipped with over-heat and boil-dry protection, ensuring safe operation.
- **Convenient Storage:** Detachable base, foldable handle, and integrated cord storage in the base for maximum portability.

Portable & Foldable Water Kettle



Image: The kettle's compact folded and extended dimensions are highlighted, demonstrating its travel-friendly design.

Why choose us?	Stainless Steel Collapsible Kettle  <ul style="list-style-type: none">✓ Stainless steel inner has no odor.✓ Double-walled design, removable base for easy cleaning.	Silicone Non-Detachable Collapsible Kettle  <ul style="list-style-type: none">✗ Silicone material, easy to produce odor.✗ Non-detachable, difficult to clean.
-----------------------	--	---

Image: Illustration of the kettle's dual mode control, explaining the 'Boil & Keep Warm' and 'Constant Heating' functions.

4. PACKAGE CONTENTS

Your HYTRIC Travel Electric Kettle package includes:

- 1 x HYTRIC Travel Electric Kettle (Model: MC31G)
- 1 x Detachable Power Base with Embedded Cord Storage
- 1 x Storage Bag
- 1 x User Manual

5. SETUP

Follow these steps to set up your HYTRIC Travel Electric Kettle:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Unfold Kettle:** Gently pull the top section of the kettle upwards until it locks into its full size. Ensure the handle is extended and locked into place.
3. **Connect Power:** Take the detachable power base. If the power cord is stored, gently pull it out from the base. Connect the power cord to the kettle's designated port, ensuring it is fully inserted.
4. **Fill Water:** Open the kettle lid and fill the kettle with water. Do not exceed the 'MAX' fill line to prevent overflow during boiling.
5. **Close Lid:** Securely close the kettle lid.




Image: A step-by-step visual guide demonstrating the setup process, including unfolding, connecting the base, filling water, and powering on.

6. OPERATING INSTRUCTIONS

The HYTRIC Travel Electric Kettle offers two main operating modes:

- **Mode I: Boil & Keep Warm**

This mode is ideal for quickly boiling water and then maintaining its temperature. Once the water boils, the kettle will automatically shut off. If the water temperature drops below 80°C, it will automatically reheat to maintain warmth.

- **Mode II: Constant Heating**

This mode continuously heats the contents without automatically shutting off after boiling. It is suitable for cooking items like noodles or eggs, where sustained heat is required. You will need to manually switch off the kettle when using this mode.

To select a mode, use the control switch located on the kettle's base. Ensure the kettle is plugged into a power outlet before selecting your desired mode.

Two Modes Control



Image: A detailed view of the kettle's control panel, illustrating the two distinct heating modes and their indicators.

7. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your HYTRIC Travel Electric Kettle:

- **Always unplug the kettle** from the power outlet and allow it to cool completely before cleaning.
- **Hand Wash Only:** The kettle is designed for hand washing. Do not immerse the electrical base or cord in water.
- **Interior Cleaning:** The 304 food-grade stainless steel interior can be cleaned with a soft sponge and mild dish soap. Rinse thoroughly.
- **Exterior Cleaning:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale, fill the kettle with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution. Boil the mixture and let it sit for 30 minutes to an hour, then rinse thoroughly several times.
- **Storage:** Once clean and dry, collapse the kettle, fold the handle, and store the power cord in its integrated compartment. Place the kettle in its storage bag for protection.



Image: Close-up images highlighting the 304 food-grade stainless steel interior, the embedded cord storage, and the foldable handle for easy cleaning and storage.

8. TROUBLESHOOTING

If you encounter any issues with your HYTRIC Travel Electric Kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not heat up.	Not properly plugged in; Power outlet malfunction; Kettle not correctly placed on base; Boil-dry protection activated.	Ensure plug is firmly in outlet and kettle base. Check power outlet with another appliance. Reposition kettle on base. If boil-dry activated, unplug, let cool for 15 minutes, then refill and restart.
Water overflows during boiling.	Kettle overfilled.	Do not fill water above the 'MAX' fill line.
Unusual odor or taste in water.	New appliance odor; Mineral deposits.	Boil and discard water several times before first use. Descale the kettle as per cleaning instructions.
Kettle does not collapse or extend smoothly.	Mechanism obstructed or misaligned.	Ensure no debris is caught in the folding mechanism. Apply gentle, even pressure.

If the problem persists, please contact HYTRIC customer support.

9. SPECIFICATIONS

- **Brand:** HYTRIC
- **Model Name:** Foldable Electric Kettle

- **Item Model Number:** MC31G
- **Capacity:** 650 ML
- **Material:** 304 Stainless Steel Interior, BPA-Free, Non-Toxic
- **Color:** Black
- **Product Dimensions (Unfolded):** 7.87"L x 7.87"W x 5.9"H
- **Item Weight:** 1.8 pounds
- **Special Features:** Automatic Shut-Off, Embedded Electric Cord, Foldable, Heat Resistant Handle, Stainless Steel Interior
- **Recommended Uses:** Boiling, Heating (Water, Noodles, Tea, Coffee, Eggs)
- **Product Care Instructions:** Hand Wash

10. WARRANTY AND SUPPORT

HYTRIC products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal use. For specific warranty details, please refer to the warranty card included in your package or contact HYTRIC customer support.

For technical support, troubleshooting assistance, or warranty claims, please contact our customer service team:

- **Website:** Visit the HYTRIC Store on Amazon
- **Email:** (Please refer to product packaging for contact email)
- **Phone:** (Please refer to product packaging for contact phone number)

Please have your model number (MC31G) and purchase date ready when contacting support.