



Manuals.plus /

› **JLab** /

› JLab JBuds Open Sport Earbuds User Manual - Model EBJBOPSPRTRBLK82

## JLab EBJBOPSPRTRBLK82

# JLab JBuds Open Sport Earbuds User Manual

Model: EBJBOPSPRTRBLK82

## INTRODUCTION

---

The JLab JBuds Open Sport Earbuds are designed to provide an open-ear listening experience, allowing you to enjoy audio while remaining aware of your surroundings. Featuring a secure earhook design, these earbuds are suitable for various activities, including workouts and daily use. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your JBuds Open Sport.



Image: JLab JBuds Open Sport Earbuds, showcasing the earbuds and their charging case. One earbud is positioned outside the case, highlighting its earhook design.

## WHAT'S IN THE BOX

---

Upon opening your JLab JBuds Open Sport Earbuds package, you should find the following components:

- JBuds Open Sport Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual (this document)



Image: The complete package contents, including the JBuds Open Sport Earbuds, their charging case, and the distinctive blue USB-C charging cable.

## SETUP

---

### 1. Charging the Earbuds and Case

Before first use, fully charge your JBuds Open Sport Earbuds and their charging case. The case provides an additional 17 hours of playtime, extending the earbuds' 9-hour battery life.

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a USB power source.
3. The indicator light on the case will show charging status. Allow sufficient time for a full charge.



Image: JLab JBuds Open Sport Earbuds securely placed within their charging case, indicating they are ready for charging or storage.

## 2. Initial Bluetooth Pairing

The JBuds Open Sport Earbuds support Google Fast Pair for Android devices and standard Bluetooth pairing for all other devices.

### For Android Devices (Google Fast Pair):

1. Ensure Bluetooth is enabled on your Android device.
2. Open the charging case with the earbuds inside.
3. A pop-up notification will appear on your Android device. Follow the on-screen prompts to connect.

### For Other Bluetooth Devices (iOS, Laptops, etc.):

1. Remove both earbuds from the charging case. They will automatically enter pairing mode (indicated by flashing lights).
2. Go to your device's Bluetooth settings.
3. Select "JBuds Open Sport" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbud lights will stop flashing.

## 3. JLab App Customization

Enhance your experience by downloading the JLab App. The app allows you to customize touch controls, adjust sound preferences with presets (JLab Signature, Balance, Bass Boost), and receive software updates.

- Download the JLab App from the Google Play Store or Apple App Store.
- Connect your JBuds Open Sport Earbuds to your device.
- Open the JLab App and follow the instructions to connect and customize your earbuds.

## OPERATING INSTRUCTIONS

---

### 1. Secure Earhook Fit

The earhook design ensures a stable fit during physical activity. To secure the fit, gently pinch the earhook to conform it to your ear's shape. This prevents the earbuds from falling off during rigorous movements.



Image: A detailed view of a single JLab JBuds Open Sport Earbud, highlighting the open-ear speaker and the flexible earhook for secure placement.

### 2. Touch Controls

The JBuds Open Sport Earbuds feature touch-sensitive controls on each earbud. These controls can be customized via the JLab App. Refer to the app for a detailed overview of touch functions and customization options.

### 3. Bluetooth Multipoint

Bluetooth Multipoint allows you to connect your earbuds to two devices simultaneously. This enables seamless transitions between audio sources, such as switching from a podcast on your laptop to a call on your mobile phone without re-pairing.

- Pair the earbuds with your first device (e.g., laptop).
- Disconnect Bluetooth from the first device.
- Pair the earbuds with your second device (e.g., smartphone).
- Reconnect Bluetooth on your first device. The earbuds will now be connected to both devices.

### 4. Clear Calls

Each earbud is equipped with a MEMS microphone featuring noise-canceling technology. This ensures your voice is transmitted clearly during calls, even in noisy environments, by reducing background sound.

### 5. Safe Listening

The open-ear design positions 14.2mm speakers in front of your ear, delivering audio without blocking your ear canal. This allows you to hear your music, podcasts, or calls while maintaining awareness of your surroundings, enhancing safety in various situations.

## MAINTENANCE

---

### 1. IP55 Durability

The JBuds Open Sport Earbuds have an IP55 rating, making them resistant to sweat and dust. This protection allows for use during workouts and in various outdoor conditions. While resistant, they are not designed for submersion in water.

### 2. Cleaning and Storage

- Wipe the earbuds and charging case with a soft, dry, or slightly damp cloth as needed. Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts on both the earbuds and the case are clean and dry before charging.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.

## TROUBLESHOOTING

---

### No Audio or Pairing Issues:

- **Ensure Earbuds are Charged:** Verify both earbuds and the charging case have sufficient battery life.
- **Re-pair Earbuds:** Forget "JBuds Open Sport" from your device's Bluetooth settings, then repeat the initial pairing steps.
- **Reset Earbuds:** If issues persist, consult the JLab App or JLab support website for specific earbud reset instructions.

### Poor Sound Quality:

- **Check Earbud Placement:** Ensure the earbuds are positioned correctly in front of your ears for optimal sound delivery.
- **Adjust EQ Settings:** Use the JLab App to experiment with different EQ presets (JLab Signature, Balance, Bass Boost) to find your preferred sound profile.

- **Volume Levels:** Adjust volume on both your connected device and the earbuds.

### Earbuds Not Staying in Place:

- **Adjust Earhook:** Gently pinch and mold the earhook to better fit the contour of your ear.
- **Proper Orientation:** Ensure the earbuds are worn on the correct ear (Left/Right) and oriented as intended.

## PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	Open Sport
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 4.0
Included Components	Charging Case, User Manual
Compatible Devices	Laptops, Smartphones, Tablets
Water Resistance Level	IP55 (Water Resistant)
Frequency Range	20 Hz - 20,000 Hz
Control Method	App, Touch
Battery Life	Up to 26 Hours (9 hours in buds + 17 hours in case)
Audio Driver Type	Hybrid Driver
Earpiece Shape	Earhook
Special Feature	Lightweight, Multipoint Pairing, Touch Control
Product Dimensions	3.62 x 1.54 x 5.43 inches
Item Weight	5.3 ounces
Item Model Number	EBJBOPSPRTRBLK82
UPC	810119072627

## WARRANTY AND SUPPORT

For warranty information, technical support, or to view additional product resources, please visit the official JLab website or contact JLab customer service.

You can find more information and support at the JLab Store on Amazon.