

- Manuals.plus /
- › [Wulcea](#) /
 - › Wulcea Graphene Heated Jacket for Men (Model RTAX-018A) Instruction Manual

Wulcea RTAX-018A

Wulcea Graphene Heated Jacket for Men Instruction Manual

Model: RTAX-018A

1. PRODUCT OVERVIEW

The Wulcea Graphene Heated Jacket is designed to provide superior warmth and comfort in cold environments. Featuring advanced graphene heating technology and a high-capacity battery pack, this jacket offers customizable warmth for extended periods. Its durable, windproof, and waterproof design ensures protection against various weather conditions.

GRAPHENE HEAT

FAR INFRARED BIOMIMETIC WARMTH



HONEYCOMB STRUCTURE

BUILT TO LAST

INHERENTLY SAFE HEATING

EVENLY DIFFUSION HEATING

LINEAR STRUCTURE

FRAGILE BY DESIGN

DANGEROUS HOT SPOTS

PARTIAL ZONE HEATING



Image 1.1: Front view of the Wulcea Graphene Heated Jacket.

Key Features:

- **Graphene Heating Technology:** Provides rapid, consistent, and evenly distributed heat.
- **High-Capacity Battery:** Includes a 12V 18,400mAh fast-charging power bank for extended heating duration.
- **Multiple Heat Zones:** Strategically placed heating elements for targeted warmth.
- **Durable Construction:** Windproof and waterproof exterior with a comfortable fleece lining.

- **Stylish Design:** Combines functionality with a modern aesthetic.

2. SAFETY INFORMATION

Your safety is paramount. The Wulcea Graphene Heated Jacket utilizes advanced graphene heating elements designed for even heat distribution and reduced risk of hot spots, unlike traditional linear heating wires. Always follow these guidelines:

- Do not use the jacket if the heating elements or wiring appear damaged.
- Avoid folding the jacket tightly when the heating function is active to prevent damage to the elements.
- Keep the battery pack dry and away from extreme temperatures.
- Disconnect the battery pack before washing the jacket.
- If you experience discomfort or excessive heat, immediately turn off the jacket and disconnect the battery.




Image 2.1: Graphene heating provides even warmth, reducing the risk of localized hot spots associated with traditional linear heating.

Your browser does not support the video tag.

Video 2.1: This video illustrates the difference between graphene infrared heating and traditional copper wire heating, highlighting the even heat distribution of graphene technology.

3. PACKAGE CONTENTS

Upon opening your Wulcea Graphene Heated Jacket package, please ensure all the following items are present:

- 1 x Wulcea Graphene Heated Jacket
- 1 x 12V 18,400mAh Power Bank
- 1 x Charging Cable for Power Bank
- 1 x User Manual (this document)

4. SETUP AND CHARGING

4.1 Charging the Power Bank

Before first use, fully charge the included 12V 18,400mAh power bank. Connect the charging cable to the power bank and plug it into a suitable power source. The LED display on the power bank will indicate the charging status and battery level. A full charge typically takes approximately 4.5 hours from a depleted state.



Image 4.1: The included 12V 18,400mAh power bank.

4.2 Connecting the Power Bank to the Jacket

1. Locate the battery pocket inside the jacket, typically on the left side.
2. Inside the pocket, you will find a connecting cable.
3. Connect the cable from the jacket to the designated port on the fully charged power bank.
4. Place the power bank securely into the pocket and zip it closed.



Image 4.2: Power bank connected inside the jacket pocket.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the features of the jacket, including how to connect the power bank.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off and Adjusting Heat Settings

Once the power bank is connected, locate the power button on the inside label of the jacket. This button controls the heating function and allows you to cycle through heat settings.

1. **To Power On:** Press and hold the power button for approximately 3 seconds until it illuminates. The jacket will typically start on the High heat setting (Red light).
2. **To Adjust Heat:** Briefly press the power button to cycle through the heat settings:
 - **High Heat (Red Light):** Approximately 131°F (55°C), lasting 3-4 hours.
 - **Medium Heat (Blue Light):** Approximately 113°F (45°C), lasting 5-6 hours.
 - **Gentle Heat (Green Light):** Approximately 95°F (35°C), lasting 8-10 hours.
3. **To Power Off:** Press and hold the power button for approximately 3 seconds until the light turns off. Alternatively, you can disconnect the power bank.



Image 5.1: Heat settings and estimated battery life.



Image 5.2: The discreetly placed power button.

5.2 Heat Zones

The jacket features multiple graphene heating zones strategically placed to provide warmth to key areas of your body, including the back, chest, and neck. This design ensures comprehensive and comfortable heating.

Garment's Measurements

Size	SHOULDER (CLOTH)	SHOULDER (FIT RANGE)	BUST (CLOTH)	BUST (FIT RANGE)	HIP	LENGTH	SLEEVE
S	20.1"	18.1-18.9"	46.5"	33.6-38.6"	44.9"	28.0"	25.4"
M	20.9"	18.9-19.7"	48.9"	39.0-41.0"	47.3"	28.8"	26.0"
L	21.7"	19.7-20.4"	51.2"	41.4-43.3"	49.6"	29.6"	26.6"
XL	22.7"	20.7-21.5"	54.4"	44.5-46.5"	52.8"	30.3"	27.2"
2XL	23.6"	21.7-22.5"	57.5"	47.7-49.6"	55.9"	31.1"	27.6"
3XL	24.8"	22.9-23.6"	61.5"	51.6-53.6"	59.9"	31.9"	28.0"
4XL	26.0"	24.0-24.8"	64.6"	54.8-56.7"	63.0"	32.7"	28.4"
5XL	27.2"	25.2-26.0"	67.8"	58.0-59.9"	66.2"	33.5"	28.8"

Image 5.3: Illustration of the 6 smart heat zones.

Your browser does not support the video tag.

Video 5.1: This video provides a brief overview of the Wulcea Graphene Heated Jacket's heating capabilities and operation.

6. CARE AND MAINTENANCE

Proper care will extend the life and performance of your heated jacket.

6.1 Washing Instructions

- **Disconnect Power:** Always ensure the power bank is disconnected and removed from the jacket before washing.
- **Hand Wash:** Hand washing is recommended for best results. Use cold water and a mild detergent.
- **Machine Wash:** If machine washing, use a gentle cycle with cold water. Place the jacket in a laundry bag to protect the heating elements.
- **Do Not Bleach:** Avoid using bleach or harsh chemicals.
- **Do Not Wring:** Gently squeeze out excess water.
- **Air Dry:** Hang the jacket to air dry completely before reconnecting the power bank or wearing. Do not tumble dry or iron.

6.2 Storage

Store the jacket in a cool, dry place when not in use. Ensure the power bank is fully charged before long-term storage to maintain battery health.




Image 6.1: Key features like the detachable hood, waterproof fabric, and fleece lining contribute to the jacket's durability and ease of care.

7. TROUBLESHOOTING

If you encounter issues with your Wulcea Graphene Heated Jacket, please refer to the common problems and solutions below. For further assistance, contact customer support.

Problem	Possible Cause	Solution
Jacket not heating	Power bank not connected or discharged; power button not activated.	Ensure power bank is fully charged and securely connected. Press and hold the power button for 3 seconds to activate.
Uneven or localized heating	Damage to heating elements; improper fit of jacket.	Ensure the jacket fits snugly to allow heating elements to make proper contact. If issue persists, contact support.
Power bank not charging	Faulty charging cable or adapter; power bank issue.	Try a different charging cable and adapter. Ensure connections are secure. If still not charging, contact support.
Jacket turns off unexpectedly	Low battery on power bank; safety shutdown.	Recharge the power bank. If the jacket repeatedly shuts off with a charged battery, contact support.

Your browser does not support the video tag.

Video 7.1: This video provides a detailed troubleshooting guide and instructions for common issues.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	RTAX-018A
Brand	Wulcea
Material	100% Polyester (Outer Fabric), Polyester Fleece (Lining)
Battery Type	12V 18,400mAh Lithium-ion (included)
Heat Settings	High (131°F/55°C), Medium (113°F/45°C), Low (95°F/35°C)
Estimated Battery Life	3-4 hours (High), 5-6 hours (Medium), 8-10 hours (Low)
Care Instructions	Machine Wash, Hand Wash (remove battery)
Climate Suitability	Cold Weather
Features	Graphene heating, Fur Lined, Detachable Hood, Windproof, Waterproof

8.1 Garment Measurements

Please refer to the sizing chart below to ensure the correct fit. Measurements are approximate and may vary slightly.



Image 8.1: Detailed garment measurements by size.

9. WARRANTY AND SUPPORT

Wulcea products are manufactured with quality and customer satisfaction in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims. For product support, technical assistance, or warranty inquiries, please contact the seller or refer to the contact information provided with your purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DCF1HXSX>

More documents and user manuals: <https://manuals.plus/>