Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LuxenHōme WHIF1980

LuxenHome 35" Sideboard Buffet Cabinet with Sliding Doors

Model: WHIF1980

Brand: LuxenHōme

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your LuxenHome 35" Sideboard Buffet Cabinet. Please read all instructions carefully before assembly and use to ensure safe and proper functionality of the product. Keep this manual for future reference.

Safety Information

- Exercise caution when assembling, moving, or using the cabinet to avoid pinch points, injuries, or damage.
- Always use proper lifting techniques for heavy items. It is recommended that two adults assemble and move this cabinet.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload shelves. Distribute weight evenly.
- Attach the provided wall straps to prevent tipping, especially in households with children or pets.

Package Contents

Before beginning assembly, ensure all parts and hardware are present and undamaged. Refer to the included parts list in your package for specific component identification. If any parts are missing or damaged, please contact customer support.



Image: All components laid out for assembly.

Assembly Instructions

For a visual guide, please refer to the official assembly video below. Lay out all parts on a clean, flat, and soft surface to prevent scratches.

Your browser does not support the video tag.

Video: LuxenHome Aria 2-Door Cabinet Assembly Demonstration. This video provides a step-by-step visual guide for assembling the cabinet.

1. **Step 1: Prepare the Base**
   Insert quickfit screws into the designated holes on the bottom panel (Part 3).
2. **Step 2: Attach Side and Middle Panels**
   Insert wooden dowels into the bottom panel (Part 3). Insert cam locks into the side panels (Parts 1 & 5) and middle panel (Part 2). Carefully fit these panels onto the bottom panel, aligning the dowels and cam locks. Turn the cam locks clockwise to tighten.
3. **Step 3: Insert Back Panel**
   Slide the back panel (Part 9) into the grooves between the assembled side and middle panels.
4. **Step 4: Prepare Top Panel**
   Insert wooden dowels into the top edges of the side and middle panels (Parts 1, 2, and 5).
5. **Step 5: Attach Top Panel**
   Carefully place the top panel (Part 4) onto the assembled structure, aligning it with the dowels. Secure the top panel to the side and middle panels using screws.
6. **Step 6: Attach Legs**
   Fix the four legs (Part 8) to the underside of the top panel (Part 4) using the provided screws and Allen key.
7. **Step 7: Install Wall Straps and Secure Back Panel**
   Fix the wall straps (Part K) to the top panel (Part 3) using washers (Part L) and screws (Part J). Secure the backing panel (Part 9) by fixing wedges (Part H) using screws (Part I).
8. **Step 8: Install Shelves**
   Fit the shelf supports (Part N) into the desired positions within the assembled unit. Place the shelves (Part 6) on top of the shelf supports.
9. **Step 9: Attach Door Handles**
   Fix the handles (Part G) to the doors (Part 7) using washers (Part L) and screws (Part F).
10. **Step 10: Insert Sliding Doors**

Insert the doors (Part 7) into the grooves between the top and bottom panels from the back. Ensure they slide smoothly.

Product Features

- **Modern Sliding Door Design:** Features natural wood grain, rounded edges, and fluted-style sliding doors for a contemporary aesthetic.
- **Premium Material:** Constructed from sturdy engineered wood with a wood-look finish, offering durability and a warm, natural touch.
- **Adjustable Storage:** Includes adjustable and removable shelves to customize storage space according to your needs.
- **Compact Size:** Designed to provide practical storage without occupying excessive floor space.



Image: Detailed view of the cabinet's design elements.



Image: Interior features including sliding door and adjustable shelf.

Usage & Placement

This versatile cabinet can be utilized in various settings:

- **Living Room:** As an accent cabinet for decor or media storage.
- **Dining Room:** Functions as a sideboard or buffet for dinnerware and serving items.
- **Hallway/Entryway:** Provides a stylish console table for keys, mail, and other essentials.
- **Kitchen:** Ideal as a coffee station or additional storage for kitchen items.
- **Bedroom:** Can serve as a unique nightstand or additional storage.



Image: Cabinet in a living room setting.



Image: Cabinet in a dining room setting.



Image: Cabinet in an entryway setting.



Image: Cabinet in a bedroom setting.

Maintenance & Care

To maintain the appearance and longevity of your cabinet:

- Wipe with a damp cloth for regular cleaning.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Protect the surface from direct heat and moisture. Use coasters or mats for beverages and hot items.
- Periodically check all hardware connections and tighten if loose.

Specifications

Feature	Detail
Brand	LuxenHōme
Model Number	WHIF1980
Color	Light Brown
Material	Engineered Wood
Product Dimensions (D x W x H)	15.7"D x 35.4"W x 29.5"H
Item Weight	38 Pounds
Number of Doors	1 (sliding, covers two compartments)
Number of Shelves	2 (adjustable/removable)
Assembly Required	Yes

Product Dimensions



Image: Product Dimensions Diagram.

Troubleshooting

If you encounter any issues with your LuxenHome cabinet, please consider the following common solutions:

- **Wobbly Cabinet:** Ensure all screws and cam locks are fully tightened. Check that the cabinet is placed on a level surface. Adjust leg levelers if applicable.
- **Doors Not Sliding Smoothly:** Verify that the doors are correctly seated in their top and bottom grooves. Check for any obstructions in the tracks.
- **Missing Parts:** Refer to the package contents list. If parts are missing, contact customer support immediately.

For persistent issues, please contact LuxenHōme customer service.

Warranty & Support

LuxenHōme products are designed for quality and durability. For information regarding product warranty, returns, or additional support, please visit our official website or contact our customer service team.

Contact Information:

Email: customerservice@luxenhome.com

Phone: +1 909 548 8688

Website: www.luxenhome.com/help

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCF9CTX8

More documents and user manuals: **https://manuals.plus/**