

[Manuals.plus](#) /

› [YXYKODM](#) /

› XYKODM Mini Portable Bluetooth Speaker BS-101 User Manual

YXYKODM BS-101

YXYKODM Mini Portable Bluetooth Speaker BS-101 User Manual

Model: BS-101

INTRODUCTION

This manual provides detailed instructions for the XYKODM Mini Portable Bluetooth Speaker, Model BS-101. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its features. Keep this manual for future reference.

PRODUCT OVERVIEW

Package Contents

The package includes the following items:

- XYKODM Mini Portable Bluetooth Speaker (BS-101)
- Charging Cable
- Hand Cord
- Product Manual (this document)
- Color Box

Speaker Components

Familiarize yourself with the speaker's components:



Image: Detailed diagram of the YXYKODM Mini Portable Bluetooth Speaker, highlighting its various parts. These include the Power On/Off button (which also controls pause/play, answer/hang up, and remote selfie), an LED indicator light, a hanging rope hole, a built-in microphone for calls, the main speaker grille, and the charging port.

- **Power On/Off Button:** Located on the bottom. Controls power, play/pause, answer/end calls, and remote selfie function.
- **LED Indicator Light:** Provides status feedback (e.g., charging, paired, low battery).
- **Hanging Rope Hole:** For attaching the included hand cord for portability.
- **Built-in Microphone:** Enables hands-free calling.
- **Speaker:** Audio output.
- **Charging Port:** Micro USB port for charging the device.

Key Features

- **Compact and Portable Design:** Weighs approximately 1.76 ounces (50g) with dimensions of 1.26 inches (32mm) height and 1.339 inches (34mm) diameter.

- Bluetooth 5.0 Technology: Ensures stable and efficient wireless connection.
- HD Sound & Bass Boost: Delivers clear audio with enhanced bass.
- Loudness: Capable of up to 90 decibels (DB) at 12 meters from the source.
- Multi-function Button: Controls power, music playback, call management, and remote selfie.
- Hands-Free Calling: Integrated microphone for phone calls.
- DSP HD Intelligent Noise Reduction: Improves call clarity.
- TWS (True Wireless Stereo) Function: Allows pairing two speakers for stereo sound.
- IPX5 Waterproof Rating: Provides protection against splashes and light rain.
- Operating Range: Up to 12 meters (36 feet).
- Battery Life: Approximately 2-3 hours of playback on a single charge.

Our Unique Features



Image: An illustration highlighting the unique features of the speaker, including powerful sound, a simple one-click button for multiple functions, the ability to answer phone calls, a remote selfie shutter, and a Micro USB port for charging. It also shows the speaker wirelessly connected to a smartphone via Bluetooth.

Tiny as a Quarter



Can easily be placed in the pocket



No need to get big speakers for loudness



Image: A visual comparison illustrating the compact size of the YXYKODM Mini Portable Bluetooth Speaker, shown next to a US quarter coin. The image also depicts the speaker easily fitting into a pocket and contrasts it with a large, traditional speaker, emphasizing its portability and small footprint.

SETUP

Charging the Speaker

1. Locate the Micro USB charging port on the speaker (refer to the "Speaker Components" diagram).
2. Connect the provided charging cable to the speaker's charging port.
3. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. The LED indicator light will illuminate during charging. It will typically change color or turn off once fully charged.
5. A full charge provides approximately 2-3 hours of playback time.

Bluetooth Pairing

1. **Power On:** Press and hold the Power On/Off button on the speaker until you hear an audible prompt or the LED indicator light begins to flash, indicating it is in pairing mode.
2. **Activate Bluetooth:** On your smartphone, tablet, or computer, enable Bluetooth.
3. **Search for Devices:** In your device's Bluetooth settings, search for available devices.
4. **Select Speaker:** Select "BS-101" (or similar name) from the list of available devices.
5. **Confirm Pairing:** Once connected, you will hear an audible confirmation, and the LED indicator light will typically stop flashing and remain solid.

The speaker will automatically attempt to reconnect to the last paired device when powered on.



Image: The YXYKODM Mini Portable Bluetooth Speaker positioned on a car dashboard, wirelessly connected to a smartphone. This image highlights the convenience of Bluetooth 5.0 technology for hands-free calling and audio streaming in a vehicle environment.

TWS (True Wireless Stereo) Pairing (for two speakers)

To achieve stereo sound, you can pair two YXYKODM BS-101 speakers together:

1. Ensure both speakers are fully charged and powered off.
2. Power on both speakers simultaneously. Do not connect either speaker to your phone yet.
3. On one of the speakers, quickly press the Power On/Off button twice. This speaker will search for the other speaker.
4. The two speakers will automatically connect to each other, indicated by an audible prompt.
5. Once the speakers are paired with each other, connect your phone to one of the speakers via Bluetooth as described in the "Bluetooth Pairing" section. The audio will now play in stereo through both speakers.



Image: An illustration featuring two YXYKODM Mini Portable Bluetooth Speakers, each emitting sound waves, suggesting a 360-degree high-fidelity audio experience. One speaker is shown near a laptop and the other near a smartphone, indicating their versatile connectivity and potential for True Wireless Stereo (TWS) pairing.

Power On/Off

- **Power On:** Press and hold the Power On/Off button until the LED indicator lights up and you hear a power-on sound.
- **Power Off:** Press and hold the Power On/Off button until the LED indicator turns off and you hear a power-off sound.

Music Playback

- **Play/Pause:** While music is playing, press the Power On/Off button once to pause. Press it again to resume playback.

Hands-Free Calling

When connected to your phone via Bluetooth:

- **Answer Call:** When an incoming call rings, press the Power On/Off button once to answer the call.
- **End Call:** During a call, press the Power On/Off button once to end the call.
- **Reject Call:** Press and hold the Power On/Off button for approximately 2 seconds to reject an incoming call.



DSP HD intelligent noise reduction

Built-in noise-cancelling microphone, clear sound quality, at the same time can be one-click answer, so that the call distance

Image: A visual representation of the YXYKODM Mini Portable Bluetooth Speaker connected to a smartphone, emphasizing its DSP HD intelligent noise reduction feature and built-in microphone. This setup allows for clear, one-click hands-free calling, compatible with Android, Apple, and Windows devices.

Remote Selfie Function

When connected to your phone via Bluetooth:

- **Activate Camera:** Open your phone's camera application.
- **Take Photo:** Quickly double-press the Power On/Off button to trigger your phone's camera shutter and take a photo.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use harsh chemicals or abrasive cleaners.

- **Water Resistance:** The speaker has an IPX5 waterproof rating, meaning it is resistant to splashes and light rain. Do not submerge the speaker in water. Ensure the charging port cover (if present) is securely closed to maintain water resistance.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided charging cable.
Cannot pair with Bluetooth device.	Bluetooth is off on your device; speaker is not in pairing mode; speaker is already connected to another device; too far from speaker.	• Ensure Bluetooth is enabled on your device. • Make sure the speaker is in pairing mode (LED flashing). • Disconnect from any other paired devices. • Move your device closer to the speaker (within 12 meters). • Restart both the speaker and your Bluetooth device.
No sound or low sound.	Volume too low on speaker or connected device; speaker not properly paired; audio source issue.	• Increase volume on both the speaker and your connected device. • Ensure the speaker is successfully paired. • Check if the audio is playing correctly from your source device.
Short battery life.	Speaker not fully charged; high volume usage; aging battery.	• Ensure the speaker is fully charged before use. • Reduce volume for longer playback. • Battery performance may degrade over time.

Problem	Possible Cause	Solution
TWS pairing fails.	Incorrect pairing procedure; speakers too far apart.	- Follow the TWS pairing instructions carefully. - Ensure both speakers are close to each other during pairing. - Make sure neither speaker is already connected to a phone before TWS pairing.

SPECIFICATIONS

Feature	Detail
Model Name	BS-101
Brand	YXYKODM
Wireless Technology	Bluetooth 5.0
Speaker Type	Portable Bluetooth Speaker
Audio Output Mode	Mono (Stereo with TWS pairing)
Speaker Maximum Output Power	3 Watts
Frequency Response	20 Hz (minimum specified)
Bluetooth Range	Up to 12 meters (36 feet)
Power Source	Battery Powered
Battery Life	Approximately 2-3 hours
Control Method	Single Button (Touch)
Product Dimensions (H x Ø)	1.26 inches (32mm) H x 1.339 inches (34mm) Ø
Item Weight	1.76 ounces (approx. 50g)
Waterproof Rating	IPX5
Compatible Devices	Smartphone, Tablet, Laptop

Compact Size



Image: A technical diagram illustrating the compact dimensions of the YXYKODM Mini Portable Bluetooth Speaker. It shows a height of 1.26 inches (32mm), a diameter of 1.339 inches (34mm), and a weight of 1.2 ounces (34 grams).

WARRANTY AND SUPPORT

Warranty Information

This YXYKODM product comes with a Full Warranty. For specific terms and conditions, please refer to the warranty card included in your product packaging or contact customer support.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact YXYKODM customer support. Refer to the product packaging or the official YXYKODM website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question