

THURSO SURF Click Fin All-around Center Fin

THURSO SURF SUP Click Fin - All-Around Center Fin Instruction Manual

Model: Click Fin All-around Center Fin

1. INTRODUCTION

This manual provides essential instructions for the proper installation, use, and maintenance of your THURSO SURF SUP Click Fin. Designed for all-around paddleboarding, this center fin offers enhanced stability and maneuverability. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Tool-Free Installation:** Screwless US box fin design for quick and easy attachment.
- **Optimal Dimensions:** Base of 5.5 inches (14 cm) and depth of 5.1 inches (13 cm) for balanced stability and control.
- **Compatibility:** Designed to fit standard US fin boxes securely. *Note: Does not fit Quick Lock fin boxes.*
- **Versatile Performance:** Suitable for various water conditions and all-around paddleboarding.
- **Durable Construction:** Made from high-quality, fiberglass-reinforced nylon for long-lasting performance.

2.2 Components


The THURSO SURF SUP Click Fin package includes the following components:

- 1 x THURSO SURF SUP Click Fin (All-around Center Fin)
- Fin retention pin (integrated into the fin base)



Image 1: The THURSO SURF SUP Click Fin, showing its design and the integrated retention mechanism.

Fiberglass-Reinforced Nylon



STRONG AND FLEXIBLE

Image 2: Detail of the fin construction, highlighting the fiberglass-reinforced nylon material for strength and flexibility.

3. SETUP AND INSTALLATION

The THURSO SURF SUP Click Fin features a tool-free installation system designed for convenience. Follow these steps to properly install the fin into your paddleboard's US fin box:

1. **Prepare the Fin Box:** Ensure the fin box on your paddleboard is clean and free of sand or debris.
2. **Align the Fin:** Slide the front end of the fin base into the fin box channel.
3. **Secure the Fin:** Push the fin down firmly until the integrated retention pin clicks into place within the fin box. You should hear and feel a distinct click, indicating it is securely locked.
4. **Verify Installation:** Gently pull on the fin to ensure it is firmly seated and does not wobble.

Important Note: This fin is designed for standard US fin boxes. It is not compatible with Quick Lock fin boxes. Attempting to force it into an incompatible fin box may cause damage to the fin or the board.



Image 3: A person demonstrating the installation of a fin into a paddleboard's fin box.

4. OPERATING INSTRUCTIONS (USAGE)

Once installed, your THURSO SURF SUP Click Fin is ready for use. The fin provides directional stability and improved tracking for your paddleboard. For optimal performance:

- Ensure the fin is fully submerged in water during use.
- Avoid dragging the fin over shallow areas or obstacles to prevent damage.
- The fin's design is optimized for all-around paddleboarding, offering a balance of stability and maneuverability in various water conditions.



Image 4: A paddleboarder enjoying the water, demonstrating the fin in use for stability and tracking.

5. MAINTENANCE

Proper maintenance will extend the life of your THURSO SURF SUP Click Fin:

- **Rinse After Use:** After each use, especially in saltwater, rinse the fin and fin box with fresh water to remove salt, sand, and debris.
- **Inspect for Damage:** Regularly check the fin for any cracks, chips, or signs of wear. Inspect the retention pin for proper function.
- **Storage:** Store the fin in a cool, dry place away from direct sunlight when not in use. If removing the fin for storage, ensure it is clean and dry.
- **Cleaning:** Use mild soap and water for cleaning if necessary. Avoid harsh chemicals or abrasive materials.

6. TROUBLESHOOTING

Fin Not Clicking In Easily

- **Check for Obstructions:** Ensure the fin box channel and the fin base are free of sand, dirt, or other debris that might prevent a smooth insertion.
- **Apply Firm Pressure:** Sometimes, a new fin or a tight fin box may require a firm, steady push to engage the click mechanism. Ensure you are pushing straight down.
- **Lubrication (Optional):** A small amount of silicone-based lubricant can be applied to the fin base or fin box channel if repeated difficulty is encountered. Avoid petroleum-based lubricants.
- **Compatibility Check:** Double-check that your paddleboard has a standard US fin box. This fin is not compatible with Quick Lock fin boxes.

Fin Feels Loose After Installation

- **Verify Click:** Ensure the fin was pushed down completely until the retention pin audibly clicked into place.
- **Inspect Retention Pin:** Check the integrated retention pin on the fin for any damage or wear that might prevent it from securing properly.
- **Fin Box Condition:** Inspect the fin box on your paddleboard for any damage or excessive wear that might prevent a tight fit.

7. SPECIFICATIONS

Attribute	Detail
Model Name	Click Fin All-around Center Fin
Brand	THURSO SURF
Material	Plastic (Fiberglass-Reinforced Nylon)
Color	Black
Item Dimensions (LxWxH)	5.5 x 1 x 5.1 inches (14 x 2.5 x 13 cm)
Fin Base	5.5 inches (14 cm)
Fin Depth	5.1 inches (13 cm)
Item Weight	8 ounces (0.23 Kilograms)
Suggested Users	Unisex-adult
Included Components	All-around Center Fin

PRODUCT SPECIFICATIONS



Image 5: Diagram illustrating the base and depth dimensions of the THURSO SURF SUP Click Fin.

8. WARRANTY AND SUPPORT

Warranty: The THURSO SURF SUP Click Fin comes with a 30-day manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support: For warranty claims, technical assistance, or any questions regarding your THURSO SURF product, please contact THURSO SURF customer service. Refer to the official THURSO SURF website or your purchase documentation for current contact information.

You can also visit the [THURSO SURF Store on Amazon](#) for more product information and support resources.