

[manuals.plus](#) /

› [Philips](#) /

› [Philips Shaver Series 5000 Electric Shaver S5889/50 User Manual](#)

**Philips S5889/50**

# Philips Shaver Series 5000 Electric Shaver S5889/50 User Manual

Model: S5889/50

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your Philips Shaver Series 5000 Electric Shaver, Model S5889/50. Please read these instructions carefully before using the appliance and retain them for future reference.

### 1.1 Package Contents

Verify that all items are present in the package:

- Philips Shaver Series 5000 (Model S5889/50)
- Concealed Trimmer (integrated)
- Travel Case
- Quick Clean Pod
- Cleaning Cartridge (for Quick Clean Pod)
- USB-A Charging Cable (Power supply not included)
- Cleaning Brush



Figure 1: Philips Shaver Series 5000 and included accessories.

## 2. IMPORTANT SAFETY INFORMATION

### **WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:**

- This appliance is waterproof and suitable for use in a bath or shower. For safety reasons, the shaver can only be operated cordlessly.
- Do not use the appliance if it is damaged.
- Keep the appliance and USB-A charging cable away from heated surfaces.
- Do not use the appliance with a damaged charging cable.
- Do not immerse the charging cable in water or any other liquid.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Only use the appliance for its intended household use as described in this manual.

- Do not use attachments not recommended by Philips.
- Always check the shaving heads before use. If the shaving heads are damaged, do not use the appliance, as this may cause injury.

## 3. SETUP AND CHARGING

### 3.1 Charging the Shaver

Before first use, fully charge the shaver. A full charge provides approximately 60 minutes of cordless shaving time.

1. Ensure the shaver is dry before charging.
2. Connect the small end of the USB-A charging cable to the shaver's charging port.
3. Connect the large end of the USB-A charging cable to a compatible USB power adapter (not included).
4. The battery indicator lights on the shaver will illuminate to show the charging progress. When fully charged, all lights will be solid.
5. Disconnect the shaver from the power source once charging is complete.



Figure 2: Charging the shaver using the USB-A cable. Note: Power adapter is sold separately.


## 4. OPERATING THE SHAVER

### 4.1 Shaving Techniques

The Philips Shaver Series 5000 is designed for both wet and dry shaving. For best results, ensure your skin is clean.

- **Dry Shaving:** For a quick shave, use the shaver on dry skin.
- **Wet Shaving:** For a more comfortable shave, use with shaving foam or gel, or in the shower.

Hold the shaver at a right angle to your skin and move it in small, circular motions. Apply gentle pressure. The shaver's flexible 360-degree heads adapt to your facial contours for optimal skin contact.



Passt sich mit flexiblen  
**360-Grad-Scherköpfen**  
den Konturen Ihres  
Gesichts an

Figure 3: Flexible 360-degree shaving heads for optimal contour following.





Figure 4: Shaving with SkinIQ technology, which detects and adapts to facial contours.

#### 4.2 SkinIQ Technology and Power Adapt Sensor

The shaver features SkinIQ technology, which includes a Power Adapt sensor. This sensor reads your hair density 250 times per second and automatically adjusts the cutting power to ensure an efficient and comfortable shave, even on a 3-day beard.



Passt sich mit dem  
**Power Adapt Sensor**  
an die jeweilige  
Bartdichte an



Figure 5: Power Adapt Sensor adjusts cutting power based on beard density.

#### 4.3 Using the Concealed Trimmer

The shaver includes a concealed trimmer for precise grooming of sideburns and moustaches.

1. To activate the trimmer, slide the trimmer release button upwards.
2. Use the trimmer to shape and define edges.
3. After use, slide the trimmer release button downwards to retract the trimmer.

---

### 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and hygiene of your shaver.

#### 5.1 Quick Clean Pod

The Quick Clean Pod provides a thorough and convenient cleaning solution for your shaver.

1. Ensure the shaver is switched off.

2. Open the Quick Clean Pod and insert a cleaning cartridge.
3. Place the shaver head-down into the Quick Clean Pod.
4. Press the power button on the shaver to start the cleaning cycle.
5. The shaver will automatically clean and lubricate the shaving heads.
6. Once the cycle is complete, remove the shaver and allow it to air dry.

## 5.2 Manual Cleaning

For a quick clean, rinse the shaver head under running water.

1. Switch off the shaver.
2. Press the release button to open the shaving head unit.
3. Rinse the shaving head unit and the hair chamber under warm running water.
4. Shake off excess water and allow the shaver to air dry.
5. Close the shaving head unit.




Figure 6: Easy cleaning by opening the shaving head and rinsing under water.

## 5.3 Replacing Shaving Heads

For optimal shaving performance, replace the shaving heads approximately every 12 months. Replacement heads are available from Philips retailers.

1. Switch off the shaver and disconnect it from the power supply.
2. Open the shaving head unit.
3. Remove the retaining ring by turning it counter-clockwise.
4. Remove the old shaving heads.
5. Insert the new shaving heads into the unit.
6. Place the retaining ring back and turn it clockwise to secure.
7. Close the shaving head unit.

## 6. TROUBLESHOOTING

If you encounter issues with your shaver, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 30 minutes.
Poor shaving performance.	Shaving heads are dirty or worn.	Clean the shaving heads thoroughly or replace them if they are older than 12 months.
Shaver pulls hair.	Shaving heads are worn or shaver is not fully charged.	Ensure shaver is fully charged. Replace shaving heads if necessary.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure you are using gentle, circular motions. Consider wet shaving with foam/gel. Allow skin to adapt.

If the problem persists, contact Philips customer support.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	S5889/50
Power Source	Rechargeable Battery (Cordless operation)
Battery Type	Rechargeable
Shaving Time	Up to 60 minutes on a single charge
Blade Material	Stainless Steel (SteelPrecision blades)
Head Type	Rotary, 360-degree flexible heads

Feature	Detail
Special Features	SkinIQ Technology, Power Adapt Sensor, Wet & Dry use, Concealed Trimmer, Quick Clean Pod compatible
Item Weight	0.56 Kilograms
Color	Black

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

This Philips Shaver Series 5000 comes with a 2-year warranty. An additional 3 years of warranty can be obtained upon registration with Philips.com within 90 days of purchase. Please retain your proof of purchase for warranty claims.

### 8.2 Customer Support

For further assistance, product information, or to register your product, please visit the official Philips website or contact Philips customer support in your region.

Website: [www.philips.com](http://www.philips.com)

© 2024 Philips. All rights reserved.

### Related Documents - S5889/50

	<p><a href="#">Philips i9000 Prestige Ultra Shaver with SkinIQ Pro Technology</a></p> <p>Detailed overview of the Philips i9000 Prestige Ultra electric shaver, highlighting its SkinIQ Pro technology, Triple Lift &amp; Cut blades, 360° contouring head, and personalized shaving modes for ultimate comfort and performance.</p>
	<p><a href="#">Philips Shaver Series 5000 S5887/50: Advanced Wet &amp; Dry Shaving with SkinIQ Technology</a></p> <p>Discover the Philips Shaver Series 5000 S5887/50, featuring SkinIQ technology for an efficient and skin-friendly shave. Enjoy wet &amp; dry use, 60-minute battery life, and convenient USB-A charging.</p>



### [Philips Shaver Series 5000 S5887/10: Powerful Shaving with SkinIQ Technology](#)

Discover the Philips Shaver Series 5000 (S5887/10) for a powerful, skin-gentle shave. Featuring Steel Precision blades, SkinIQ technology, 360-D flexing heads, and 60 minutes of cordless use for a superior grooming experience.



### [Philips Shaver Series 9000 Prestige SP9883/35: Advanced Wet & Dry Electric Shaver with SkinIQ Technology](#)

Discover the Philips Shaver Series 9000 Prestige SP9883/35, an advanced wet and dry electric shaver featuring SkinIQ technology for a personalized, close, and gentle shave. Explore its features, specifications, and benefits for ultimate grooming.



### [i9000 Prestige Ultra SkinIQ Pro 7](#)

i9000 Prestige Ultra

### [SkinIQ Pro 7](#)

0.08mm 360° 7 UV



### [Philips Shaver Series 7000 S7887/63: Advanced Skin Protection with SkinIQ Technology](#)

Discover the Philips Shaver Series 7000 (S7887/63) for a close, comfortable shave. Featuring SkinIQ technology, Steel Precision blades, and 360-D flexible heads for advanced skin protection and personalized grooming.