



[Manuals.plus](#) /

› [Tecnock](#) /

› Tecnock S8915D Remote Control Stunt Car User Manual

Tecnock S8915D

Tecnock S8915D Remote Control Stunt Car User Manual

Model: S8915D | Brand: Tecnock

[Introduction](#) | [Safety Information](#) | [What's in the Box](#) | [Setup](#) | [Operating Instructions](#) | [Maintenance](#) | [Troubleshooting](#) | [Specifications](#) | [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Tecnock S8915D Remote Control Stunt Car. This 2.4GHz 4WD vehicle is designed for dynamic play, featuring double-sided driving, 360° rotations, and exciting flips. Its robust design and easy USB-C charging make it an ideal toy for children aged 6-12, providing hours of entertainment both indoors and outdoors.



Figure 1: Tecnock S8915D Remote Control Stunt Car (Purple variant shown).

2. SAFETY INFORMATION

Please read and understand all safety instructions before operating the product. Failure to follow these instructions may result in injury or damage to the product.

- **CHOKING HAZARD:** Small parts. Not suitable for children under 3 years.
- Adult supervision is recommended during operation.
- Do not operate the vehicle near people, pets, or obstacles to prevent accidents.
- Avoid operating in wet conditions or near water to prevent electrical damage.
- Do not modify or disassemble the product, as this may cause malfunction or injury.
- Use only the provided charging cable and recommended batteries.
- Ensure the vehicle is turned off when not in use or during charging.

3. WHAT'S IN THE BOX

The package includes the following components:

- Tecnock S8915D RC Stunt Car

- Remote Control
- USB-C Charging Cable
- Rechargeable Lithium-Ion Battery (pre-installed)
- Product Manual
- Screwdriver (for remote control battery compartment)




Figure 2: All items included in the TecnoCK S8915D package.

4. SETUP

4.1. Charging the RC Car

1. Locate the USB-C charging port on the side of the RC car.
2. Connect the provided USB-C charging cable to the car's port.
3. Plug the other end of the USB-C cable into a compatible USB power adapter (not included) or a USB port on a computer.
4. The LED indicator on the car will light up during charging and change color or turn off when fully charged. A full charge typically takes approximately 60 minutes.

• **Convenient and User-Friendly Charging Mode**



Figure 3: Connecting the USB-C charging cable to the RC car.

4.2. Installing Batteries in the Remote Control

1. Use the included screwdriver to open the battery compartment on the back of the remote control.
2. Insert 2 x AAA batteries (not included), ensuring correct polarity (+/-).
3. Close the battery compartment and secure it with the screw.

4.3. Powering On and Pairing

1. Ensure the RC car is fully charged.
2. Press and hold the power button on the RC car for approximately 3 seconds until the LED lights illuminate.
3. Press and hold the power button on the remote control for approximately 3 seconds until its LED indicator lights up.
4. The car and remote will automatically pair. The LED lights on both devices will stop blinking and remain solid once paired.

5. OPERATING INSTRUCTIONS

The Tecnock S8915D RC Stunt Car offers intuitive controls for various maneuvers.

5.1. Basic Controls

- **Forward/Backward:** Use the left joystick/button to move the car forward or backward.
- **Left/Right:** Use the right joystick/button to steer the car left or right.

5.2. Stunt Features

- **360° Rotations:** The car can perform continuous 360-degree spins. Experiment with joystick combinations to achieve this.
- **180° Flips & Double-Sided Driving:** The unique design allows the car to flip 180 degrees and continue driving on its other side, making it highly resilient to crashes and obstacles.
- **Agile Stunt Movements:** The independent wheel axles enable dynamic movements and quick changes in direction.



Figure 4: Demonstrating 360° rotation and double-sided flip capabilities.

5.3. Advanced Features

- **2.4GHz Anti-Interference:** The advanced 2.4GHz remote control technology allows multiple cars to operate simultaneously without signal interference, perfect for multiplayer racing.
- **All-Terrain Support:** Designed with durable wheels, the car can navigate various surfaces including carpet, stone roads, asphalt, and lawns.

- **LED Breathing Lights:** The car features eye-catching LED lights that simulate twinkling stars, enhancing visibility and fun during nighttime play.



Figure 5: The RC car is capable of operating on various terrains.



Figure 6: Multiple Tecnock RC cars can be operated simultaneously without interference.

Your browser does not support the video tag.

Video 1: Official product video showcasing the Tecnock Remote Control Stunt Car's features and stunts.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the car after use. Avoid water or harsh chemicals.
- **Battery Care:**
 - Always fully charge the car's battery before first use.
 - Do not overcharge the battery. Disconnect once fully charged.
 - Remove batteries from the remote control if not used for extended periods to prevent leakage.
 - Store the car and remote in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Car does not turn on.	Ensure the car's battery is charged. Press and hold the power button for 3 seconds.
Remote control does not work.	Check if AAA batteries are correctly installed and have sufficient power. Press and hold the power button for 3 seconds.
Car and remote are not pairing.	Ensure both devices are powered on and within range. Turn both off and on again to re-attempt pairing.
Poor control range or interference.	Ensure no other 2.4GHz devices are causing interference. Move to an open area.
Car is slow or unresponsive.	The car's battery may be low. Recharge the car.

8. SPECIFICATIONS

Feature	Detail
Brand	Tecnock
Model Name	S8915D
Model Number	1801U
Control Frequency	2.4GHz
Drive Type	4WD (Four-Wheel Drive)
Stunt Capabilities	360° Rotations, 180° Flips, Double-Sided Driving
Car Battery	Rechargeable Lithium-Ion (included)
Charging Port	USB-C
Remote Control Batteries	2 x AAA (not included)
Material Type	Plastic
Item Dimensions (L x W x H)	5.75 x 5.12 x 2.28 inches
Item Weight	8.8 ounces
Recommended Age	6-12 years

9. WARRANTY & SUPPORT

Tecnock products are designed for durability and performance. For specific warranty details, please refer to the product packaging or contact Tecnock customer support.

If you encounter any issues or have questions regarding your Tecnock S8915D Remote Control Stunt Car, please visit the official Tecnock store on Amazon or contact their customer service for assistance. You can find more information at: [Tecnock Store](#)

