Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VINGLI VIN-G57000706

VINGLI 2 Person Outdoor Patio Swing Set Instruction Manual

Model: VIN-G57000706

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your VINGLI 2 Person Outdoor Patio Swing Set. Please read all instructions carefully before assembly and use. Retain this manual for future reference.

Image: The VINGLI 2 Person Outdoor Patio Swing Set, featuring a black steel frame, black cushions, and an adjustable black canopy.

Safety Information

Observe the following safety guidelines to prevent injury or damage to the product:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 550 lbs (approximately 250 kg). This swing is designed for two adults.
- **Assembly:** Ensure all bolts, nuts, and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Placement:** Place the swing on a flat, stable surface. Avoid uneven ground or slopes.
- **Weather Conditions:** While designed for outdoor use, extreme weather conditions (strong winds, heavy rain, snow) may require the canopy to be lowered or removed, and the swing to be secured or stored indoors.
- **Children:** Supervise children when they are near or using the swing.

- **Modifications:** Do not modify the product in any way. Unauthorized modifications may compromise safety and void any potential warranty.

Package Contents

Before beginning assembly, verify that all components are present and undamaged. Refer to the parts list provided in your product packaging. If any parts are missing or damaged, contact VINGLI customer support.

Assembly Instructions

Assembly typically requires two persons and can be completed in approximately 20 to 30 minutes. Follow the step-by-step diagrams and instructions included in your product packaging for detailed guidance.

1. **Frame Assembly:** Begin by assembling the main steel frame components. Ensure all connections are aligned correctly before tightening bolts.
2. **Swing Seat Attachment:** Attach the swing seat to the main frame using the provided hanging mechanisms (e.g., springs, chains).
3. **Canopy Installation:** Secure the canopy frame to the top of the main frame. Attach the canopy fabric, ensuring it is taut and properly aligned.
4. **Cushion Placement:** Place the seat and backrest cushions onto the swing. The cushions feature a sleeve design and front edge ropes to attach them securely to the frame.
5. **Final Check:** Double-check all connections for tightness and stability. Ensure the swing moves freely and safely.



Image: Close-up views illustrating key assembly and design details: extra tape designs for canopy tightening, end caps protecting feet and ground, front edge rope for cushion attachment, and sleeve design for secure cushion fit.

Operating Instructions

- **Using the Swing:** Sit gently on the swing seat. The swing is designed for a smooth, gentle motion. Avoid excessive force or standing on the swing.
- **Adjusting the Canopy:** The canopy is fully adjustable and can be tilted to provide optimal shade. Loosen the adjustment knobs on the canopy frame, position the canopy to your desired angle, and then re-tighten the knobs to secure it.
- **Cushion Comfort:** The thick, cushioned seats and backrests provide comfort. Ensure cushions are properly attached using the integrated sleeve design and front ropes to prevent shifting during use.

Image: A close-up of the rotatable canopy adjustment mechanism, showing how to loosen and tighten the knob to change the canopy's angle for sun protection.

Image: A woman seated on the VINGLI patio swing, demonstrating the comfort provided by the 2-inch thick cushions and breathable materials.

Maintenance

- **Cleaning the Frame:** Wipe the steel frame with a damp cloth and mild soap. Rinse thoroughly and dry to prevent rust. Avoid abrasive cleaners.
- **Cleaning Cushions:** The cushions are removable for easy cleaning. Spot clean with a mild detergent and water. Allow to air dry completely before reattaching. Do not machine wash or tumble dry unless specified on the cushion care label.
- **Canopy Care:** Clean the canopy fabric with a soft brush and mild soap solution. Rinse and allow to air dry.
- **Seasonal Storage:** During off-season or prolonged periods of non-use, it is recommended to store the swing indoors or cover it with a protective outdoor furniture cover to extend its lifespan.
- **Hardware Check:** Periodically inspect all bolts, nuts, and connections for tightness. Re-tighten as needed to maintain structural integrity.

Troubleshooting

- **Swing feels unstable:** Ensure the swing is placed on a completely flat and level surface. Check all frame connections and tighten any loose bolts.
- **Canopy does not stay in position:** Verify that the adjustment knobs on the canopy frame are fully tightened after positioning the canopy.
- **Cushions slide off:** Ensure the cushion sleeve design is properly engaged with the frame and the front edge ropes are securely tied.
- **Squeaking noise:** Apply a small amount of silicone-based lubricant to the spring connections or any moving metal parts if squeaking occurs.

Specifications

Feature	Detail
Brand	VINGLI
Model Number	VIN-G57000706
Color	Black
Product Dimensions (D x W x H)	41.7" x 67.7" x 60"
Frame Material	Metal (Steel)
Finish Type	Unfinished
Seat Depth	17 inches
Item Weight	34.1 pounds
Weight Capacity	550 lbs
Assembly Required	Yes

Image: A detailed diagram illustrating the dimensions of the VINGLI patio swing (67.7" W x 41.7" D x 60" H) and its maximum weight capacity of 550 lbs.

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact VINGLI customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 VINGLI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCFZZGJG

More documents and user manuals: **https://manuals.plus/**