

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SEMKY](#) /

› [SEMKY City Series Farm House Building Blocks Set with LED Lights Instruction Manual](#)

SEMKY B0DCG3M9P7

SEMKY City Series Farm House Building Blocks Set with LED Lights

Model: B0DCG3M9P7

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SEMKY City Series Farm House Building Blocks Set with LED Lights. Please read all instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience.

Safety Information: This product contains small parts and is recommended for ages 8 and up. Adult supervision is required to reduce the risk of injuries.

2. PACKAGE CONTENTS

Verify that all components are present before starting assembly. The package should contain:

- 610 Building Blocks (sorted and packaged by number bag)
- LED Light Kit
- Instruction Manual (this document)
- Brick Separator (included for convenience)

If any pieces are missing, please refer to the 'Warranty and Support' section for assistance.

3. SETUP AND ASSEMBLY

Follow the step-by-step instructions provided in the included printed instruction manual. The blocks are organized into numbered bags corresponding to the assembly stages.

1. **Unpack Components:** Carefully open the packaging and lay out the numbered bags of blocks. Do not open all bags at once to avoid mixing pieces.
2. **Follow Manual:** Refer to the detailed illustrations in the printed instruction manual. Parts for each step are highlighted in color, while completed sections are shown in grayscale.
3. **LED Light Installation:** The LED light kit is integrated during specific assembly steps. Ensure proper placement and connection as indicated in the manual. It is recommended to test the lighting assembly before fully integrating it into the model.
4. **Secure Connections:** Press blocks firmly together to ensure secure connections. Use the included brick separator if needed to disassemble incorrectly placed blocks.



Image 1: Fully assembled SEMKY Farm House Building Blocks Set, showcasing the detailed design and various elements.



Image 2: Comparison of the farm house model in daylight and illuminated by its integrated LED lights at night.

4. OPERATING INSTRUCTIONS

Once assembled, your Farm House model offers interactive features:

- **LED Lights:** Activate the LED lights to illuminate the farm house, creating a realistic night scene. Follow the specific instructions in the assembly manual for power connection and activation.
- **Interchangeable Plants:** The set includes various interchangeable plant pieces (e.g., corn, carrots, grapes) to customize your farm landscape. Easily swap them to simulate different seasons or crops.
- **Movable Elements:** The orange tractor and trailer can be moved around the farm scene. The roof of the house can be lifted on one side for interior access, and the back of the house is open for viewing

internal details.

- **Animal Pen:** The sheep pen can be opened to 'release' the miniature sheep figures.

Your browser does not support the video tag.

Video 1: An overview of the SEMKY Farm House Set, demonstrating its features and assembled appearance.



Image 3: Detailed view of the farm area, showing interchangeable crops like corn and carrots, along with a white picket fence and miniature animals.



Image 4: Close-up of the farm house entrance with a red mailbox and a view into the sheep pen, highlighting rich internal details.

5. MAINTENANCE

To ensure the longevity of your building block set:

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the blocks. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the assembled model or disassembled blocks in a cool, dry place away from direct sunlight to prevent discoloration or warping.
- **Handling:** Handle the model with care, especially when moving it, to prevent pieces from detaching.

6. TROUBLESHOOTING

- **Missing Pieces:** If you discover any missing pieces during assembly, please contact SEMKY customer support as detailed in the 'Warranty and Support' section.
- **LED Lights Not Working:** Double-check all connections of the LED light kit. Ensure batteries (if applicable, not specified in product data) are correctly inserted and functional.
- **Blocks Not Snapping Together:** Ensure you are using the correct blocks for each step. Apply firm, even pressure. If a block is particularly difficult, try rotating it or checking for any obstructions.

7. SPECIFICATIONS

Feature	Detail
Model Number	B0DCG3M9P7
Number of Pieces	610
Product Dimensions (L x W x H)	8.8 x 4.4 x 5.5 inches
Item Weight	1.43 pounds
Recommended Age	8 years and up
Special Features	Integrated LED Lights, Interchangeable Plant Elements



Image 5: Visual representation of the assembled farm house model's dimensions (8.8 x 4.4 x 5.5 inches).

8. WARRANTY AND SUPPORT

SEMKY is committed to providing high-quality products. All pieces in SEMKY products are sorted and packaged by machine with strict inspections. In the event that your set is still missing pieces, please contact our customer support for assistance.

Missing Parts: If you find any missing parts, please contact SEMKY customer service directly. We will send the missing parts to you free of charge.

For further support or inquiries, please visit the official SEMKY store or contact the seller through your purchase platform.

