

[Manuals.plus](#) /

- › [Signature Design by Ashley](#) /
- › Signature Design by Ashley Modmax Swivel Glider Rocker Recliner User Manual

Signature Design by Ashley 9210261

Signature Design by Ashley Modmax Swivel Glider Rocker Recliner User Manual

Model: 9210261

Brand: Signature Design by Ashley

INTRODUCTION

Thank you for choosing the Signature Design by Ashley Modmax Swivel Glider Rocker Recliner. This manual provides essential information for the safe and effective use, assembly, and maintenance of your new furniture. Designed for comfort and versatility, this recliner features a smooth reclining motion, 360-degree swivel, and convenient hidden storage compartments. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: The Modmax Swivel Glider Rocker Recliner in Burnt Orange, showcasing its contemporary design.

IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product.

- **Keep a safe distance from the chair when the reclining or swivel mechanism is in motion.** Ensure no obstructions are present around the chair during operation.
- **Do not use outdoors.** This recliner is designed for indoor use only. Exposure to outdoor elements can damage the fabric and internal mechanisms.
- Avoid placing heavy objects on the footrest when it is extended.
- Do not allow children to play on or around the recliner unsupervised, especially when operating the reclining mechanism.
- Ensure the recliner is placed on a stable, level surface to prevent tipping.

SETUP AND ASSEMBLY

The Signature Design by Ashley Modmax Swivel Glider Rocker Recliner requires minimal assembly. It typically arrives in two main pieces: the base and the backrest, along with two bolster pillows.

1. **Unpack Components:** Carefully remove all components from the packaging. Inspect for any damage during transit.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding receivers on the base of the recliner. Slide the backrest firmly down until it clicks securely into place. No tools are typically required for this step.
3. **Position Bolster Pillows:** Place the two bolster pillows on the armrests as desired. These pillows are removable.
4. **Placement:** Position the assembled recliner in your desired indoor location, ensuring adequate space for reclining and swiveling.

Note: While assembly is simple, the recliner is heavy (approximately 128 pounds). It is recommended to have two people for unpacking and positioning the chair to prevent injury.



Figure 2: The recliner positioned in a room, demonstrating its size and aesthetic integration.

OPERATING INSTRUCTIONS

Your Modmax recliner offers multiple comfort functions for a relaxing experience.

Reclining Function

- **To Recline:** Locate the press-back handle on the side of the recliner (typically on the right side when seated). Pull the handle to release the footrest. Lean back gently to recline the backrest to your desired position. The recliner offers two reclining positions.
- **To Return Upright:** Push down on the footrest with your legs until it locks into place. Lean forward to bring the backrest to its upright position.



Figure 3: The recliner with its footrest extended, demonstrating the reclining function.

Swivel Function

The recliner is equipped with a 360-degree swivel base, allowing you to rotate freely. Simply apply gentle pressure with your feet to turn the chair in any direction.

Glider/Rocker Function

The chair also functions as a glider and rocker, providing a smooth, soothing motion. This feature operates automatically when the chair is in its upright position.

Hidden Storage Compartments

Convenient hidden storage compartments are located beneath the loose bolster pillows on the armrests.

- **To Access Storage:** Simply lift the bolster pillow on either armrest to reveal the compartment underneath.
- These compartments are ideal for storing small items such as remote controls, books, or snacks.



Figure 4: The recliner with one of its hidden storage compartments open, showing space for small items.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your recliner.

Fabric Care (Next-Gen Nuvella Polyester)

- **Spot Clean Only:** For spills and stains, immediately blot the affected area with a clean, dry cloth. Do not rub.
- For stubborn stains, use a mild soap solution and a clean, damp cloth. Test on an inconspicuous area first.
- Allow the fabric to air dry completely. Do not use harsh chemicals or abrasive cleaners.
- The cover is machine washable. Refer to the care tag on the cover for specific washing instructions.




Figure 5: A close-up view of the Next-Gen Nuvela polyester fabric, highlighting its texture and durability.

General Maintenance

- Regularly vacuum the recliner using a soft brush attachment to remove dust and debris.
- Check all connections and mechanisms periodically to ensure they are secure. Tighten any loose screws if necessary.
- Avoid exposing the recliner to direct sunlight or extreme temperatures, as this can cause fading or damage to the fabric and frame.

TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Recliner not reclining smoothly.	Mechanism obstruction or loose connection.	Check for any objects obstructing the mechanism. Ensure the backrest is fully engaged with the base.
Footrest wobbles or does not stay extended.	Loose hardware or mechanism issue.	Inspect the footrest mechanism for loose bolts and tighten if necessary. If the issue persists, contact customer support.
Chair does not swivel easily.	Obstruction under the base or uneven surface.	Ensure no debris is caught under the swivel base. Verify the chair is on a flat, level surface.
Fabric stain.	Spill or dirt.	Spot clean immediately with a mild soap solution and damp cloth. Refer to Maintenance section.

SPECIFICATIONS

Detailed specifications for the Signature Design by Ashley Modmax Swivel Glider Rocker Recliner.

Brand: Signature Design by Ashley

Model Name: Modmax Swivel Glider Recliner

Model Number: 9210261

Color: Burnt Orange (as per current product variant)

Product Dimensions (D x W x H): 40.25"D x 41.38"W x 39.75"H

Fully Reclined Length: 58.5"

Item Weight: 128 pounds

Material: Next-Gen Nuvela (Polyester) fabric, Foam fill

Special Features: Reclining, Arm Rest, Foot Rest, Removable Cover, Swivel, Glider, Rocker, Hidden Storage Compartments

Product Care Instructions: Spot Clean (Machine washable cover)

Assembly Required: Yes (Minimal)

Indoor/Outdoor Usage: Indoor

UPC: 024052879643

Country of Origin: Vietnam

WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official Signature Design by Ashley website.

If you require further assistance, have questions about assembly, operation, or need to report a defect, please contact Signature Design by Ashley customer support.

Manufacturer: Ashley Furniture Industries

Customer Support: Please visit the [Signature Design by Ashley Store on Amazon](#) or their official website for contact information.

© 2025 Signature Design by Ashley. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.