

## Beyution NK12

# Beyution NK12 Replacement Remote Control User Manual

MODEL: NK12

## 1. Product Overview

This manual provides instructions for the Beyution NK12 Replacement Remote Control, designed to function as a direct replacement for the original remote of the Nakamichi NK12 400W 38" Surround Sound Soundbar. This remote control requires no programming or pairing for immediate use.





Figure 1: Front view of the Beyution NK12 Replacement Remote Control, showing all buttons.

**Key Features:**

- **Direct Replacement:** Functions immediately without programming or pairing.
- **Extended Range:** Operates effectively up to 10 meters (approximately 33 feet) with stable performance.
- **Durable Construction:** Made from ABS plastic and soft rubber, with printing designed for long-term use.
- **Ergonomic Design:** Lightweight and comfortable to hold.



Figure 2: Comparison of the replacement remote control (left) and the original remote control (right).

## 2. Setup and Battery Installation

The Beyution NK12 Replacement Remote Control operates using AAA batteries. No complex setup or programming is required; simply insert the batteries, and the remote is ready for use.

1. **Open Battery Compartment:** Locate the battery cover on the back of the remote control. Gently slide or press the latch to open the cover.
2. **Insert Batteries:** Insert two (2) AAA 1.5V batteries into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries match the polarity indicators inside the compartment.
3. **Close Battery Compartment:** Replace the battery cover, ensuring it clicks securely into place.



**Figure 3:** Rear view of the remote control with the battery cover removed, illustrating battery insertion.

The remote control is now ready for immediate use with your Nakamichi NK12 Soundbar.

### 3. Operating Instructions

This remote control provides full functionality for your Nakamichi NK12 400W 38" Surround Sound Soundbar. Point the remote control directly towards the soundbar's infrared receiver for optimal performance.



Figure 4: Example of remote control usage with a home entertainment system.

#### Button Functions:

Button	Function
Power (Red Circle)	Turns the soundbar On or Off.
LED DIM	Adjusts the brightness of the soundbar's LED display.
TV-HDMI	Selects HDMI input source.
AUX	Selects Auxiliary input source.

Button	Function
<b>LINE IN</b>	Selects Line In input source.
<b>OPT</b>	Selects Optical input source.
<b>BT (Bluetooth)</b>	Selects Bluetooth input source.
<b>PAIR</b>	Initiates Bluetooth pairing mode.
<b>SLEEP</b>	Activates or deactivates sleep timer function.
<b>MUTE</b>	Mutes or unmutes the sound.
<b>VOL- / VOL+</b>	Decreases / Increases volume level.
<b>Previous / Play/Pause / Next</b>	Controls media playback (e.g., skip tracks, play/pause).
<b>MOVIE</b>	Activates Movie sound mode.
<b>NEWS</b>	Activates News sound mode.
<b>MUSIC</b>	Activates Music sound mode.
<b>SPORTS</b>	Activates Sports sound mode.

## 4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the remote control. Avoid using liquid cleaners or abrasive materials, as these can damage the finish or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries simultaneously with new ones of the same type (AAA 1.5V). Do not mix old and new batteries or different battery types.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

## 5. Troubleshooting

If you encounter issues with your Beyution NK12 Replacement Remote Control, refer to the following troubleshooting steps:

### 1. Remote Not Responding:

- Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
- Replace old batteries with new AAA 1.5V batteries.
- Ensure there are no obstructions between the remote control and the soundbar's infrared receiver.
- Verify that the remote is pointed directly at the soundbar.

### 2. Limited Range:

- Ensure batteries are fresh. Weak batteries can reduce the operating range.
- Minimize interference from other electronic devices or bright light sources.

### 3. Specific Button Not Working:

- Gently press the button multiple times to ensure it is not stuck.
- If the issue persists after checking batteries, the remote may be faulty.

If these steps do not resolve the issue, please contact customer support for further assistance.

## 6. Product Specifications

Feature	Detail
Model Number	NK12
Compatibility	Nakamichi NK12 400W 38" Surround Sound Soundbar
Connectivity Technology	Infrared (IR)
Maximum Control Distance	10 meters (approx. 33 feet)
Material	ABS Plastic, Soft Rubber
Power Source	2 x AAA 1.5V Batteries (not included)
Product Dimensions	7 x 1.5 x 0.5 inches (17.8 x 3.8 x 1.3 cm)
Item Weight	1.9 ounces (54 grams)
Color	Black

## 7. Warranty and Support

Beyution provides customer support for its products. If you receive a damaged or non-functional remote control, or if your specific device model is not listed as compatible, please contact us directly for assistance.

For any inquiries or support needs, please refer to the contact information provided with your purchase or on the Beyution official website. We are committed to providing a satisfactory solution.