

[Manuals.plus](#) /

- › [Signature Design by Ashley](#) /
- › Signature Design by Ashley Mercomatic Power Reclining Sofa User Manual

Signature Design by Ashley Mercomatic

Signature Design by Ashley Mercomatic Power Reclining Sofa User Manual

Model: Mercomatic

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Signature Design by Ashley Mercomatic Power Reclining Sofa. This power reclining sofa features one-touch reclining, adjustable headrests, and integrated USB ports, designed for comfort and modern convenience. Please read these instructions thoroughly before assembly and operation.



Image: The Mercomatic Power Reclining Sofa in blue, showcasing its contemporary design.

SAFETY INFORMATION

Important Safety Warnings:

- All foam and upholstered surfaces meet flammability standards.
- Keep the sofa away from open flames or high heat sources to prevent fire hazards.
- Supervise children and pets to avoid entrapment risks, especially during reclining operations. Ensure no body parts or objects are in the path of moving mechanisms.
- Do not allow children to play on or operate the reclining mechanism.
- Ensure the power cord is not pinched or damaged.

SETUP AND ASSEMBLY

Your Mercomatic Power Reclining Sofa requires assembly. Please follow the included instructions and ensure all hardware is present before beginning.

Unpacking and Preparation

- Carefully remove all components from the packaging. Retain packaging materials until assembly is complete to ensure no parts are discarded.
- Verify all parts are present against the parts list provided in the separate assembly guide.
- Ensure you have adequate space for assembly. The sofa dimensions are 85.25" W x 39.75" D x 42" H. A minimum door width of 85.25 inches is required for entry.

Assembly Steps

1. **Positioning:** Place the sofa components in the desired location. Note that this is a wall-hugger design, requiring minimal space (approximately 7.75 inches) between the wall and the chair back when reclining.
2. **Connecting Sections:** Connect the sofa sections as per the detailed assembly instructions.
3. **Attaching Legs:** Securely attach the exposed feet with faux wood finish to the base of the sofa.
4. **Power Connection:** Connect the power cord to the sofa's power input and then to a suitable wall outlet. Ensure the cord is not obstructed or damaged.

Tools Required: A wrench is recommended for assembly. All necessary assembly tools are included.

Recommended for Assembly: 2 people.



Image: Detailed diagram showing the dimensions of the Mercomatic Power Reclining Sofa.

OPERATING INSTRUCTIONS

Your Mercomatic Power Reclining Sofa offers convenient power features for enhanced comfort.

Power Reclining Function

- Locate the one-touch power control buttons on the inner side of the armrest.
- Press and hold the appropriate button to recline the seat or return it to the upright position. The mechanism allows for infinite reclining positions.
- Release the button at your desired recline angle.

Adjustable Headrest

- The headrest can be adjusted independently using the controls on the armrest.
- Press and hold the headrest adjustment button to move the headrest to your preferred angle for optimal viewing comfort.
- Release the button to lock the headrest in place.

USB Charging Ports

- The sofa is equipped with USB-C fast charging and zero-draw USB ports located on the armrest.
- Simply plug your compatible USB cable directly into the port to charge your devices.
- The zero-draw feature ensures power is only consumed when a device is actively charging, conserving energy.



Image: Close-up view of the power control buttons and USB charging port integrated into the sofa's armrest.



Image: Illustration detailing the USB-A and USB-C charging options available on the sofa.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your sofa.

- **Cleaning:** For general cleaning, spot clean with a damp cloth. The upholstery cleaning code is 'W', indicating that water-based cleaning agents can be used. Test any cleaning solution on an inconspicuous area first.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Dusting:** Regularly dust the sofa with a soft, dry cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading and damage to the upholstery.

- **Mechanism Care:** Periodically check all bolts and connections to ensure they are tight. Do not lubricate the reclining mechanism unless specifically instructed by the manufacturer.

TROUBLESHOOTING

If you encounter issues with your sofa, refer to the following common troubleshooting tips:

- **Sofa Not Reclining:**

- Ensure the power cord is securely plugged into both the sofa and a working wall outlet.
- Check if the wall outlet is receiving power by plugging in another device.
- Inspect the power cord for any visible damage.

- **USB Ports Not Charging:**

- Verify the sofa is powered on and the power cord is connected.
- Try a different USB cable or device to rule out issues with your charging accessories.

- **Unusual Noises During Operation:**

- Ensure no objects are obstructing the reclining mechanism.
- Check for any loose hardware and tighten if necessary.

If these steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Signature Design by Ashley
Model Name	Mercomatic
Product Dimensions (D x W x H)	39.75"D x 85.25"W x 42"H
Item Weight	269 Pounds
Color	Blue
Upholstery Fabric Type	Faux Leather, Leather
Special Features	Adjustable Headrest, Armrest, Position Lock, Recliner, USB Charging Ports
Assembly Required	Yes
Recommended People for Assembly	2
Tools Recommended For Assembly	Wrench (included)
Minimum Required Door Width	85.25 Inches
Furniture Wall Clearance	7.75 Inches
Seating Capacity	3
Reclining Seat Count	2
Reclining Position Count	Infinite Position

Frame Material Type	Metal
Product Care Instructions	Spot Clean with Damp Cloth
Upholstery Cleaning Code	W
UPC	024052882919
ASIN	B0DCGDQY7C

WARRANTY INFORMATION

This Signature Design by Ashley Mercomatic Power Reclining Sofa comes with a **Limited Warranty**. For specific details regarding coverage, duration, and terms, please refer to the warranty documentation included with your purchase or contact Signature Design by Ashley customer service.

CUSTOMER SUPPORT

For further assistance, parts replacement, or to report any issues not covered in this manual, please contact Signature Design by Ashley customer support.

You can also visit the official [Signature Design by Ashley Store](#) for more product information and support resources.