#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- mompush /
- Mompush Baby Stroller Instruction Manual

# mompush P711

# **Mompush Baby Stroller Instruction Manual**

Model: P711 Brand: Mompush

# 1. Introduction

This manual provides essential information for the safe and proper use, assembly, maintenance, and troubleshooting of your Mompush Baby Stroller. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1.1: The Mompush Baby Stroller in Grey, showcasing its sleek design and robust frame.

# 2. SAFETY INFORMATION

Always prioritize the safety of your child. Failure to follow these instructions could result in serious injury or death.

- Never leave your child unattended in the stroller.
- Ensure all locking devices are engaged before use.
- Do not overload the storage basket or hang bags on the handle, as this can cause the stroller to tip.
- Always use the harness system to secure your child.
- Ensure that children are clear of any moving parts if you adjust the stroller.
- This stroller is designed for children from birth up to 50 pounds.

### 3. SETUP AND ASSEMBLY

# 3.1. Unpacking and Components

Carefully remove all components from the packaging. Verify that all parts listed below are present.

#### **Included Components:**

- Stroller Frame
- Seat Unit (Convertible to Bassinet)
- Cup Holder
- Foot Cover
- Rain Cover
- Car Seat Adapter

### 3.2. Frame Assembly

- 1. Unfold the stroller frame by releasing the folding latch. Ensure the frame locks securely into place.
- 2. Attach the wheels by pushing them onto the axles until they click. Pull on the wheels to ensure they are securely attached.

#### 3.3. Seat Unit Installation

The seat unit is reversible and can be installed to face the parent or face the world.

- 1. Align the seat unit connectors with the corresponding slots on the stroller frame.
- 2. Push down firmly until you hear a click, indicating the seat is securely locked.
- 3. To reverse the seat, press the release buttons on both sides of the seat unit, lift, rotate, and re-attach.

# One handed recline



Figure 3.1: The Mompush Stroller offers four versatile modes: travel system (car seat not included), newborn bassinet mode, parent-facing seat, and world-facing seat, adapting to your child's growth.

### 3.4. Car Seat Adapter Installation

The included car seat adapter allows compatibility with various infant car seats (car seat not included).

- 1. Remove the seat unit from the stroller frame.
- 2. Attach the car seat adapters to the designated slots on the stroller frame until they click into place.
- 3. Carefully place your infant car seat onto the adapters, ensuring it locks securely. Always check for a firm connection before use.

## 4. OPERATING INSTRUCTIONS

### 4.1. Adjusting the Seat Recline

The seat offers multiple recline positions for customized comfort, from upright to a flat bassinet mode for newborns.

- To recline the seat, locate the recline mechanism (often a lever or strap) at the back of the seat.
- Press the lever or pull the strap while gently pushing the seat back to the desired position.
- To bring the seat upright, pull the strap or lift the lever while pulling the seat forward.



Figure 4.1: The stroller features a one-handed recline mechanism, allowing for easy adjustment of the seat to multiple positions for your child's comfort.

### 4.2. Harness System

The 5-point harness system ensures your child's safety.

- 1. Place your child in the seat.
- 2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
- 3. Insert the buckle tongues into the buckle housing until they click.
- 4. Adjust the straps to ensure a snug fit, leaving no more than one finger's width between the strap and your child.

### 4.3. Canopy Adjustment

The UPF 50+ canopy provides maximum sun protection and features ventilation panels.

- Extend the canopy by pulling it forward.
- The canopy can be zipped open to reveal additional mesh panels for improved airflow and natural light.

# Stretch the shade



Figure 4.2: The stroller's canopy extends to provide UPF 50+ sun protection, featuring a zipper for additional coverage and ventilation panels for optimal airflow.

# 4.4. Handlebar and Footrest Adjustment

The adjustable handlebar and footrest enhance comfort for both parent and child.

- To adjust the handlebar height, locate the buttons on either side of the handle and press them while moving the handle up or down.
- The footrest can be adjusted to provide optimal support for your child's legs as they grow. Locate the adjustment mechanism beneath the footrest and set it to the desired angle.

# **New and Improved**



Figure 4.3: The Mompush Stroller features a new adjustable handlebar for parent comfort and an adjustable footrest to support your child's growing legs.

# 4.5. Folding the Stroller

The stroller features a compact, one-step folding mechanism.

- 1. Ensure the seat is in the forward-facing position and fully upright.
- 2. Locate the folding release mechanism (usually on the handlebar or side of the frame).
- 3. Activate the release and push the handlebar forward and down until the stroller folds compactly. It will automatically lock and stand independently.

# Compact fold with

without seat attached automatically locks, stands upright



Figure 4.4: The stroller folds compactly and stands upright, making it convenient for storage and transport.

# 5. MAINTENANCE

#### 5.1. Cleaning

- Fabric Parts: Spot clean with a damp cloth and mild soap. Do not machine wash or bleach. Allow to air dry completely.
- Frame: Wipe the frame with a soft, damp cloth. Dry thoroughly to prevent rust.
- Wheels: Regularly clean debris from the wheels and axles. Lubricate moving parts with a silicone-based lubricant if necessary.

### 5.2. Storage

Store the stroller in a dry, cool place away from direct sunlight and extreme temperatures. Ensure it is clean and dry before storing to prevent mold or mildew.

# 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not fold or unfold smoothly.	Folding mechanism is jammed or dirty; seat not in correct position.	Ensure seat is upright and forward-facing. Clear any obstructions from the folding mechanism. Lubricate moving parts if needed.
Wheels squeak or do not turn freely.	Debris in wheel axles; lack of lubrication.	Clean wheels and axles thoroughly. Apply a silicone-based lubricant to the wheel mechanisms.
Stroller feels unstable or wobbly.	Frame not fully locked; wheels not properly attached.	Ensure the frame is fully unfolded and locked. Check that all wheels are securely clicked into place.
Harness is difficult to buckle or unbuckle.	Buckle mechanism is dirty or damaged.	Clean the buckle with a damp cloth. Do not force the buckle. If damaged, contact customer support.

# 7. SPECIFICATIONS

Feature	Detail
Brand	Mompush
Model Number	P711
Color	Grey
Material	Polyester (Fabric), Aluminum (Frame), Rubber (Tires)
Age Range (Description)	0-36 Months
Maximum Weight Recommendation	50 Pounds
Item Weight	23 Pounds
Item Dimensions (L x W x H)	38"L x 23.6"W x 43.3"H
Folded Size	13" x 22" x 37"
Harness Type	5 Point
Stroller Type	Standard Stroller, Convertible 2-in-1
Car Seat Compatible	Yes (with included adapter)
Number of Wheels	4
Brake System	Yes

#### 8. WARRANTY AND SUPPORT

## 8.1. Warranty Information

For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Mompush website. The manufacturer's warranty typically covers defects in materials and workmanship under normal use.


Please note that third-party protection plans, if purchased, are separate from the manufacturer's warranty and have their own terms and conditions.

## 8.2. Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact Mompush customer support. Keep your purchase receipt and model number (P711) ready when contacting support. For contact details, please visit the official Mompush website or refer to the contact information provided in your product packaging.

© 2025 Mompush. All rights reserved.

#### Related Documents - P711



#### Mompush Nova Stroller User Manual and Safety Guide

Comprehensive user manual and safety guide for the Mompush Nova stroller, covering assembly, usage, cleaning, and warranty information. Ensure safe and optimal use of your stroller.



#### Mompush Lithe V2 Stroller User Manual and Safety Information

Comprehensive guide for the Mompush Lithe V2 stroller, covering safety warnings, assembly instructions, cleaning, and warranty information. Learn how to use and maintain your stroller for optimal performance and child safety.



#### Mompush Meteor Stroller User Manual and Safety Guide

Comprehensive user manual and safety guide for the Mompush Meteor stroller, covering assembly, usage, cleaning, and warranty information.



#### Mompush Meteor Stroller User Manual and Safety Guide

Comprehensive user manual and safety guide for the Mompush Meteor stroller, covering assembly, usage, cleaning, and warranty information. Learn how to safely operate and maintain your stroller for optimal performance and child safety.



#### Mompush T3500 Lightweight Stroller User Manual and Safety Guide

Comprehensive user manual and safety guide for the Mompush T3500 lightweight stroller, covering assembly, operation, safety precautions, maintenance, and warranty information.



#### Mompush T629 Stroller: User Manual, Assembly, and Safety Guide

Official user manual for the Mompush T629 stroller. Find detailed instructions on assembly, bassinet mode, stroller mode, harness adjustment, safety warnings, folding, and care. Ensure safe and proper use of your Mompush T629 stroller.