

[Manuals.plus](#) /

› [Nyeekey](#) /

› Nyeekey 9-in-1 Toddler Slide and Climber Playset (Model 1116) Instruction Manual

## Nyeekey 1116

# Nyeekey 9-in-1 Toddler Slide and Climber Playset (Model 1116) Instruction Manual

Your comprehensive guide to assembly, use, and care.

## 1. INTRODUCTION

---

Thank you for choosing the Nyeekey 9-in-1 Toddler Slide and Climber Playset. This versatile playset is designed to provide a safe and engaging environment for children aged 1-4 years, fostering physical activity and imaginative play. It features a slide, basketball hoop, telescope, ring-toss, climbing elements, a tunnel, and storage space. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure a safe and enjoyable experience.

# 9 in 1

## L-Shaped Toddler Slide



Figure 1: Overview of the 9-in-1 playset features.



**Global Recycled Standard (GRS)**  
Safe & Fun for Kids, Gentle on the Planet!



Figure 2: Detailed diagram of the playset's components and activities.

## 2. SAFETY INFORMATION

Read all instructions before assembly and use. Adult supervision is required at all times. Failure to follow these instructions may result in serious injury.

- Ensure all parts are securely fastened before allowing children to play.
- Place the playset on a level, soft surface such as grass or a play mat. Avoid hard surfaces like concrete or asphalt.
- Keep children away from the playset during assembly to prevent injury.
- Regularly inspect the playset for loose parts, damage, or wear. Discontinue use if any damage is found.
- Do not allow more than one child on the slide or climbing elements at a time.
- Maximum weight recommendation: 155 Pounds.
- Recommended age range: 1-4 years.

any combination of 4 parts,  
suitable for various sizes of spaces.



Figure 3: Safety guidelines including maximum load and material information.

### 3. PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. Refer to the assembly video for visual identification of components.

Your browser does not support the video tag.

Video 1: Detailed assembly guide for the Nyeekoy 9-in-1 Toddler Slide and Climber Playset, showing all parts and step-by-step construction.

### 4. SETUP AND ASSEMBLY

The Nyeekoy 9-in-1 Toddler Slide and Climber Playset is designed for simple and intuitive assembly. Follow the steps below or refer to the detailed assembly video for visual guidance.

#### 4.1 Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components against the parts list.
2. **Assemble the Slide Base:** Connect the two main slide sections together using the provided fasteners. Ensure they click securely into place.
3. **Construct the Main Play Structure:** Attach the side panels and floor pieces to form the central climbing and tunnel areas. Use the designated connectors and tighten them firmly.
4. **Integrate the Slide:** Securely attach the assembled slide to the main play structure.
5. **Install Climbing Stairs:** Attach the climbing stairs to the designated side of the playset.
6. **Add Accessories:** Install the basketball hoop, telescope, and ring-toss elements to their respective positions.
7. **Final Check:** Double-check all connections and fasteners to ensure they are tight and secure. The playset can be

configured in various ways to suit different spaces.



Figure 4: Examples of playset configurations for different spaces.

## 5. OPERATING INSTRUCTIONS

This playset offers multiple activities to keep children entertained. Always ensure children are supervised while playing.

### 5.1 Slide Usage

Children should climb the stairs to the top platform, sit down, and slide feet-first. Ensure the landing area is clear.



Figure 5: Child on the slide.

### 5.2 Climbing Elements

The playset includes a climbing staircase and various platforms. Encourage children to use handholds and steps for safe climbing.



Figure 6: Detail of the climbing staircase.

### 5.3 Basketball Hoop

Use the provided lightweight ball to practice shooting hoops. The hoop is designed for young children.



Figure 7: Child using the basketball hoop.

### 5.4 Telescope

The rotatable telescope allows children to engage in imaginative exploration. It can be turned 360 degrees.



Figure 8: Child using the telescope.

### 5.5 Ring-Toss

Practice hand-eye coordination by tossing rings onto the designated pegs.



Figure 9: Child playing ring-toss.

## 5.6 Tunnel and Storage Space

Children can crawl through the tunnel for imaginative play. The playset also includes a storage area for toys.



Figure 10: Storage space for toys.

Your browser does not support the video tag.

Video 2: Demonstration of children interacting with various features of the Nyeekoy playset, including the slide, climbing, and imaginative play areas.

## 6. MAINTENANCE

Regular maintenance will extend the life of your playset and ensure continued safety.

- **Cleaning:** Wipe down the playset regularly with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all nuts, bolts, and connections for tightness. Re-tighten as necessary. Inspect plastic components for cracks, breaks, or sharp edges.
- **Storage:** If used outdoors, consider covering the playset during harsh weather conditions to protect the materials. For long-term storage, disassemble and store in a dry, cool place.

## 7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Playset feels wobbly:** Check all connection points and ensure fasteners are fully tightened. Make sure the playset is on a flat, stable surface.
- **Parts do not fit:** Refer to the assembly video and instructions to ensure you are using the correct parts for each step and aligning them properly. Do not force parts together.
- **Missing parts:** Contact Nyeekoy customer support with your product model number and a description of the missing part.

## 8. SPECIFICATIONS

| Feature            | Detail                                |
|--------------------|---------------------------------------|
| Model Number       | 1116                                  |
| Material           | Polyethylene (PE), Polypropylene (PP) |
| Product Dimensions | 77.2"L x 63"W x 36.6"H                |
| Item Weight        | 33.17 Pounds                          |

|                               |                     |
|-------------------------------|---------------------|
| Maximum Weight Recommendation | 155 Pounds          |
| Age Range (Description)       | Toddler (1-4 years) |
| Assembly Required             | Yes                 |



Figure 11: Playset dimensions.

9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or any other support inquiries, please contact Nyeekoy customer service. Keep your purchase receipt and product model number (1116) handy for faster service.

**Contact Information:** Refer to the product packaging or the retailer's website for the most up-to-date customer service contact details.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question