
[Manuals.plus](#) /

› [Torchlet](#) /

› Torchlet Smart RGB Floor Lamp User Manual

Torchlet FL123

Torchlet Smart RGB Floor Lamp User Manual

Model: FL123

PRODUCT OVERVIEW

The Torchlet Smart RGB Floor Lamp offers versatile lighting solutions for your living space. Featuring a classic design with a white fabric shade, this lamp integrates cutting-edge RGB technology, providing 16 million DIY colors and various scene modes. It can be controlled via a remote, base buttons, or a dedicated smartphone application, and includes a music rhythm mode for dynamic lighting effects.



Image: The Torchlet Smart RGB Floor Lamp displaying a vibrant array of colors, enhancing the ambiance of a room.

WHAT'S IN THE BOX

- Shade
- Remote Control
- Adapter
- Bulb

SPECIFICATIONS

Brand	Torchlet
Model Number	FL123

Product Dimensions	9.1"D x 9.1"W x 61"H
Item Weight	6.67 pounds
Base Material	Metal
Shade Material	Fabric
Light Source Type	LED
Wattage	11 Watt-hours
Control Method	App, Voice, Remote, Base Buttons
Room Type	Bedroom, Living Room
Indoor/Outdoor Usage	Indoor



Image: A visual representation of the floor lamp's design, highlighting its 58-inch height, 9-inch diameter, stable base, music function, remote control capability, and memory function.

SETUP AND ASSEMBLY

Follow these steps to assemble your Torchlet Smart RGB Floor Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all items listed in "What's in the Box" are present.
2. **Assemble the Pole:** Connect the pole sections by screwing them clockwise until secure. Ensure all connections are tight to provide stability.
3. **Attach to Base:** Securely screw the assembled pole into the lamp's base. The base is designed for stability.
4. **Install the Shade:** Gently stretch the fabric shade over the lamp's frame, aligning it with the top and bottom rings. Ensure the shade is evenly distributed and taut for optimal appearance.
5. **Insert Bulb and Adapter:** Screw the provided bulb into the lamp socket. Connect the power adapter to the lamp and then plug it into a standard electrical outlet.



Image: Two views of the Torchlet floor lamp, one with a round base and the other with a square base, alongside their respective packaging boxes, illustrating the product's design and components.

OPERATING INSTRUCTIONS

Your Torchlet Smart RGB Floor Lamp offers multiple control methods and lighting features:

Control Methods:

- **Remote Control:** Use the included remote to power on/off, adjust brightness, change colors, and select preset scene modes.

- **Base Buttons:** The lamp's base features physical buttons for basic control, such as power and cycling through primary colors or modes.
- **"duoCo StripX" APP:** For full functionality, download and connect to the "duoCo StripX" application on your smartphone. The app allows for precise color selection (16 million DIY colors), brightness and speed adjustments, setting timers, and accessing a wide array of scene and music modes.



Image: An illustration demonstrating the three ways to control the Torchlet floor lamp: via a smartphone application, a dedicated remote control, and integrated buttons on the lamp's base.

Lighting Features:

- **16 Million DIY Colors:** Customize your lighting with a vast spectrum of colors to match any mood or occasion.
- **Multiple Scene Modes:** Choose from a variety of static and dynamic scene modes available through the app to instantly transform your room's atmosphere.
- **Music Rhythm Mode:** Sync the lamp's lighting effects with music or other sounds from your computer, TV, or films for an immersive audio-visual experience.
- **Dimmable:** Adjust the brightness level to create the perfect ambiance, from bright task lighting to soft, ambient glow.
- **Timer Function:** Set schedules for the lamp to automatically turn on or off, enhancing convenience and energy efficiency.

DIY LIGHT SHOWS MADE BY YOU



Image: A smartphone screen displaying the "duoCo StripX" app's color selection interface, allowing users to choose from 16 million colors for personalized lighting.

FEELING THE RHYTHM OF MUSIC AND LIGHTING



Image: A person enjoying the music rhythm mode of the floor lamp, with colorful light patterns synchronized to musical notes, creating a dynamic atmosphere.

Multiple Adjustment Modes

Adjustable color temperature, brightness and RGB lighting settings



Image: Three instances of the floor lamp demonstrating various adjustment modes, including adjustable color temperature (warm to cool white) and RGB lighting settings.

MAINTENANCE

To ensure the longevity and optimal performance of your Torchlet Smart RGB Floor Lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the lamp from power before cleaning. Use a soft, dry cloth to wipe down the base and pole. For the fabric shade, a clean, dry microfiber cloth is recommended. Avoid using liquid cleaners or abrasive materials, as they may damage the finish or fabric. The shade is not washable and should not be steamed or ironed.
- **Bulb Replacement:** If the LED bulb needs replacement, ensure you use a compatible LED bulb as specified by Torchlet to maintain functionality and light quality.
- **Storage:** If storing the lamp for an extended period, disassemble it carefully and store it in its original packaging in a dry, cool place to protect components.

TROUBLESHOOTING

If you encounter issues with your Torchlet Smart RGB Floor Lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, faulty adapter/bulb.	Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet. Check if the bulb is properly screwed in. Test the outlet with another device.
Remote control not working.	Dead batteries, remote out of range, interference.	Replace the remote control batteries. Ensure you are within the effective range of the lamp. Remove any obstructions between the remote and the lamp's receiver.
App connectivity issues.	Incorrect Wi-Fi settings, app glitch, lamp not in pairing mode.	Ensure your phone's Wi-Fi is on and connected to a 2.4GHz network (if applicable). Restart the "duoCo StripX" app. Try resetting the lamp to pairing mode (refer to app instructions for specific steps). If the app freezes, restart the app.
Colors are not displaying correctly or are inconsistent.	Software glitch, internal component issue.	Restart the lamp by unplugging it for 10 seconds and plugging it back in. If the issue persists, try resetting the lamp via the app or remote to its factory settings.

WARRANTY AND SUPPORT

For warranty information or further assistance, please contact Torchlet Direct, the seller of your product. Keep your purchase receipt as proof of purchase for any warranty claims.

You can often find support and contact information on the seller's page on the platform where you purchased the product. For general inquiries, visit the [Torchlet Store](#).

