Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SeekFancy 767248610308

SeekFancy Reclining Criss Cross Office Chair User Manual

Model: 767248610308

Introduction

This manual provides instructions for the assembly, operation, and maintenance of your SeekFancy Reclining Criss Cross Office Chair. Please read this manual thoroughly before use to ensure proper function and safety.



Image: The SeekFancy Reclining Criss Cross Office Chair in white, showcasing its design and features.

Safety Information

For your safety and to prevent damage to the product, observe the following guidelines:

- **Maximum Weight Capacity:** This chair is designed to support a maximum weight of 400 lbs. Do not exceed this limit.
- Ensure all components are securely fastened during assembly and periodically check for loose connections.
- Avoid standing on the chair or using it as a step stool.
- Keep hands and feet clear of moving parts, especially during height adjustment and reclining.
- Use the chair on a flat, stable surface.

Product Features

The SeekFancy Reclining Criss Cross Office Chair offers several features designed for comfort and functionality:

- **90°-140° Synchronized Recline:** A premium tilt-back mechanism allows smooth transition from an upright 90° working position to a relaxed 140° recline.
- **Heavy-Duty 400 lbs Capacity:** Reinforced metal base and high-strength cylinder provide robust support for up to 400 lbs.
- **10% Thickened Wide Cushion:** Features upgraded, high-density sponge padding over a solid wood inner panel, designed to prevent bottoming out and allow comfortable cross-legged sitting.
- **Ergonomic Multi-Zone Support:** Two-section high backrest contours to the body, providing tailored support for the neck, back, hips, and legs.
- **Vintage Button-Tufted Aesthetics:** Exquisite stitching and button-tufted detailing enhance the chair's retro executive design.



Image: A close-up view highlighting the thickened, high-density sponge cushion for enhanced comfort.



Image: An overhead perspective demonstrating the widened and thickened seat cushion, ideal for sitting cross-legged.



Image: Detail of the chair's PU leather, indicating its water-resistant, skin-friendly, and scratch-resistant properties.

Assembly Instructions

The SeekFancy Reclining Criss Cross Office Chair requires assembly. Detailed step-by-step instructions and all necessary hardware are included in the product packaging. Please follow these instructions carefully to ensure correct and safe assembly.
If you encounter any difficulties during assembly, please refer to the troubleshooting section or contact customer support.

Operating Instructions

Reclining Function

The chair features a synchronized recline mechanism, allowing you to adjust the backrest angle from 90° to 140°.

- To recline, locate the lever on the side of the chair (typically on the right).
- Pull the lever outwards to unlock the recline mechanism.

- Lean back to your desired angle.
- Push the lever inwards to lock the chair in the reclined position.
- To return to an upright position, pull the lever outwards and lean forward. The chair will return to 90°.



Image: Illustration of the chair's 90-140 degree recline capability, highlighting ergonomic support zones.

Retractable Footrest

A hidden, extendable footrest is integrated into the chair for leg support during relaxation.

- To extend the footrest, pull it out from underneath the seat.
- Adjust its position for optimal leg support.
- To retract, push the footrest back underneath the seat until it is fully hidden.



Image: A close-up view of the hidden extendable footrest in its extended position.

Height Adjustment

The chair's height can be adjusted using the lever located under the seat.

- To raise the seat, lift the lever while taking your weight off the seat.
- To lower the seat, lift the lever while remaining seated.
- Release the lever to lock the height in place.

Swivel and Rolling

The chair features a 360° swivel function and smooth-rolling casters for easy movement.

Video: How to use the reclining function?

Your browser does not support the video tag.

Video: This video demonstrates the operation of the reclining mechanism on the SeekFancy office chair.

Video: Reclining Office Chair with Footrest

Your browser does not support the video tag.

Video: This video illustrates the use of both the reclining function and the retractable footrest for enhanced comfort.

Maintenance

Proper care and maintenance will extend the life of your SeekFancy office chair.

- **Cleaning:** The PU leather material is water-resistant and can be cleaned with a damp cloth. For deeper cleaning, dry clean only. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Casters:** Keep the casters free of debris (hair, dust) to ensure smooth rolling.
- **General Care:** Avoid exposing the chair to direct sunlight for prolonged periods to prevent material degradation.

Troubleshooting

If you encounter issues with your SeekFancy office chair, consider the following common solutions:

- **Chair not adjusting height:** Ensure the gas lift lever is fully engaged and that there is no obstruction. If the gas lift is faulty, it may need replacement.
- **Chair wobbles:** Check that all assembly bolts are securely tightened. Ensure the chair is on a level surface.
- **Recline mechanism stuck:** Verify that the recline lock lever is fully disengaged. Apply gentle pressure to the backrest while operating the lever.
- **Footrest not extending/retracting smoothly:** Check for any obstructions in the sliding mechanism. Clean any debris that may be present.

For persistent issues or concerns not addressed here, please contact SeekFancy customer support.

Specifications

Feature	Detail
Brand	SeekFancy
Model Number	767248610308
Color	White
Material	Faux Leather (Seat), Sponge (Fill), Wood (Frame)
Product Dimensions (D x W x H)	20.1"D x 22.8"W x 40"H
Item Weight	60 Pounds
Maximum Weight Recommendation	400 Pounds
Reclining Position Count	2 (90° to 140°)
Additional Features	Adjustable Height, Reclining, Rolling, Seat Lock, Swivel, Retractable Footrest
Assembly Required	Yes



Image: Detailed product dimensions of the SeekFancy Reclining Criss Cross Office Chair.

Warranty and Support

For information regarding warranty coverage, product support, or to purchase replacement parts, please contact SeekFancy customer service through the retailer where the product was purchased or visit the official SeekFancy website.

Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCJTL29G

More documents and user manuals: **https://manuals.plus/**