



[Manuals.plus](#) /

> [Blow](#) /

> BLOW BTX700ANC Bluetooth Headphones User Manual

Blow BTX700ANC

BLOW BTX700ANC Bluetooth Headphones User Manual

MODEL: BTX700ANC (32-833)

Introduction

Thank you for choosing the BLOW BTX700ANC Bluetooth Headphones. These wireless headphones are designed to provide an immersive audio experience with active noise cancellation (ANC) and versatile connectivity. Please read this manual carefully to ensure proper use and maintenance of your device.



Image: Front-side view of the BLOW BTX700ANC Bluetooth Headphones, showcasing the earcups and headband.

Package Contents

Please check the package for the following items:

- BLOW BTX700ANC Bluetooth Headphones
- USB-C Charging Cable
- 3.5mm to 3.5mm Audio Cable (1m)

Product Overview

Familiarize yourself with the various parts and controls of your headphones.



Image: Close-up view of the right ear cup, showing the control buttons and ports.

Controls and Ports:

- **Power Button:** Press and hold to power on/off. Short press for play/pause.
- **Volume Up/Next Track Button (+):** Short press to increase volume. Long press for next track.
- **Volume Down/Previous Track Button (-):** Short press to decrease volume. Long press for previous track.
- **ANC Button:** Press to activate or deactivate Active Noise Cancellation.
- **USB-C Charging Port:** For charging the headphones.
- **3.5mm Audio Jack:** For wired connection.
- **Microphone:** For hands-free calls.
- **TF Card Slot:** Insert a TF card (up to 32GB) for direct music playback.

Setup

1. Charging the Headphones

1. Connect the USB-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, off or blue for fully charged).

4. A full charge takes approximately 2.5 hours.

2. Bluetooth Pairing

1. Ensure the headphones are fully charged.
 2. Press and hold the Power button for approximately 3-5 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
 3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
 4. Select "BTX700ANC" from the list of found devices.
 5. Once successfully paired, the LED indicator will flash blue slowly.
 6. The headphones will automatically reconnect to the last paired device when powered on, if within range (up to 10 meters).
-

Operating Instructions

Power On/Off:

- **Power On:** Press and hold the Power button for 3 seconds.
- **Power Off:** Press and hold the Power button for 3 seconds.

Music Playback:

- **Play/Pause:** Short press the Power button.
- **Next Track:** Long press the "+" button.
- **Previous Track:** Long press the "-" button.
- **Volume Up:** Short press the "+" button.
- **Volume Down:** Short press the "-" button.

Call Management:

- **Answer/End Call:** Short press the Power button.
- **Reject Call:** Long press the Power button.

Active Noise Cancellation (ANC):

- Press the dedicated ANC button to activate or deactivate the noise cancellation feature. The LED indicator will light up (e.g., green) when ANC is active.

Wired Mode:

- Connect one end of the 3.5mm audio cable to the headphone's audio jack.
- Connect the other end to your audio source's 3.5mm output.
- In wired mode, the headphones function passively, and battery power is not required for audio playback, though ANC may still require power.

TF Card Playback:

- Insert a TF (microSD) card with MP3 audio files into the TF card slot.
 - The headphones will automatically switch to TF card playback mode. Use the music playback controls to manage your audio.
-

Maintenance

Proper care will extend the life of your headphones.

Cleaning:

- Wipe the headphones with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.

Storage:

- When not in use, fold the headphones for compact storage.
- Store them in a cool, dry place, away from direct sunlight and extreme temperatures.



Image: The BLOW BTX700ANC headphones in their folded position, ready for storage or transport.

Troubleshooting

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source using the USB-C cable.

Problem	Solution
Cannot pair with device.	<ul style="list-style-type: none"> ◦ Ensure headphones are in pairing mode (LED flashing blue/red). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device (within 10 meters). ◦ Forget "BTX700ANC" from your device's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none"> ◦ Increase volume on both the headphones and your connected device. ◦ Ensure headphones are properly paired. ◦ If using wired mode, check the 3.5mm cable connection.
ANC is not effective.	Ensure the ANC feature is activated by pressing the ANC button. Note that ANC is most effective against low-frequency, constant noise.

Specifications

Feature	Detail
Model Name	BTX700ANC
Model Number	32-833
Bluetooth Version	5.3
Operating Distance	Up to 10 meters
Frequency Range	2.402 - 2.480 GHz
Driver Size	40mm
Battery Capacity	500mAh
Operating Time	Up to 10 hours
Charging Time	Approximately 2.5 hours
Impedance	32 Ohms
Weight	336 Grams
Water Resistance	Not waterproof
TF Card Support	Max 32GB
Compatible Devices	Laptop, Tablet, Mobile Phone
Special Features	Active Noise Cancellation (ANC), Foldable Design, Rechargeable Battery

Safety Information

Please observe the following safety guidelines for safe operation:

- Do not expose the headphones to extreme temperatures, humidity, or liquids.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- Do not attempt to disassemble or modify the headphones. This will void the warranty.
- Keep out of reach of children.
- Dispose of the product and battery responsibly according to local regulations.

Warranty and Support

BLOW products are designed for reliability and performance. For warranty claims or technical support, please refer to the warranty card included with your purchase or contact your retailer. Information regarding spare parts availability and software updates is not provided in this manual.

For further assistance, please visit the official BLOW website or contact their customer service.