Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HiFuture HEO3

HiFuture OLYMBUD3 TWS Earbuds User Manual

Model: HEO3

Introduction

Thank you for choosing the HiFuture OLYMBUD3 TWS Earbuds. These earbuds are designed to provide a superior audio experience with enhanced bass, clear calls, and long-lasting comfort. Featuring Bluetooth 5.3 technology, IPX5 splashproof rating, and up to 30 hours of total playtime, the OLYMBUD3 are your ideal companion for daily listening.



Image: The HiFuture OLYMBUD3 TWS Earbuds, black in color, resting inside their open charging case. The earbuds are clearly visible with 'HiFuture' branding, and the case shows 'L' and 'R' indicators for left and right earbuds.

Package Contents

Please check the package for the following items:

- HiFuture OLYMBUD3 TWS Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- User Manual

Setup

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged. Place the earbuds into the charging case. Connect the USB charging cable to the charging port on the case and the other end to a USB power adapter (not included).

- The indicator light on the charging case will show charging status.
- A full charge typically takes approximately 1.5 to 2 hours.
- The earbuds will charge automatically when placed inside the case.



Image: The black HiFuture OLYMBUD3 charging case standing upright with a green indicator light, and the two black earbuds placed beside it on a white surface. This illustrates the components outside the case.

2. Pairing with Your Device

The OLYMBUD3 earbuds utilize Bluetooth 5.3 for a fast and stable connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "OLYMBUD3" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

Note: The earbuds should automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.



Image: A white smartphone displaying its Bluetooth settings, showing "HiFuture OlymBuds3" as connected. Next to the phone is an open white charging case with two white earbuds inside, illustrating the wireless connection process.

Operating the Earbuds

Wearing the Earbuds

For optimal sound quality and comfort, choose the ear tips that best fit your ears. Gently insert the earbuds into your ear canal and twist slightly to secure them. The OLYMBUD3 are designed for a comfortable fit, ensuring hours of wear without discomfort.



Image: A close-up of a person's ear with a black HiFuture earbud being gently inserted, emphasizing the comfortable fit design of the OLYMBUD3 earbuds.

Smart Touch Controls

The OLYMBUD3 earbuds feature intuitive smart touch controls on each earbud. The specific functions may vary slightly depending on your device and application, but common controls include:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap (Left Earbud):** Previous track.
- **Double Tap (Right Earbud):** Next track.
- **Triple Tap:** Activate voice assistant (Siri, Google Assistant, etc.).
- **Long Press (2 seconds):** Reject incoming call.
- **Long Press (3 seconds):** Manual pairing mode (when not connected).

Call Management with ENC Technology

The built-in ENC (Environmental Noise Cancellation) technology ensures crystal-clear calls by reducing background noise,

allowing your voice to be heard clearly even in noisy environments.

Audio Playback

Experience powerful audio quality with the 6mm drivers and enhanced bass. The OLYMBUD3 delivers a rich and immersive sound profile for all your music and media.

Maintenance

Cleaning Your Earbuds

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, remove them from the earbuds and clean with a mild soap solution if necessary, then rinse and dry thoroughly before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts on both earbuds and case are clean and free of debris.

Storage and Battery Care

Store the earbuds in their charging case when not in use to protect them and keep them charged. For long-term storage, charge the earbuds and case at least once every three months to prevent battery degradation.

IPX5 Splashproof Rating

The OLYMBUD3 earbuds are rated IPX5 splashproof, meaning they are resistant to sweat and light splashes of water. They are not designed for submersion in water or for use during swimming. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

Troubleshooting

If you encounter any issues with your OLYMBUD3 earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing with device.	Ensure earbuds are charged and out of the case. Turn off and on Bluetooth on your device. Forget "OLYMBUD3" from your device's Bluetooth list and re-pair. Try resetting the earbuds (refer to manual for specific reset procedure, usually long press both earbuds in case).
No sound from one or both earbuds.	Check earbud battery levels. Ensure earbuds are properly connected to your device. Clean any debris from the earbud speaker mesh. Try re-pairing the earbuds.
Charging case not charging.	Ensure the USB cable is securely connected. Try a different USB cable or power adapter. Clean the charging port on the case.

Problem	Possible Solution
Poor call quality.	Ensure earbuds are fully charged. Move closer to your connected device to avoid interference. Check for any obstructions blocking the microphone.

Specifications

Feature	Detail
Model Name	HEO3 (OLYMBUD3)
Brand	HiFuture
Connectivity	Bluetooth 5.3
Audio Technology	ENC (Environmental Noise Cancellation)
Driver Size	6mm
Playtime	Up to 30 hours (with charging case)
Water Resistance	IPX5 Splashproof
Color	Black
Ear Placement	In Ear
Form Factor	In Ear
Package Dimensions	13.2 x 11.1 x 4.4 cm; 180 g
Country of Origin	China



Image: A graphic featuring the HiFuture OlymBuds3 earbuds and charging case, with a large "25 Hr Play Time" text overlay. Note: While this image indicates 25 hours, the product features list states up to 30 hours of total playtime.

Warranty and Support

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official HiFuture website. You can also find more information and products from HiFuture at their official Amazon store:

Visit the HiFuture Store on Amazon

© 2024 HiFuture. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCK8TBTT

More documents and user manuals: **https://manuals.plus/**