### Manuals+

Q & A | Deep Search | Upload

#### **CUBE 863 Cart-C Bk**

# **CUBE CART 3 Wheel Push Pull Golf Cart User Manual**

Model: 863 Cart-C Bk | Brand: CUBE

#### INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your CUBE CART 3 Wheel Push Pull Golf Cart. Designed for ease of use and compact storage, this golf cart offers a lightweight and efficient solution for transporting your golf bag on the course.



Image: The CUBE CART 3 Wheel Push Pull Golf Cart shown in both its unfolded, ready-to-use state and its compact, folded state for storage and transport.

## SETUP AND ASSEMBLY

The CUBE CART features a simple two-step folding system for quick setup. Minimal assembly is required upon first use.

## **Initial Assembly**

- 1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the packing list (not provided in this manual, refer to product packaging) are present.
- 2. **Attach Rear Wheels:** The rear wheels are designed for quick attachment. Align the wheel axle with the corresponding slot on the cart frame and push until it clicks securely into place. Repeat for the second rear wheel.

#### 3. Unfold the Cart:

- Pull up the handle to unlock the adjustable position.
- Unlock and unfold the main section of the cart.
- Fold the spring-loaded front wheel into position, aligning it with the back wheel.



Image: Visual guide demonstrating the two-step process for unfolding the golf cart, including pulling the handle, unfolding the main section, and positioning the front wheel.



Image: A woman demonstrating the two-step folding process of the CUBE CART, highlighting the ease of collapsing the cart for storage.

## **OPERATING INSTRUCTIONS**

# **Adjusting Handle Height**

The ergonomic handle can be adjusted to three different height positions to suit various user preferences and ensure comfortable pushing.

- Locate the handle adjustment mechanism near the base of the handle.
- Press the release button or lever (if applicable) and slide the handle up or down to the desired height.
- Ensure the handle locks securely into place before use.



Image: A close-up view of the CUBE CART's handle, illustrating its adjustable height feature for multiple pushing positions.



Image: Detailed view of the handle adjustment mechanism, showing the red lever used to secure the handle at different heights.

## **Using the Foot-Operated Parking Brake**

The foot-operated parking brake provides stability when the cart is stationary.

- To engage the brake, press down firmly on the red lever located near one of the rear wheels with your foot.
- To release the brake, lift the lever upwards with your foot.
- Always ensure the brake is engaged when leaving the cart unattended, especially on inclines.



Image: A visual representation of the CUBE CART's foot brake mechanism and its oversized, friction-free wheels, designed for smooth movement.



Image: Close-up of the CUBE CART's wheel and the red foot brake, indicating its position and function.

# **Utilizing Storage Features**

The CUBE CART is equipped with an integrated storage console for various golf accessories.

- Beverage Holder: Located on the handle for easy access to drinks.
- Scorecard Holder: A dedicated slot for your scorecard.
- Accessory Compartment: A covered compartment for small items like keys, wallet, or phone.
- Tee and Ball Holders: Specific slots to keep your tees and golf balls organized.



Image: A detailed view of the CUBE CART's convenient storage console, labeling the beverage holder, golf tees holder, golf ball holder, elastic strap, and scorecard holder.



Image: A woman opening the storage compartment on the golf cart's handle, demonstrating easy access to golf tees and balls.

# **Securing Your Golf Bag**

The adjustable bag supports and straps ensure your golf bag remains secure during transport.

- Place your golf bag onto the cart's lower and upper supports.
- Utilize the elastic straps to firmly secure the bag to the cart frame. Ensure the bag is snug to prevent shifting during movement.



Image: Hands securing a golf bag to the CUBE CART using the integrated elastic straps, ensuring the bag is stable and secure.

# **Umbrella Holder (Included)**

A complimentary umbrella holder is included for use in various weather conditions.

- Insert the umbrella holder into the designated slot on the cart's handle assembly.
- Place your golf umbrella into the holder.



Image: A man standing next to the CUBE CART with a golf bag and an umbrella securely placed in the umbrella holder, demonstrating its utility on the golf course.



Image: A man adjusting an umbrella in the CUBE CART's umbrella holder, showcasing the ease of use for weather protection.

## **M**AINTENANCE

Regular maintenance will extend the life and performance of your CUBE CART.

- Cleaning: Wipe down the cart with a damp cloth after each use to remove dirt, grass, and debris. For stubborn stains, use mild soap and water. Avoid abrasive cleaners or solvents.
- Wheel Inspection: Periodically check the wheels for any signs of wear or damage. Ensure they rotate freely and are free of obstructions. The oversized wheels are designed for low maintenance.
- **Moving Parts:** Inspect all moving parts, including the folding mechanism and brake, to ensure they operate smoothly. Lubricate pivot points with a silicone-based spray if necessary.
- **Storage:** Store the cart in a dry, cool place, away from direct sunlight and extreme temperatures. The compact folded size (approximately 22" x 18.5" x 13.5") allows for convenient storage.

#### **Troubleshooting**

Problem	Possible Cause	Solution
Cart does not fold/unfold smoothly.	Mechanism obstructed or stiff.	Check for debris in the folding joints. Apply a small amount of silicone lubricant to pivot points. Ensure all release levers are fully engaged/disengaged.
Foot brake not engaging/disengaging.	Debris in mechanism or misaligned.	Clear any debris around the brake mechanism. Ensure the lever is fully pressed down or lifted. If issues persist, inspect for damage.
Cart pulls to one side.	Front wheel alignment issue.	While the manual states the front wheel is adjustable, some users report difficulty. Gently check if the front wheel assembly is bent or misaligned. If persistent, contact customer support.
Umbrella holder feels flimsy.	Normal flex due to material; heavy umbrella.	This is often due to the plastic construction. Use the lightest umbrella possible to minimize sway. Ensure it is fully inserted into the holder.

# **SPECIFICATIONS**

• Model: 863 Cart-C Bk

• Brand: CUBE

• Product Dimensions (Unfolded): Approximately 44.5" (L) x 27" (W) x 47.5" (H)

• Folded Dimensions: Approximately 22" (H) x 18.5" (W) x 13.5" (D)

• Item Weight: 14.5 Pounds

• Material: Aluminum Body, Rubber Tires

• Number of Wheels: 3

 Special Features: Adjustable Handle, Foldable, Lightweight, Foot-Operated Parking Brake, Integrated Storage Console, Umbrella Holder

• Assembly Required: Yes (Minimal)

# **Product Dimension**



Image: Detailed diagram illustrating the product dimensions when unfolded and in its compact, folded state.



Image: The CUBE CART in its compact folded state, shown fitting easily into a car trunk, with its folded dimensions highlighted.

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact CUBE customer service directly. Specific warranty details are not provided in this manual; please refer to the product's original packaging or the manufacturer's official website for the most current warranty policy.

Manufacturer: Cube Carts

© 2025 CUBE. All rights reserved.

#### **Related Documents**



#### CUBE Carbon Frame and Fork Additional Instructions | Model Year 2025

Detailed additional operating and assembly instructions for CUBE C:68X, C:68, C:62, and HPC series carbon frames and forks for Model Year 2025. Covers important notes, care, guarantee, and assembly procedures.

