

RPPB2024

Regalosonline Mini Personal Portable Hand Blender RPPB2024 User Manual

Model: RPPB2024 | Brand: Generic

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Regalosonline Mini Personal Portable Hand Blender. Designed for convenience and versatility, this blender allows you to prepare a variety of beverages and soft foods on the go. Please read this manual thoroughly before first use and retain it for future reference.

PRODUCT OVERVIEW

Key Features

- **Compact and Portable Design:** Easy to carry for use at home, office, gym, or while traveling.
- **Powerful Blending:** Equipped with a DC motor reaching 21,000 RPM and 6 stainless steel blades for efficient blending of fruits, vegetables, and powders.
- **USB Rechargeable:** Convenient charging via USB-C port from various sources including wall adapters, power banks, or car chargers.
- **2-in-1 Functionality:** Blend and drink from the same cup.
- **Durable Materials:** Food-contact parts made of stainless steel, with a high-quality plastic structure.
- **Easy to Clean:** Simple cleaning process with water and soap.

Components

1. Blender Base with Motor and Controls
2. Blender Cup (300 ml capacity)
3. Lid with Drinking Spout
4. USB Charging Cable

Small Portable Juicer

Enjoy shakes and smoothies anytime and anywhere



Image: The Regalosonline Mini Personal Portable Hand Blender shown with various fruits, highlighting its use for fresh beverages.

SETUP

- 1. Initial Charge:** Before first use, fully charge the blender using the provided USB cable. Connect the USB-C end to the blender's charging port and the USB-A end to a compatible power source (e.g., wall adapter, computer, power bank). The indicator light will show charging status.
- 2. Wash Components:** Disassemble the blender cup and lid. Wash them thoroughly with warm, soapy water. Rinse well and dry completely before assembly. The blender base should not be submerged in water; wipe it clean with a damp cloth.
- 3. Assemble:** Ensure the blender cup is securely twisted onto the blender base. The safety lock mechanism must be engaged for the blender to operate.



Image: Close-up of the blender base showing the USB charging port and power button, illustrating the charging process.

OPERATING INSTRUCTIONS

- 1. Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1 inch or 2.5 cm) to ensure optimal blending. Do not overfill the cup; leave some space for blending.
- 2. Add Liquid:** Always add liquid (water, milk, juice, etc.) before adding solid ingredients. This helps the blades move freely and prevents motor strain.
- 3. Secure the Cup:** Ensure the blender cup is firmly attached to the base and the safety lock is engaged. The blender will not operate if the cup is not correctly secured.
- 4. Start Blending:** Press the power button twice quickly to start the blending cycle. The blender will run for a set duration (typically 30-60 seconds) or until you press the button once to stop it.
- 5. Optimal Blending:** For best results, hold the blender upside down or at an angle during blending to allow ingredients to fall onto the blades. Gently shake the blender if ingredients get stuck.
- 6. Enjoy Your Drink:** Once blending is complete, remove the blender cup from the base, attach the drinking lid, and enjoy your fresh beverage.

Your browser does not support the video tag.

Video: Demonstration of the portable blender's features, including its compact size, easy operation, and powerful 6-blade

system for smooth blending.

Your browser does not support the video tag.

Video: Overview of the Regalosonline Portable Blender, highlighting its 10 oz capacity and USB charging capability for convenient use.

MAINTENANCE

Cleaning

1. **Quick Clean:** After each use, add a small amount of water and a drop of dish soap to the blender cup. Secure the lid and run the blender for a few seconds. Rinse thoroughly.
2. **Deep Clean:** For a more thorough clean, detach the cup from the base. Wash the cup and lid with warm, soapy water using a brush if necessary. Rinse and dry completely.
3. **Base Cleaning:** Wipe the blender base with a damp cloth. Do not submerge the base in water or place it in a dishwasher.

Storage

Store the blender in a clean, dry place away from direct sunlight and extreme temperatures. Ensure all components are dry before storage to prevent mold or odors.



Image: The blender disassembled into its base, cup, and lid, illustrating how to separate components for cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not start	Cup not securely attached; Low battery; Power button not pressed correctly.	Ensure cup is twisted on tightly and safety lock is engaged. Charge the blender. Press the power button twice quickly to start.
Ingredients not blending smoothly	Too many ingredients; Not enough liquid; Ingredients too large.	Reduce ingredient quantity. Add more liquid. Cut ingredients into smaller pieces. Blend in pulses or invert the blender.
Blender leaks	Lid not properly sealed; Cup not properly sealed to base.	Ensure the lid is tightly screwed on. Verify the cup is securely twisted onto the base. Check for any damage to seals.

Problem	Possible Cause	Solution
Short battery life	Incomplete charging; Old battery.	Ensure the blender is fully charged before use. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	RPPB2024
Brand	Generic
Capacity	300 Milliliters
Product Dimensions	7.7"D x 3.3"W x 3.3"H
Item Weight	14.9 ounces
Power Source	Battery Powered (USB Rechargeable)
Motor Speed	Up to 21,000 RPM
Number of Blades	6
Control Type	Push Button
Container Material	Plastic
Special Features	Compact, Ergonomic Handle, Personal, Portable
Included Components	USB Charger

Small Portable Juicer

Product Details



Image: Visual representation of the blender's dimensions (height, width, weight) for easy reference.

Product Details


Product	Details
<p data-bbox="354 409 660 450">Portable Juicer</p> 	<p data-bbox="833 409 1246 488">Packing size: 22 cm*10 cm*13,5 cm</p> <p data-bbox="833 535 1107 613">Weight: 0,43 kg Color: Blue</p> <p data-bbox="833 660 1131 739">Volume: 400 ml RPM:21000±15%</p> <p data-bbox="833 786 1262 826">Certification: CE, ROHS</p>

Image: A table summarizing key product details such as packing size, weight, color, volume, RPM, and certifications.

WARRANTY AND SUPPORT

This Regalonline Mini Personal Portable Hand Blender comes with a **Limited Warranty**. For specific warranty terms, duration, and conditions, please refer to the warranty card included in your product packaging or contact the retailer where you purchased the product.

For technical support, troubleshooting assistance, or inquiries regarding your product, please contact the seller or manufacturer directly. Contact information can typically be found on the product packaging or the retailer's website.