

[Manuals.plus](#) /

› [Pagani Design](#) /

› Pagani Design PD1786 Multifunction Quartz Watch User Manual

Pagani Design PD1786

Pagani Design PD1786 Multifunction Quartz Watch User Manual

Model: PD1786

INTRODUCTION

Thank you for choosing the Pagani Design PD1786 Multifunction Quartz Watch. This timepiece combines elegant design with practical features, including a chronograph, moon phase indicator, automatic date, and week display, all powered by a reliable Japanese quartz movement. This manual provides essential information for proper setup, operation, and maintenance to ensure optimal performance and longevity of your watch.



Image: The Pagani Design PD1786 watch featuring a brown dial, chronograph subdials, moon phase, and a stainless steel bracelet.

SETUP INSTRUCTIONS

Before using your watch, please follow these steps to set the time, date, day of the week, and moon phase.

Components Overview

- **Crown:** Used for setting time, date, and day.
- **Pushers:** Used for operating the chronograph function.
- **Hour/Minute Hands:** Indicate the current time.
- **Small Seconds Hand:** Located in a subdial.
- **Date Display:** Shows the current date.
- **Day of Week Display:** Shows the current day.
- **Moon Phase Indicator:** Displays the current phase of the moon.
- **Chronograph Subdials:** Measure elapsed time.



Image: A side view of the watch, highlighting the crown and pushers on the right side of the case.

Setting the Time

1. Pull the crown out to the **second click position**. The small seconds hand will stop.
2. Turn the crown to move the hour and minute hands clockwise until the desired time is set. Pay attention to AM/PM for correct date change.
3. Push the crown back to the normal position to start the watch.

Setting the Date and Day of Week

1. Pull the crown out to the **first click position**.

2. Turn the crown *clockwise* to set the date.
3. Turn the crown *counter-clockwise* to set the day of the week.
4. Once the date and day are set, push the crown back to the normal position.

Note: Avoid setting the date and day between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism. If you need to adjust during this period, first set the time outside this window, adjust the date/day, then reset the time.

Setting the Moon Phase

The moon phase is typically set by a dedicated pusher or by rotating the crown in a specific position. Refer to the specific markings on your watch for the moon phase adjustment pusher, usually located on the side of the case. Use a small, non-metallic tool to gently press the recessed pusher until the moon phase display aligns with the current moon phase.

OPERATING INSTRUCTIONS

Using the Chronograph

The chronograph function allows you to measure elapsed time independently of the main time display.

1. **Start:** Press the **upper pusher** to start the chronograph. The chronograph seconds hand will begin to move.
2. **Stop:** Press the **upper pusher** again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping, press the **lower pusher** to reset the chronograph hands to their zero positions.

Note: Do not operate the chronograph pushers while the watch is wet or submerged to prevent water intrusion.

Water Resistance

Your Pagani Design PD1786 watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water.



Image: The Pagani Design PD1786 watch worn on a wrist, showcasing its elegant appearance.

MAINTENANCE

Proper care will help maintain the appearance and functionality of your watch.

Cleaning

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and fingerprints.
- For stainless steel bracelets, a soft brush with mild soapy water can be used, followed by thorough rinsing and drying. Ensure the crown is fully closed before cleaning with water.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish or seals.

Storage and Handling

- Store your watch in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid exposing the watch to strong magnetic fields, as this can affect the accuracy of the quartz movement.
- Protect the watch from impacts and shocks.

Battery Replacement

As a quartz watch, the PD1786 is powered by a battery. When the battery runs low, the watch may stop or the seconds hand may jump in irregular intervals (End-of-Life indicator). Battery replacement should be performed by a qualified watchmaker to ensure proper sealing and water resistance.



Image: The Pagani Design PD1786 watch with its stainless steel bracelet and open butterfly clasp, ready for adjustment or wear.

TROUBLESHOOTING

If you encounter issues with your watch, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Watch has stopped	Battery depleted; Crown pulled out.	Replace battery (professional service recommended); Push crown fully in.
Date/Day changes at noon	AM/PM incorrectly set.	Advance the time by 12 hours.
Chronograph hands do not reset to zero	Requires calibration.	Consult a professional watchmaker for adjustment.

Problem	Possible Cause	Solution
Condensation inside watch	Water intrusion; Sudden temperature change.	Seek immediate professional service to prevent damage.

If the problem persists after attempting these solutions, please contact customer support or a certified watch repair center.

SPECIFICATIONS

- **Model Number:** PD1786
- **Movement:** Japanese Quartz (VX3HA)
- **Case Material:** 316L Stainless Steel
- **Case Diameter:** 32.5 mm
- **Case Thickness:** 10.5 mm
- **Band Material:** Stainless Steel
- **Band Width:** 21.5 mm
- **Band Length:** 170 mm
- **Dial Window Material:** Resin (Scratch-resistant)
- **Water Resistance:** 50 Meters (5 ATM)
- **Weight:** 99 Grams
- **Functions:** Time (Hour, Minute, Small Seconds), Date, Day of Week, Moon Phase, Chronograph
- **Clasp Type:** Double closure with folding ratchet clasp



Image: The reverse side of the Pagani Design PD1786 watch, displaying the engraved case back and the detailed folding clasp.

WARRANTY INFORMATION

This Pagani Design PD1786 watch comes with a limited warranty. For specific terms and conditions, please refer to the warranty card included with your purchase or contact the seller directly. Additionally, a 30-day free return policy is offered, ensuring your satisfaction with this product.

CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact the seller or the manufacturer's customer service. Keep your purchase receipt and model number (PD1786) handy for faster service.