



Manuals.plus /

› let'me /

› let'me Humidifier with Warm & Cool Mist - Model HQ-JS2325WE User Manual

## let'me HQ-JS2325WE

# let'me Humidifier with Warm & Cool Mist - Model HQ-JS2325WE User Manual

## INTRODUCTION

---

Thank you for choosing the let'me Humidifier Model HQ-JS2325WE. This advanced humidifier is designed to enhance your indoor environment by providing both warm and cool mist options, intelligent humidity control, and an aromatherapy feature. With its large 2.64-gallon capacity and efficient operation, it is suitable for spaces up to 500 sq ft, offering up to 60 hours of continuous runtime. Please read this manual thoroughly before operation to ensure safe and optimal performance.

## IMPORTANT SAFETY INSTRUCTIONS

---

- Always place the humidifier on a firm, flat, water-resistant surface at least 12 inches (30 cm) away from walls and appliances.
- Do not place the humidifier directly on carpet, rugs, or absorbent surfaces.
- Keep the humidifier out of reach of children and pets.
- Use only clean, distilled, or demineralized water to prevent mineral buildup and ensure optimal mist output.
- Do not add essential oils directly into the water tank. Use the designated aroma tray only.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not block the air intake or mist outlet.
- If the humidifier emits an unusual smell or sound, discontinue use immediately and contact customer support.

## PACKAGE CONTENTS

---

- let'me Humidifier Unit
- Remote Control

## PRODUCT OVERVIEW

---






Figure 1: The let'me Humidifier, Model HQ-JS2325WE, in white, shown with its remote control. The unit features a digital display and a tall, slim design.

# Warm Mist

with a temperature of 100-120°F



Figure 2: A close-up of the humidifier's digital control panel, indicating warm mist operation and a temperature of 120°F. The water tank is visible with blue-tinted water.

# Comfort beyond quiet



Figure 3: The remote control for the let'me Humidifier, featuring buttons for power, sleep mode, mist volume, humidity customization, warm mist, timer, UV lamp, and color light.

## SETUP

### 1. Initial Placement

- Unpack the humidifier and all accessories.
- Place the humidifier on a flat, stable surface. Ensure it is at least 12 inches (30 cm) away from any walls

or furniture to allow for proper mist dispersion.

## 2. Filling the Water Tank

- Ensure the humidifier is unplugged before filling.
- Open the top-fill lid.
- Pour distilled or demineralized water directly into the water tank until it reaches the 'MAX' line indicated on the side. Do not overfill.
- Close the top-fill lid securely.

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing, assembly, and initial setup of the let'me Humidifier, including how to prepare it for first use.

## 3. Adding Essential Oils (Optional)

- Locate the aroma tray on the side of the humidifier.
- Add a few drops of your preferred essential oil onto the aroma pad within the tray.
- Close the aroma tray.



Figure 4: A hand is shown adding essential oil drops into the dedicated aroma tray located on the side of the humidifier, allowing for aromatherapy integration.

## OPERATING INSTRUCTIONS

---

The humidifier can be operated using the touch control panel on the unit or the included remote control.

### 1. Power On/Off

- Plug the power cord into a suitable electrical outlet.
- Press the **ON/OFF/SLEEP** button on the control panel or remote to turn the unit on or off.

## 2. Mist Modes (Warm/Cool Mist)

- Press the **WARM/COOL MIST** button to switch between warm mist and cool mist modes.
- Warm mist will typically reach 120°F within 5 minutes.

## 3. Mist Volume

- Press the **MIST VOLUME** button to cycle through low, medium, and high mist output settings.

## 4. Customize Humidity

- Press the **CUSTOMIZE HUMIDITY** button to set your desired humidity level (45%-95% RH). The unit will automatically adjust mist output to maintain this level.

## 5. Timer Function

- Press the **TIMER** button to set an operating time from 1 to 24 hours. The humidifier will automatically turn off when the set time expires.

## 6. Mood Light

- Press the **UV LAMP & COLOR LIGHT** button to activate or deactivate the mood lighting. Warm mist glows amber, and cool mist shines blue.

## 7. Sleep Mode

- Press and hold the **ON/OFF/SLEEP** button for 3 seconds to activate Sleep Mode. This will turn off all LED lights and operate the humidifier at a low, quiet setting.

# MAINTENANCE

---

Regular cleaning is essential for optimal performance and hygiene.

## 1. Daily Maintenance

- Empty and rinse the water tank daily.
- Wipe the inside of the tank with a soft cloth.

## 2. Weekly Cleaning

- Unplug the humidifier.
- Remove the water tank and empty any remaining water.
- Pour 1 cup (240ml) of white vinegar into the water tank and let it soak for 30 minutes to loosen mineral buildup.
- Gently scrub the inside of the tank and the ultrasonic atomizer with a soft brush or cloth.
- Rinse the tank thoroughly with clean water until the vinegar smell is gone.
- Wipe the exterior of the unit with a soft, damp cloth.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Lack of water; mineral buildup; mist outlet blocked.	Refill water tank; clean the ultrasonic atomizer; ensure mist outlet is clear.
Unusual odor	Stagnant water; new unit smell.	Clean the water tank and replace water; run the unit in a well-ventilated area for a few hours.
Water leakage	Tank not properly seated; overfilling.	Ensure the water tank is correctly placed; do not exceed the MAX fill line.
Unit not turning on	No power; power button not pressed.	Check power connection; press the ON/OFF/SLEEP button.

## SPECIFICATIONS

Feature	Detail
Brand	let'me
Model Name	HQ-JS2325WE
Special Features	Adjustable Humidity Control, Sleep Mode, 3 Mist Level Option, Aroma Diffuser, Auto Shut Off, Leakproof, Timer, Water Level Window
Color	White
Floor Area Coverage	500 Square Feet
Operation Mode	Automatic, Manual
Product Dimensions	7.48"D x 26.18"W x 7.48"H
Item Weight	7.89 pounds (3.59 Kilograms)
Room Type	Bedroom, Kids Room, Living Room, Yoga Room
Control Method	Remote, Touch
Water Tank Capacity	2.64 Gallons (10 Liters)
Maximum Mist Output (Cool)	300 mL/h
Maximum Mist Output (Warm)	500 mL/h

## WARRANTY AND SUPPORT

The let'me Humidifier Model HQ-JS2325WE comes with a standard manufacturer's warranty. For detailed warranty information, product support, or assistance with troubleshooting, please refer to the contact information provided in your product packaging or visit the official let'me website. Please retain your proof of purchase for warranty claims.