Marsail TZESD6N-N1-US

Marsail Electric Standing Desk (Model TZESD6N-N1-US) User Manual

Adjustable Height Home Office Desk

1. Introduction

Thank you for choosing the Marsail Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new adjustable height desk. Please read these instructions carefully before use and retain them for future reference.

Safety Information

- Ensure the desk is assembled by two people using the recommended tools and following the provided instructions.
- The desk supports a maximum weight of 176 lbs (80 kg). Do not overload the desk.
- Be cautious while operating the electric lifting mechanism. Keep fingers and other body parts away from moving parts during adjustments to prevent injury.
- Always ensure the desk is stable and not overloaded, especially at its maximum height of 46.7 inches.
- This product is designed for indoor use only.

2. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop (40x24 inches, Maple finish)
- Desk Frame (Steel)
- Electric Lifting Mechanism (Motor and Control Panel)
- Power Adapter and Cables
- Headphone Hook
- Storage Bag
- Cable Organizer
- Assembly Tools (Allen key, screws, etc.)
- User Manual

3. Assembly Instructions

The desk requires assembly by two people. All necessary tools are included. Follow the provided instructions for proper assembly. Ensure the desk is stable and not overloaded, especially at its maximum height of 46.7 inches.

Assembly Steps Overview

1. **Assemble the Frame:** Connect the crossbar to the lifting columns and attach the feet.
2. **Assemble the Desktop:** Secure the two desktop pieces together using the provided dowels and connectors.
3. **Attach the Desktop:** Mount the assembled desktop onto the frame, securing it with screws.
4. **Connect the Cables:** Connect the motor and control panel cables to the power adapter and secure them.
5. **Attach Accessories:** Install the storage bag, headphone hook, and cable organizer as desired.

For a detailed visual guide, please refer to the installation video below:

Video Description: This video provides a step-by-step guide on how to install the Marsail Electric Standing Desk, covering all assembly stages from unboxing to final setup.



Image Description: An overview image showing the various components of the electric standing desk laid out for assembly.

4. Operating Instructions

Height Adjustment

The Marsail Electric Standing Desk features a one-touch adjustment system, allowing you to easily switch between sitting and standing positions. The height range is from 27.5 inches to 46.7 inches.

- Use the **Up (^)** and **Down (v)** arrows on the control panel to manually adjust the desk height.
- The digital display will show the current height in inches.

Memory Presets

The desk allows you to save up to four custom height settings for quick adjustments.

1. Adjust the desk to your desired height using the Up/Down arrows.
2. Press the **'S'** button (Save) once. The display will show 'S-'.
3. Within 3 seconds, press the desired memory button (**1, 2, 3, or 4**). The display will show 'S-1', 'S-2', etc., confirming the height is saved.
4. To recall a saved height, simply press the corresponding memory button (**1, 2, 3, or 4**). The desk will automatically move to

that preset height.



Image Description: A close-up of the desk's control panel, highlighting the Up/Down arrows and the four memory preset buttons (1, 2, 3, 4).

Video Description: This video demonstrates the operation of the automatic standing desk, including manual height adjustments and using the memory preset functions.

5. Features

Spacious Desktop

The 40x24 inch desktop provides ample space for your work, study, gaming, or creative projects, ensuring a productive and organized workspace.



Image Description: An image illustrating the dimensions of the Marsail Electric Standing Desk, showing the 40-inch depth, 24-inch width, and adjustable height range.

Integrated Storage

Keep your workspace tidy with the included accessories:

- **Multifunctional Side Storage Pocket:** A double-layered pocket for organizing folders, notebooks, and office supplies, providing easy access without cluttering the desktop.
- **Headphone Hook:** Conveniently hang your headphones to keep them within reach and off the desk surface.
- **Cable Organizer:** Helps manage and route cables for a cleaner and safer workspace.



Image Description: The Marsail Electric Standing Desk featuring an attached side storage pocket, ideal for keeping documents and small office items organized.

Stable and Quiet Operation

The desk is engineered for maximum stability and quiet performance.

- **Wobble-Free Design:** Tested to ensure high levels of stability, minimizing wobble even at elevated heights.
- **Energy-Efficient Motor:** Features a quiet motor operating below 50 dB, moving smoothly at 2 inches per second. It is designed for reliable performance and has been tested for 50,000 lift cycles.



Image Description: An image illustrating the desk's stability, showing a spinning top on the desktop without wobbling during height adjustment.



Image Description: A visual representation of the desk's motor endurance, indicating it has undergone 50,000 cycles of rigorous testing for reliable performance.

6. Maintenance

To ensure the longevity and optimal performance of your Marsail Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Check Connections:** Periodically inspect all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables are neatly organized and not pinched or tangled, which could affect desk operation or cause damage.
- **Avoid Overloading:** Do not exceed the maximum weight capacity of 176 lbs (80 kg) to prevent strain on the motor and frame.

7. Troubleshooting

If you encounter any issues with your desk, refer to the following common troubleshooting steps:

- **Desk Not Moving:** Check if the power cable is securely plugged into both the desk and the wall outlet. Ensure there are no obstructions preventing movement.
- **Uneven Movement:** Ensure the desk is placed on a level surface. Check that all frame connections are tight and evenly secured.
- **Error Codes:** If the display shows an error code, consult the full troubleshooting section in the comprehensive manual (if provided separately) or contact customer support.
- **Noise During Operation:** A slight hum from the motor is normal. If you hear unusual or loud noises, ensure no cables or objects are interfering with the moving parts.

8. Specifications

Feature	Specification
Brand	Marsail
Model Number	TZESD6N-N1-US
Product Dimensions (D x W x H)	40"D x 24"W x 28"H
Desktop Size	40x24 inches
Minimum Height	27.5 Inches
Maximum Height	46.7 Inches
Color	Maple
Top Material Type	Engineered Wood
Base Material	Engineered Wood, Steel
Lifting Mechanism	Electric
Number of Height Positions	4 (Memory Presets)
Item Weight	40.06 Pounds
Maximum Load Capacity	176 lbs (80 kg)
Included Components	Headphone Hook, Storage Bag, Cable Organizer
Required Assembly	Yes (Recommended 2 people)

9. Warranty and Support

Warranty Information

This Marsail Electric Standing Desk comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage details and duration.

Customer Support

If you have any questions, require assistance with assembly, operation, or troubleshooting, or need to claim warranty service, please contact Marsail customer support through the retailer's platform or the official Marsail website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question