Redragon BK7114

Redragon BK7114 Low-Profile Wireless Computer Keyboard

INSTRUCTION MANUAL

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Redragon BK7114 Low-Profile Wireless Computer Keyboard. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: The Redragon BK7114 Low-Profile Wireless Keyboard in Steel Grey, featuring its full 98-key layout and the accompanying 2.4G USB dongle.

Key Features

- **Dual Wireless Connections:** Supports both Bluetooth and 2.4GHz wireless connectivity. Store up to 3 Bluetooth devices and 1 2.4G device for easy switching. Wired connection is for charging only.
- **Slim 98 Keys Layout:** A tactical 96% layout with low-profile keycaps, designed for a blend of style and functionality while saving desk space.
- **Whisper-Quiet Typing:** Equipped with premium scissor switches for a quiet typing experience, reducing noise distraction.
- **Seamless Win & Mac Switching:** A dedicated side button allows for quick and effortless toggling between

Windows and Mac operating systems.

- **Mixed Colors Design:** Features a unique mixed color keycap design (Steel Grey) to enhance your workspace aesthetics. Note: This model does not include backlighting.



Image: Visual representation of the keyboard's key features, including its dual wireless technology, 98-key layout, ultra-thin profile, and scissor key structure.

Setup

1. Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the keyboard to a USB power source using the provided charging cable. The wired connection is solely for charging purposes.

2. Connecting via 2.4GHz Wireless

1. Locate the 2.4G USB dongle (receiver) included with your keyboard.
2. Plug the USB dongle into an available USB port on your computer or device.

3. Ensure the keyboard's connection mode is set to 2.4G (refer to the operating section for mode switching). The keyboard should automatically connect to the dongle.

3. Connecting via Bluetooth

The keyboard supports connection to up to three Bluetooth devices.

1. Switch the keyboard to one of the Bluetooth modes (BT1, BT2, or BT3).
2. On your device (PC, laptop, tablet), enable Bluetooth and search for new devices.
3. Select "Redragon BK7114" from the list of available devices.
4. Follow any on-screen prompts to complete the pairing process.



Image: The Redragon BK7114 keyboard demonstrating its 2.4G+BT dual connectivity, shown wirelessly connected to both a laptop and a tablet.

Operating

Switching Between Devices (2.4G / BT1 / BT2 / BT3)

To switch between connected devices, use the dedicated function keys on the keyboard. Refer to the keyboard's layout for specific key combinations (e.g., Fn + 1/2/3 for Bluetooth, Fn + 4 for 2.4G).

Switching Between Windows and Mac Modes

The keyboard features a convenient side button or key combination to seamlessly switch between Windows and Mac operating system layouts. This adjusts the functionality of certain keys (e.g., Alt/Option, Win/Command) to match the respective OS.



Image: The Redragon BK7114 keyboard in a multi-device setup, highlighting its compatibility and the ease of switching between Windows and Mac operating systems.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For deeper cleaning, a can of compressed air can be used to remove debris from between the keys. Avoid using harsh chemicals or abrasive materials.

- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. Charge the keyboard when the battery indicator suggests low power.

Troubleshooting

- **Keyboard not connecting:**
  - Ensure the keyboard is charged.
  - For 2.4GHz, verify the USB dongle is securely plugged in and the keyboard is in 2.4G mode.
  - For Bluetooth, ensure Bluetooth is enabled on your device and the keyboard is in pairing mode (BT1/BT2/BT3). Try re-pairing the device.
  - Try connecting to a different USB port or device to rule out port/device issues.
- **Keys not responding:**
  - Check battery level.
  - Ensure the keyboard is properly connected to your device.
  - Clean any debris that might be stuck under the keycaps.
- **Lag or intermittent connection:**
  - Move the keyboard closer to the receiver/device.
  - Avoid interference from other wireless devices (e.g., Wi-Fi routers, other 2.4GHz devices).

Specifications

Feature	Specification
Brand	Redragon
Model Name	BK7114
Connectivity Technology	2.4Ghz, Bluetooth (BT)
Keyboard Description	Wireless 98 Keys Scissors Mechanism Keyboard
Key Switch Type	Scissor Mechanism
Layout	98 Keys (96% Practical Layout)
Keycap Profile	Low-Profile Slim
Compatible Devices	PC, Laptop, Tablet
Operating System Compatibility	Mac OS, Windows
Power Source	Battery Powered (1 Lithium Polymer battery included)
Item Weight	1.56 pounds
Package Dimensions	15.59 x 6.61 x 1.34 inches
Color	Steel Grey

Warranty and Support

For warranty information, technical support, or any inquiries regarding your Redragon BK7114 keyboard, please refer to the official Redragon website or contact Redragon customer service directly. Contact details can typically be found on the product packaging or the manufacturer's official support page.

Please retain your proof of purchase for warranty claims.

© 2024 Redragon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question