Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

K&F CONCEPT KF34.043U

K&F CONCEPT 9.1ft/2.8M Portable Extendable Photography Light Stand

Model: KF34.043U

1. Introduction

This manual provides detailed instructions for the safe and effective use of your K&F CONCEPT 9.1ft/2.8M Portable Extendable Photography Light Stand. Please read this manual thoroughly before operating the product and retain it for future reference.



Image 1.1: K&F CONCEPT 9.1ft/2.8M Portable Extendable Photography Light Stand.

2. Safety Information

- Ensure all locking mechanisms are securely fastened before attaching any equipment.
- Do not exceed the maximum load capacity of 8 kg (18 lbs).
- Place the stand on a stable, level surface to prevent tipping.
- Be aware of your surroundings when extending or collapsing the stand to avoid injury or damage.
- Avoid using the stand in strong winds or adverse weather conditions without proper stabilization (e.g., sandbags, not supplied).

3. Package Contents

Verify that all components are present upon unpacking:

- 1 x K&F CONCEPT 9.1ft/2.8M Portable Extendable Photography Light Stand

4. Product Features

- **Sturdy and Stable Construction:** Made of high-quality metal for enhanced stability and durability. Features a tripod base with an extension bar, collapsible long legs, and non-slip feet.
- **Extendable Adjustment:** Height adjustable from 112 cm (44 inches) to 280 cm (9.1 ft) with a special buckle design.
- **Wide Compatibility:** Equipped with a standard 1/4" screw stud at the top, adjustable 180 degrees. Compatible with various photography accessories such as strobe lights, webcams, cameras, softboxes, ring lights, and video lights.
- **Ultra-Portable Design:** Foldable design allows for quick breakdown into a compact size for easy transport and storage.



Image 4.1: Detailed view of the light stand's structural features.

Image 4.2: Illustration of the robust metal construction.

5. Setup

Follow these steps to set up your light stand:

1. **Unfold the Legs:** Gently open the support feet outwards until they are fully extended and stable.
2. **Secure the Base:** Support the center shaft with one hand and lock the bottom tripod knob to secure the legs in place.
3. **Adjust Height:** Loosen the quick-release fixtures on the shaft sections. Pull the center shaft up to the desired height.
4. **Lock Height:** Once the desired height is reached, twist the quick-release clips clockwise to securely fasten each section. Ensure all sections are tightly locked before mounting equipment.




Image 5.1: Visual guide for easy installation.

6. Operating

The light stand is designed for versatile use in various photography and videography scenarios.

6.1 Height Adjustment

The stand can be adjusted from a minimum height of 112 cm (44 inches) to a maximum height of 280 cm (9.1 ft). To adjust, loosen the twist-lock mechanisms on each section, extend or retract to the desired height, and then firmly tighten the locks.




Image 6.1: Height adjustment range and storage size.

6.2 Attaching Equipment

The top of the stand features a standard 1/4" screw stud. Attach your photography equipment (e.g., strobe light, webcam, camera, softbox, ring light) by screwing it onto the stud. Ensure the equipment is securely fastened.



Image 6.2: The 1/4" screw adapter for versatile applications.



Multi-purpose 1/4" Screws

1/4" threaded screws for taking pictures, mounting strobes, umbrellas, softboxes and other photographic equipment.

Note: When using heavy photographic equipment such as softboxes, strobes, etc., sandbags (not supplied) may be required to increase their stability.

Image 6.3: Multi-purpose 1/4" screws for various photographic equipment.

Note: When using heavy photographic equipment such as large softboxes or strobes, it is recommended to use sandbags (not supplied) on the legs to increase stability and prevent tipping.

6.3 Application Scenarios

The light stand is suitable for a wide range of applications, including:

- Live Streaming
- Outdoor Activities
- Photography Studio setups
- Commercial Shooting




Image 6.4: Various application scenarios for the light stand.

7. Maintenance

- Clean the stand regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- Inspect all locking mechanisms and screws periodically for tightness and wear. Tighten any loose components.
- Store the stand in a dry, cool place when not in use to prevent rust and damage.
- Avoid exposing the stand to extreme temperatures or humidity.

8. Troubleshooting

- **Issue: Stand feels unstable.**
  Solution: Ensure the legs are fully extended and the bottom tripod knob is securely locked. Verify that the stand is on a level surface. Consider using sandbags for additional stability, especially with heavy equipment.
- **Issue: Height adjustment sections slip.**
  Solution: Ensure all quick-release clips are tightened firmly after adjusting the height. Check for any debris or damage in the locking mechanisms.
- **Issue: Equipment does not attach securely to the 1/4" screw.**
  Solution: Confirm that your equipment has a compatible 1/4" thread. Ensure the screw is not stripped or damaged.

9. Specifications

Feature	Specification
Brand	K&F CONCEPT
Model Name	KF34.043U
Product Dimensions	40.16 x 3.54 x 3.54 inches (folded)
Item Weight	4.36 pounds (1.98 Kilograms)
Maximum Height	280 Centimeters (9.1 ft)
Minimum Height	112 Centimeters (44 inches)
Weight Limit	8 Kilograms (18 lbs)
Compatible Devices	Camera, Smartphone, Strobe Light, Webcams, Softbox, Ring Light, Video Light
Screw Type	Standard 1/4"

10. Warranty and Support

K&F CONCEPT photography light stand comes with a 2-year product warranty. If you encounter any problems or require assistance, please feel free to contact K&F CONCEPT customer support. They will provide a proper solution at the earliest opportunity.

For support, please visit the official K&F CONCEPT website or refer to the contact information provided with your purchase.

© 2024 K&F CONCEPT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCNTLYWR

More documents and user manuals: **https://manuals.plus/**