

[Manuals.plus](#) /

› [Emerio](#) /

› Emerio Filter Coffee Machine CME-116801 Instruction Manual

Emerio CME-116801



Emerio Filter Coffee Machine

MODEL: CME-116801

Introduction

Thank you for choosing the Emerio Filter Coffee Machine CME-116801. This compact and efficient coffee maker is designed to brew up to 5 cups (0.6 liters) of fresh filter coffee, perfect for individual use or small households. Featuring a removable permanent filter, anti-drip function, and automatic shut-off, it offers convenience and ease of use. Please read this instruction manual carefully before first use to ensure safe and optimal operation of your appliance.

Important Safety Instructions

- Always ensure the appliance is placed on a stable, flat, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- The hot plate remains hot after brewing. Avoid contact.
- Only use cold water for brewing.
- Do not open the lid during the brewing cycle.

Product Overview

Familiarize yourself with the components of your Emerio Filter Coffee Machine:



Figure 1: Full view of the Emerio Filter Coffee Machine with glass carafe.



Figure 2: Close-up of the removable permanent filter basket.



Figure 3: View of the anti-drip mechanism above the carafe.



Figure 4: Illuminated On/Off switch located on the side.

Main Components:

- Water Tank with Water Level Indicator
- Lid
- Filter Basket (with removable permanent filter)
- Glass Carafe (0.6L capacity)
- Hot Plate
- On/Off Switch (illuminated)
- Power Cord

Setup and First Use

1. **Unpacking:** Carefully remove the coffee machine from its packaging. Retain the packaging for future storage or disposal.

2. **Initial Cleaning:** Before first use, clean all removable parts (glass carafe, filter basket, permanent filter) with warm soapy water. Rinse thoroughly and dry.
3. **First Brew Cycle (without coffee):**
 - a. Fill the water tank with cold water up to the 'MAX' mark (0.6L).
 - b. Place the empty filter basket and permanent filter into their designated positions.
 - c. Place the empty glass carafe on the hot plate.
 - d. Plug the appliance into a suitable power outlet.
 - e. Press the On/Off switch. The indicator light will illuminate.
 - f. Allow the machine to complete a full brewing cycle with only water.
 - g. Discard the water and repeat this process 2-3 times to thoroughly clean the internal components and remove any manufacturing residues.
4. **Placement:** Place the coffee machine on a dry, stable, and heat-resistant surface, away from the edge of the counter and out of reach of children. Ensure adequate ventilation around the appliance.

Operating Instructions

Follow these steps to brew fresh coffee:

1. **Fill Water Tank:** Open the lid of the water tank. Fill the glass carafe with the desired amount of cold water (refer to the water level indicator on the carafe and the tank, marked for 2-5 cups). Pour the water from the carafe into the water tank. Do not exceed the 'MAX' fill line.
2. **Add Coffee Grounds:** Place the permanent filter (or a paper filter, if preferred) into the filter basket. Add the desired amount of ground coffee into the filter. A general guideline is one scoop (provided) per cup, but adjust to your taste. Close the lid securely.
3. **Position Carafe:** Ensure the empty glass carafe is correctly placed on the hot plate. The anti-drip mechanism will prevent coffee from dripping when the carafe is removed during brewing.
4. **Start Brewing:** Plug the power cord into a suitable electrical outlet. Press the illuminated On/Off switch. The indicator light will turn on, signaling that the brewing process has started.
5. **Brewing Process:** Water will heat up and drip through the coffee grounds into the carafe. The brewing process will complete automatically.
6. **Serve Coffee:** Once brewing is complete, the hot plate will keep the coffee warm. You can remove the carafe to pour coffee. The anti-drip function will temporarily stop the flow of coffee. Replace the carafe within 20 seconds to prevent overflow.
7. **Automatic Shut-off:** For safety and energy saving, the coffee machine will automatically shut off approximately 40 minutes after the brewing cycle is complete.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your coffee machine.

Daily Cleaning:

- Always unplug the appliance and allow it to cool completely before cleaning.
- Remove the glass carafe, filter basket, and permanent filter. Wash these parts in warm soapy water, rinse thoroughly, and dry. These parts are generally dishwasher safe, but hand washing is recommended for longevity.
- Wipe the exterior of the coffee machine with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.

- Do not immerse the main unit in water or any other liquid.

Descaling:

Mineral deposits from water can build up in your coffee machine over time, affecting performance and taste. Descale your machine regularly, depending on water hardness and frequency of use (e.g., every 2-4 weeks).

1. Prepare a descaling solution according to the descaler manufacturer's instructions, or use a mixture of white vinegar and water (e.g., 1 part vinegar to 2 parts water).
2. Pour the descaling solution into the water tank.
3. Place the empty carafe on the hot plate.
4. Run a brewing cycle with the descaling solution.
5. After the cycle, turn off the machine and let the solution sit in the carafe for about 15 minutes.
6. Discard the solution and rinse the carafe thoroughly.
7. Run at least two full brewing cycles with clean cold water to rinse out any remaining descaling solution.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	No power; water tank empty; carafe not in place.	Check power connection; fill water tank; ensure carafe is correctly positioned.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine.	Adjust coffee amount; use appropriate grind for filter coffee.
Coffee overflows from filter basket.	Too much coffee grounds; filter clogged; carafe removed too long.	Reduce coffee amount; clean filter; replace carafe quickly.
Machine leaks.	Water tank overfilled; components not properly seated; internal hose damage (rare).	Do not overfill; ensure all parts are correctly assembled. If persistent, contact customer support.
Brewing is slow.	Mineral buildup (scaling).	Perform a descaling cycle.

Specifications

Model: CME-116801

Brand: Emerio

Capacity: 0.6 Liters (up to 5 cups)

Power: 600 Watts

Voltage: 220-240V ~ 50/60Hz (Standard European voltage)

Dimensions (LxWxH): Approximately 16 x 23.6 x 28.9 cm

Weight: Approximately 880 grams

Features: Automatic Shut-off (40 min), Anti-drip function, Removable Permanent Filter, Water Level Indicator, BPA Free materials.

Color: Black

Warranty and Support

This Emerio product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details. For technical support, spare parts, or warranty claims, please contact your retailer or the Emerio customer service department. Keep your proof of purchase for warranty purposes.

For further assistance, you may visit the official Emerio website or contact their customer support channels as listed in your product documentation.

© 2025 Emerio. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.