

[Manuals.plus](#) /

› [WMARK](#) /

› WMARK NG-604KIT Hair Clipper & Trimmer Instruction Manual

WMARK NG-604KIT

WMARK NG-604KIT Hair Clipper & Trimmer Instruction Manual

Model: NG-604KIT

[Overview](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Specifications](#)

[Warranty & Support](#)

1. PRODUCT OVERVIEW

The WMARK NG-604KIT is a comprehensive grooming haircut kit that includes both a hair clipper (NG-132) and a detail trimmer (NG-314). Designed for precision and ease of use, this kit features powerful magnetic motors, long-lasting lithium-ion batteries, and a variety of cutting attachments to achieve diverse hair lengths and styles. The transparent housing allows for easy monitoring of internal components and battery status.



Image 1: WMARK NG-604KIT Hair Clipper and Trimmer Kit with charging stand and various accessories.

2. KEY FEATURES

- **Professional Clipper Blades:** The NG-132 clipper features a high carbon steel wedge blade with a ceramic moving blade, designed for self-sharpening and precision cutting through all hair types. It can be adjusted for zero-overlap. The NG-314 trimmer is equipped with a high carbon steel blade, gapped to approximately 0.1mm, and features R-angle processing to protect the skin.



Image 2: Detailed view of the NG-132 clipper blade (bottom) and NG-314 trimmer blade (top), showing their construction and gapping.

- **Cordless/Corded Operation:** Both devices can be used cordlessly or corded. The NG-132 clipper has a 2200mAh Li-ion battery providing up to 180 minutes of runtime after a 3-4 hour charge. The NG-314 trimmer has a 1200mAh Li-ion battery offering up to 210 minutes of runtime after a 3-4 hour charge.



Image 3: Digital display indicating battery charge levels for both the NG-132 clipper and NG-314 trimmer.

- **Multiple Cutting Lengths:** The NG-132 clipper includes 9 attachment combs (1mm, 3mm, 4.5mm, 6mm, 10mm, 13mm). The NG-314 trimmer comes with 3 attachment combs (1.5mm, 3mm, 4.5mm). Both can be used without combs for a close trim.
- **LED Display:** Both the clipper and trimmer feature a digital LED display that shows the remaining battery charge status.
- **Powerful and Quiet Motor:** The NG-132 clipper operates at 7000 RPM, and the NG-314 trimmer at 6500 RPM, ensuring efficient cutting for various hair types. The noise level is maintained below 60 dB for a quiet grooming experience.



Image 4: Visual representation of the motor speeds for the NG-132 clipper (7000RPM) and NG-314 trimmer (6500RPM).

- **Adjustable Taper Lever:** The clipper features an adjustable taper lever for customizing cutting lengths from a close cut to longer styles, facilitating blending and fading.
- **Dock Charging:** The kit includes a sleek USB-powered charging pod that serves as both a charging station and a stand for convenient storage.



Image 5: The charging dock for the WMARK NG-604KIT, illustrating the USB charging port and adapter connection.

3. SETUP GUIDE

3.1 Initial Charging

1. Before first use, fully charge both the clipper and trimmer.
2. Connect the USB charging cable to the charging stand and plug the adapter into a power outlet.
3. Place the clipper (NG-132) or trimmer (NG-314) onto the charging stand. Ensure the device is properly seated.
4. The LED display will indicate charging progress. A full charge takes approximately 3-4 hours.

3.2 Attaching Guide Combs

1. Select the desired guide comb for your preferred cutting length.
2. Align the comb with the blade and push it firmly until it clicks into place.
3. To remove, gently pull the comb away from the blade.

3.3 Blade Adjustment (Clipper NG-132)

- The taper lever on the side of the NG-132 clipper allows for fine adjustment of cutting length without changing guide combs.
- Move the lever up for a shorter cut and down for a longer cut. This is useful for blending and fading.

4. OPERATING INSTRUCTIONS

4.1 General Hair Cutting

1. Ensure the device is fully charged or connected to power.
2. Attach the appropriate guide comb for the desired hair length.
3. Turn on the clipper/trimmer using the power switch.
4. Hold the device with the blade flat against the hair and move it slowly against the direction of hair growth.
5. For blending, use the taper lever on the NG-132 clipper to gradually adjust the cutting length.

4.2 Detail Trimming (NG-314)

- The NG-314 trimmer is ideal for precise lines, edging, and detailing around the neckline, sideburns, and beard.
- Use without a comb for a very close trim (0.1mm gapped).
- Hold the trimmer at a slight angle and use light pressure for clean lines.

Your browser does not support the video tag.

Video 1: Demonstration of the WMARK NG-604KIT in use for hair cutting and trimming, showcasing its features and performance.

5. MAINTENANCE

5.1 Cleaning the Blades

1. After each use, turn off the device and remove any attached guide combs.
2. Use the provided cleaning brush to remove loose hairs from the blades and the internal mechanism.
3. For thorough cleaning, the blades can be carefully detached (refer to specific blade removal instructions if provided in packaging).

5.2 Oiling the Blades

- Regular oiling ensures optimal performance and longevity of the blades.
- Apply a few drops of clipper oil (typically included or recommended by manufacturer) to the teeth and friction points of the blades.

- Turn on the device for a few seconds to distribute the oil evenly, then wipe off any excess.

5.3 Storage

- Store the clipper and trimmer in a dry, cool place, away from direct sunlight and moisture.
- Use the charging stand for organized storage and to keep the devices ready for use.

6. TROUBLESHOOTING

- **Device not turning on:** Ensure the battery is fully charged. If using corded, check the power connection.
- **Poor cutting performance:** Clean the blades thoroughly to remove hair buildup. Oil the blades as per maintenance instructions. Ensure guide combs are correctly attached.
- **Excessive noise or vibration:** This may indicate a need for blade cleaning and oiling. If the issue persists, contact customer support.

7. PRODUCT SPECIFICATIONS

Model Name	WMARK NG-604KIT
Clipper Model	NG-132
Trimmer Model	NG-314
Power Source	Battery Powered (Cordless/Corded)
Battery Type	Lithium Ion
Clipper Battery Capacity	2200mAh
Trimmer Battery Capacity	1200mAh
Clipper Runtime	Up to 180 minutes
Trimmer Runtime	Up to 210 minutes
Clipper Motor Speed	7000 RPM
Trimmer Motor Speed	6500 RPM
Blade Material	High Carbon Steel (Clipper & Trimmer), Ceramic (Clipper Moving Blade)
Minimum Cutting Length	1mm (Clipper), 0.1mm (Trimmer without comb)
Maximum Cutting Length	13mm (Clipper with comb)
Product Dimensions	24 x 15.8 x 8 cm
Item Weight	990 g
Country of Origin	China

8. WARRANTY & SUPPORT

The WMARK NG-604KIT comes with a 12-month quality warranty against defects in materials and workmanship from the

date of original purchase (invoice required). This warranty does not cover intentional or unintentional damage caused by the user.

To initiate a warranty claim, contact customer service at WARRANTY@wmarkindia.in with a clear description of the problem, associated pictures, and a copy of your original invoice. Upon verification, the company will, at its discretion, repair or exchange the product. Customers are responsible for the cost of transporting the product to the service center, while the company will cover the return transport cost if a repair or exchange is necessary.

For further information or assistance, please refer to the product detail page on Amazon.in or contact the importer, SAAS Consumer Goods.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question