

[Manuals.plus](#) /

› [Compustar](#) /

› [Compustar CS935-AS 1-Way AP Alarm & Starter Kit G17 User Manual](#)

Compustar CS935-AS

Compustar CS935-AS 1-Way AP Alarm & Starter Kit G17 User Manual

Model: CS935-AS | Brand: Compustar

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Compustar CS935-AS 1-Way AP Alarm & Starter Kit G17. Please read this manual thoroughly before using the product to ensure proper function and safety. This system is designed to enhance vehicle security and convenience with features like remote start, keyless entry, and a robust alarm system.

WHAT'S INCLUDED

The Compustar CS935-AS kit includes the following components:

- 2 x 1WG17R-AM 1-Way G17 AM Remotes
- 1 x ANT-AP 1-Way AP Antenna
- 1 x CM900-AS Remote Start & Security Control Module
- 1 x Shock Sensor II Dual-Stage Impact and Tilt Sensor
- 1 x Theft-Deterrent LED Blue Security LED
- 1 x 105+dB Alarm Siren



Figure 1: CompuStar 1-Way G17 AM Remote. This remote features buttons for lock, unlock, trunk release, and remote start on its side.



Figure 2: CompuStar CM900-AS Remote Start & Security Control Module. This is the central processing unit for the alarm and remote start system.



Figure 3: Compustar 105+dB Alarm Siren. This component emits a loud sound when the alarm is triggered.

SPECIFICATIONS

| Feature | Detail |
|-------------------------|------------------------------------------------------------------------------|
| Brand | Compustar |
| Model Number | CS935-AS |
| Compatible Devices | Cars, Trucks, SUVs, and Vans (may require additional vehicle-specific parts) |
| Noise Level (Siren) | 105 Decibels |
| Remote Control Included | Yes (2 x 1-Way Remotes) |
| Security Features | Dual-Stage Shock/Impact Sensor, Tilt Sensor, Starter-Kill, Alarm Siren |
| Connectivity | 1-Way AP Antenna |
| Item Weight | 10 Pounds |
| UPC | 840127710624 |

SETUP AND INSTALLATION

Installation of the Compustar CS935-AS system typically requires professional expertise due to complex vehicle wiring and module programming. It is recommended to have this system installed by an authorized Compustar dealer.

The system may require additional parts specific to your vehicle for full functionality. Ensure all necessary components are acquired before beginning installation.

For programming the Blade module and controller, refer to the following video:

Your browser does not support the video tag.

Video 1: IdataLink BLADE Remote Start/Security Bypass Module Flashing. This video demonstrates the process of flashing and updating the Blade module and Compustar controller using a computer and the ADS-USB cable. It covers creating an account, connecting hardware, selecting vehicle details, and configuring features.

OPERATING INSTRUCTIONS

The Compustar 1-Way G17 AM Remote provides convenient control over your vehicle's security and remote start functions. All control buttons are located on the side of the remote.



Figure 4: Front view of the Compustar 1-Way G17 AM Remote, showing the display and side buttons.

Remote Functions:

- **Lock/Arm:** Press the (lock) button once. The remote will display "LOCK" or "ARM" and chirp to confirm the command.
- **Unlock/Disarm:** Press the (unlock) button once. The remote will display "UNLOCK" or "DISARM" and chirp to confirm.
- **Trunk Release:** Press and hold the (trunk) button for three full seconds. The remote will display "TRUNK" or "OPEN" to confirm.
- **Remote Start:** Press and hold the (remote start) button for three full seconds. The remote will display "REMOTE START" and then "START" with a spinning icon to indicate successful engine start. The display will also show the remaining run time.

Driving Away After Remote Start:

1. Unlock the vehicle using the remote.
2. Enter the vehicle.
3. Insert the key into the ignition and turn it to the "ON" or "RUN" position (two clicks forward).
4. Apply the brake pedal. The remote start system will disengage, and the vehicle will now be operating under key control.

Note: *If the brake pedal is pressed before the key is turned to the "ON" position, the vehicle may shut off. In this case, simply start the vehicle with the key as normal.*

For a visual demonstration of the remote's basic operation, please watch the following video:

Your browser does not support the video tag.

Video 2: Compustar Prime T9 Operation. This video demonstrates the basic functions of a Compustar remote, including locking, unlocking, trunk release, and remote engine start. It also shows the process of taking over the vehicle after a remote start.

MAINTENANCE

To ensure the longevity and optimal performance of your Compustar CS935-AS system, consider the following maintenance tips:

- **Remote Battery:** Replace the remote control battery as needed. Refer to the remote's specific instructions for battery type and replacement procedure.
- **System Checks:** Periodically test all functions of your alarm and remote start system to ensure they are working correctly.
- **Professional Inspection:** It is recommended to have your system inspected by an authorized Compustar dealer annually, especially if you experience any issues or after any vehicle service.
- **Cleaning:** Keep the remote control clean and dry. Avoid exposing the control module or antenna to excessive moisture or extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Compustar CS935-AS system, try the following basic troubleshooting steps:

- **Remote Not Responding:** Check the remote control battery. If the battery is low or dead, replace it. Ensure you are within the operating range of the system.
- **Remote Start Failure:** Ensure all vehicle doors, hood, and trunk are closed. Check if the vehicle is in park (for automatic transmissions) or if the reservation mode is properly set (for manual transmissions). Verify that the vehicle's battery is charged.
- **Alarm Triggering Randomly:** The dual-stage shock/impact sensor sensitivity might be too high. Consult an authorized installer to adjust the sensor settings.
- **No Confirmation from Remote:** This could indicate a range issue or interference. Try operating the remote closer to the vehicle.

For persistent issues, contact your authorized Compustar dealer for professional diagnosis and repair.

WARRANTY AND SUPPORT

Your Compustar CS935-AS system comes with the following warranty coverage:

- **Remote Warranty:** 1-Year Remote Warranty
- **System Warranty:** Limited Lifetime System Warranty

- **Manufacturer Warranty:** 1-Year Manufacturer Warranty

Please retain your proof of purchase for warranty claims. Warranty terms and conditions may vary. For detailed warranty information or technical support, please contact your authorized Compustar dealer or visit the official Compustar website.