

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Wintem](#) /

› Wintem Arctic Cooling Fan User Manual

## Wintem 8056819047660

# Wintem Arctic Cooling Fan User Manual

Model: 8056819047660

## INTRODUCTION

---

Thank you for choosing the Wintem Arctic Cooling Fan. This evaporative cooler is designed to provide efficient and quiet cooling for your indoor environment. This manual provides important information regarding the safe operation, setup, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using this appliance:

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the appliance with a damaged cord or plug.
- Keep the appliance away from heat sources and direct sunlight.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Always unplug the appliance before cleaning, filling, or performing maintenance.
- Do not allow children to operate the appliance without supervision.
- Place the appliance on a stable, level surface.
- Do not block air inlets or outlets.

## PRODUCT OVERVIEW

---

The Wintem Arctic Cooling Fan is a portable evaporative cooler featuring an 80W motor, a 5-liter water tank, and multiple control options for optimal comfort.



Image: The Wintem Arctic Cooling Fan, a black tower unit with a visible water level indicator, shown alongside its white remote control. The unit is on wheels, indicating portability.



Image: Diagram highlighting key features: a 15-hour cyclic timer, portability with included wheels, and 80W power output. The main unit is shown with air flowing from its side.

## Components:

- Main Unit (with integrated water tank and control panel)
- Remote Control
- Power Cord
- Wheels (pre-installed for portability)

## SETUP

---

### 1. Unpacking:

Carefully remove the cooling fan from its packaging. Inspect the unit for any signs of damage. Retain the packaging for future storage or transport.

## 2. Placement:

Place the cooling fan on a firm, level surface. Ensure there is adequate space around the unit for proper airflow (at least 20 cm from walls or furniture).

## 3. Filling the Water Tank:

1. Locate the water tank access point, typically at the bottom rear or side of the unit.
2. Pull out the water tank or open the filling cap.
3. Fill the tank with clean, cool water. The tank has a 5-liter capacity with a 4-liter net capacity. Do not exceed the "MAX" fill line. For enhanced cooling, you may add ice packs (2 ice forms included) to the water tank.
4. Securely close the water tank or replace the cap.



Image: An internal diagram showing the water tank (5L capacity, 4L net) and the cooling mechanism, with an arrow indicating the upward flow of cool air. Two ice pack forms are also depicted.

## 4. Power Connection:

Plug the power cord into a standard electrical outlet. Ensure the outlet is easily accessible.

## OPERATING INSTRUCTIONS

The Wintem Arctic Cooling Fan can be operated using either the touch control panel on top of the unit or the included remote control.




Image: A close-up of the black touch screen control panel with various function icons (Time, Swing, Mode, Cool, Speed, On/Off) illuminated in red. The white remote control is shown next to it.

### Control Panel / Remote Control Functions:

- **On/Off Button:** Press to turn the unit on or off.
- **Speed Button:** Cycles through three fan speeds: Low, Medium, and High.
- **Mode Button:** Selects between three ventilation modes:
  - **Normal:** Constant airflow at the selected speed.
  - **Natural:** Simulates natural breeze with varying fan speeds.

- **Night:** Operates at a lower, quieter speed for undisturbed sleep.
- **Cool Button:** Activates the evaporative cooling function. Ensure the water tank is filled.
- **Swing Button:** Activates or deactivates the oscillation function, allowing the air to be distributed across a wider area.
- **Timer Button:** Sets the cyclic timer for automatic shut-off, up to 15.5 hours. Press repeatedly to adjust the desired time interval.

## 3 Modalità di Ventilazione



Image: An illustration demonstrating the three ventilation modes: Normal, Natural, and Night. The diagram shows air circulation within a room, with the fan positioned to cool the space.

### Quiet Operation:

The Wintem Arctic Cooling Fan is designed for quiet operation, with a sound power level of 50.2 dB(A), ensuring a calm and comfortable environment.

# Massima freschezza, minimo rumore.



Image: A graphic illustrating the low noise level of 50.2 dB(A) and the three speed settings: Low, Medium, and High, with the fan unit in the background.

## MAINTENANCE

---

Regular maintenance ensures the longevity and efficient operation of your cooling fan.

### 1. Cleaning the Exterior:

Before cleaning, always unplug the appliance. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.

### 2. Cleaning the Water Tank:

To prevent mold and mildew, clean the water tank regularly, especially if the unit is not used for extended periods.

1. Unplug the unit.
2. Remove the water tank.

3. Empty any remaining water.
4. Clean the tank with a mild detergent and water. Rinse thoroughly.
5. Allow the tank to air dry completely before reinserting it into the unit.

### 3. Storage:

If storing the unit for a long period, ensure the water tank is empty and clean. Store the unit in a cool, dry place, preferably in its original packaging.

## TROUBLESHOOTING

---

If you encounter issues with your Wintem Arctic Cooling Fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Power button not pressed.	Check if the power cord is securely plugged into a working outlet. Press the On/Off button.
No cool air.	Water tank is empty; Cool function not activated.	Fill the water tank. Press the "Cool" button on the control panel or remote.
Weak airflow.	Air inlets/outlets blocked; Fan speed set too low.	Ensure nothing is obstructing the air vents. Increase the fan speed.
Unusual noise.	Unit not on a level surface; Internal component issue.	Place the unit on a stable, level surface. If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact customer support.

## SPECIFICATIONS

---

Detailed technical specifications for the Wintem Arctic Cooling Fan:

Feature	Specification
Brand	Wintem
Model Number	8056819047660
Dimensions (L x W x H)	22 x 24 x 53 cm
Weight	4.2 Kilograms
Power	80 Watts
Voltage	20 Volts
Water Tank Capacity	5 Liters (4 Liters net)
Noise Level	50.2 dB(A)
Control Type	Touch Screen, Remote Control
Special Features	Cyclic Timer, Portable with Wheels

Feature	Specification
Material	Plastic



Image: A diagram showing the dimensions of the Wintem Arctic Cooling Fan: 53 cm height, 22 cm width, and 24 cm depth.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

Information regarding spare parts availability is currently unavailable. For any service or repair needs, please contact authorized service personnel.

