

[Manuals.plus](#) /

› [Camelion](#) /

› Camelion Rechargeable Camping Fan with LED Light User Manual

Camelion OF433

Camelion Rechargeable Camping Fan with LED Light User Manual

Model: OF433

INTRODUCTION

Thank you for purchasing the Camelion Rechargeable Camping Fan with LED Light, Model OF433. This versatile 2-in-1 device is designed to provide both cooling airflow and adjustable illumination for your outdoor and indoor activities. Please read this manual thoroughly before use to ensure proper operation, maintenance, and safety.

SAFETY INSTRUCTIONS

To prevent injury or damage to the product, always follow these basic safety precautions:

- Do not immerse the fan or LED light in water or other liquids.
- Keep out of reach of children and pets.
- Do not block the fan blades or air vents during operation.
- Use only the provided USB-C cable for charging.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Avoid exposing the device to extreme temperatures, direct sunlight, or high humidity.
- Ensure the fan is placed on a stable, flat surface when using the tripod.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Camping Fan Unit
- 1 x Detachable LED Light
- 1 x Power Base

- 1 x Tripod
- 1 x USB-C Cable (31.5 in / 80 cm)
- 1 x Waterproof Pouch
- 1 x User Guide

Camelion

ITM. / ART. 1834925

Rechargeable Camping Fan with LED Light Ventilateur de camping rechargeable avec lampe à DEL



INCLUDES

- 1 x Fan
- 1 x LED Light
- 1 x Power Pack
- 1 x Tripod
- 1 x USB-C cable 31.5 in / 80 cm
- 1 x Waterproof Pouch
- 1 x User Guide

COMPREND

- 1 x Ventilateur
- 1 x Lampe à DEL
- 1 x Bloc d'alimentation rechargeable
- 1 x Trépied
- 1 x Câble USB-C 80 cm / 31,5 po
- 1 x Pochette étanche
- 1 x Guide de l'utilisateur

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including
interference that may cause undesired operation.

Cet appareil est conforme à la partie 15 des règles de la FCC.
L'utilisation est sujette aux deux conditions suivantes :
(1) cet appareil ne peut causer d'interférences néfastes, et
(2) cet appareil doit accepter toute interférence reçue, y compris
les interférences qui peuvent causer des activités non désirées.

CAN ICES-3(B) / NMB-3(B)



Image: Back of the product packaging illustrating the included components such as the fan, LED light, tripod, and cables.

SETUP

1. **Attach Tripod:** Screw the tripod securely into the threaded hole at the bottom of the fan unit. Ensure it is stable.
2. **Attach LED Light:** The LED light has an integrated magnetic base. It can be attached directly to the center of the fan's front grille or used independently.
3. **Charging:** Before first use, fully charge the fan and LED light. Refer to the "Charging" section for details.






Image: Front of the product packaging displaying the assembled fan with its tripod and the detachable LED light, highlighting its dual functionality.

OPERATING INSTRUCTIONS

Fan Operation

The fan features three speed settings and an adjustable direction.

- **Power On/Off:** Press the fan power button (located on the side of the fan unit) to turn the fan on or off.
- **Adjust Fan Speed:** While the fan is on, press the fan power button repeatedly to cycle through the three fan speeds (Low, Medium, High).
- **Adjust Airflow Direction:** Manually pivot the fan head to direct airflow as desired.

LED Light Operation

The LED light offers adjustable brightness and color temperature.

- **Power On/Off:** Double-tap the light switch button (located on the LED light unit) to turn the light on or off.
- **Adjust Color Temperature:** While the light is on, single-tap the light switch button to cycle between Warm White and Cool White color temperatures.
- **Progressive Dimming:** While the light is on, press and hold the light switch button to progressively dim or brighten the light. Release the button when the desired brightness is reached.


Dimmable Light Modes
Modes d'éclairage réglables



Cool White
Blanc froid



Warm White
Blanc chaud



See inside for warranty and safety precautions.
Voir la garantie et les mesures de sécurité à l'intérieur.

www.camelionna.com



1-833-990-2624 (English, French)
Monday - Friday 9 am to 5 pm
Eastern Standard Time

1-833-990-2624 (anglais, français)
Lundi au vendredi 9 h à 17 h
Heure de l'Est



Camelion North America Inc.
2572 Daniel-Johnson Boulevard | 2nd Floor
Laval, QC, H7T 2R3 Canada

Camelion Amérique du Nord Inc.
2572, boulevard Daniel-Johnson | 2^e étage
Laval, QC, H7T 2R3 Canada

10271

MODEL N° / N° DE MODÈLE OF433

ITM. / ART. 1834925



6 79436 20065 2

MADE IN CHINA
FABRIQUÉ EN CHINE

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca

* faisant affaire au Québec sous
le nom des Entrepôts Costco

Image: Side of the product packaging detailing the control buttons for both the fan and the LED light, along with illustrations of the Cool White and Warm White light modes.

CHARGING

The Camelion Camping Fan and LED Light are powered by a rechargeable Li-ion battery. They can be charged via the included USB-C cable.

1. Connect the USB-C end of the cable to the USB-C input port on the fan unit or the LED light unit.
2. Connect the USB-A end of the cable to a compatible USB power adapter (not included), power bank, or computer USB port.
3. The charging indicator light will illuminate during charging and change color or turn off when fully charged.
4. **Note:** The fan can also be operated while connected to an external USB power source.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your device.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fan and LED light. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, preferably in the provided waterproof pouch. Ensure the battery is partially charged before storage to prolong battery life.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Recharge the device at least once every three months if not in regular use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan/Light does not turn on.	Battery is depleted.	Charge the device using the USB-C cable.
Fan speed is weak.	Low battery level.	Recharge the device.
LED light flickers or is dim.	Low battery level.	Recharge the device.
Device not charging.	Faulty USB cable or power adapter.	Try a different USB-C cable or power adapter. Ensure connections are secure.

If the problem persists after trying the above solutions, please contact Camelion customer support.

SPECIFICATIONS

Feature	Detail
Model Number	OF433
Battery Type	Rechargeable Li-ion battery
USB Input	USB-C 5V 2A
Fan Speeds	3 (Low/Medium/High)

Feature	Detail
Light Dimmability	Progressive dimming
LED Color Temperature	Warm White / Cool White
Net Weight	1.6 lb / 730 g
Dimensions (approx.)	14.06 in (Height) x 6.6 in (Width) x 6.73 in (Depth)
Blade Material	Plastic
Number of Blades	3




Image: Side of the product packaging displaying a table of specifications including battery type, USB input, light dimmability, and net weight, along with a diagram showing product dimensions.

For warranty information or technical support, please visit the official Camelion website or contact their customer service directly.

Website: www.camelionna.com

Phone: 1-833-860-2824 (Monday-Friday, 9 AM - 5 PM EST)

Place of Business: Camelion North America Inc., 2572 Deniel - Johnson Boulevard | 2nd Floor Laval QC, H7T 2R3
Canada

UPC: 0679436200652

