

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Wisdomlit](#) /

› [Wisdomlit 3-in-1 Bubble Fog Machine User Manual](#)

Wisdomlit QB-807RF

Wisdomlit 3-in-1 Bubble Fog Machine User Manual

MODEL: QB-807RF

1. Introduction

Thank you for choosing the Wisdomlit 3-in-1 Bubble Fog Machine. This versatile 400W machine is designed to create three distinct effects: vibrant colorful bubbles, enchanting fog bubbles, and continuous fog. It is perfect for enhancing the atmosphere at various events such as birthday parties, Halloween celebrations, weddings, and stage performances. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure you get the most out of your machine.



Image: The Wisdomlit 3-in-1 Bubble Fog Machine in operation, generating a large volume of bubbles and a layer of fog.

2. Important Safety Information

WARNING:

- Bubble solution and fog liquid are **NOT INCLUDED** with this machine. Please purchase both types of liquid separately from reputable suppliers.
- Do not leave bubble solution or fog liquid in the tanks when the machine is not in use for extended periods. Always drain and clean the tanks after each use to prevent residue buildup and ensure longevity.
- Keep the machine away from children and pets.
- Ensure proper ventilation when operating the machine.
- Do not block the ventilation openings.
- Only use liquids specifically designed for bubble and fog machines.

3. What's in the Box?

Please check the contents of your package to ensure all items are present:

WHAT'S IN THE BOX?



1 x Bubble Fog Machine



1 x Gift Box

1 x Replacement Fuse
(125V/5A)



1 x Remote Control
(CR2032 Button Cell Battery)



1 x Measuring Cup
(16.9 Fl Oz / 500 ml)



2-Pack
Bubble Solution Concentrate
(2.7 fl oz/pack)

NOTE: Please dilute concentrated bubble solution with water before use



1-Pack
Fog Fluid Concentrate
(3.38 fl oz/pack)

NOTE: Please dilute concentrated fog fluid with water before use



1 x User Manual



Image: A visual representation of the items included in the product packaging.

- 1 x Wisdomlit Bubble Fog Machine
- 1 x Wireless Remote Control (requires 1 x 3V, CR2032 button cell battery, included)
- 1 x Replacement Fuse (125V/5A)
- 1 x Measuring Cup (16.9 Fl Oz / 500 ml)
- 2-Pack Bubble Solution Concentrate (2.7 Fl Oz / pack) -*Note: Please dilute concentrate with water before use.*
- 1-Pack Fog Fluid Concentrate (3.38 Fl Oz / pack) -*Note: Please dilute concentrate with water before use.*
- 1 x User Manual

4. Setup Instructions

Follow these steps to set up your Wisdomlit Bubble Fog Machine:




1. Fill fog liquid tank with fog juice. (Not Included, 10.5 Fl Oz / 310 ml)



2. Pour bubble solution into bubble liquid tank. (Not Included, 18.6 Fl Oz / 550 ml)



3. Plug in the power outlet and turn on the power switch.



4. Warm-up time is 3 - 5 minutes, red indicator will be off when fully heated.



5. Push the function buttons or remote control to activate bubble fogger.



6. Discharge all the liquid, clean their tanks when not in use.

Image: A visual guide illustrating the six steps for easy setup and cleaning of the machine.

1. **Fill Fog Liquid Tank:** Locate the fog liquid tank (smaller tank). Carefully pour fog fluid (not included) into the tank. The capacity is 10.5 Fl Oz (310 ml).
2. **Fill Bubble Solution Tank:** Locate the bubble solution tank (larger tank). Carefully pour bubble solution (not included) into the tank. The capacity is 18.6 Fl Oz (550 ml).
3. **Power Connection:** Plug the machine into a standard power outlet and turn on the power switch located on the machine.
4. **Warm-up:** The machine requires 3 to 5 minutes for initial warm-up. A red indicator light will illuminate during this process. The red light will turn off when the machine is fully heated and ready for use.

5. Operating Instructions

The Wisdomlit Bubble Fog Machine offers three distinct effects, controllable via the machine's panel or the included wireless remote control.

WIRELESS REMOTE CONTROL

with Timer Settings



Image: The wireless remote control displaying its various buttons for controlling bubble, fog bubble, and fog modes, along with timer settings.

5.1. Control Panel Operation

Once the machine is warmed up (red light off), you can press the corresponding buttons on the machine's control panel to activate the desired effect:

- **BUBBLE:** Activates only bubble generation.
- **FOG BUBBLE:** Activates both bubble and fog generation simultaneously.
- **FOG:** Activates only fog generation.

5.2. Wireless Remote Control Operation

The wireless remote control allows you to operate the machine from approximately 40 feet (12 meters) away (without obstacles). The remote requires 1 x 3V, CR2032 button cell battery (included).

- **ON/OFF Button:** Press to turn the machine's effects on or off.
- **Bubble Button:** Activates only bubble generation.
- **Fog Bubble Button:** Activates both bubble and fog generation.

- **Fog Button:** Activates only fog generation.
- **Timer Settings:** The remote features integrated timer buttons to set duration and interval for the effects.

Timer Settings Details:

Mode	Duration Options	Interval Options
Bubble / Fog Bubble	30s, 60s, 180s, 300s	10s, 30s, 60s, 90s
Fog	180s, 300s	60s, 90s

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your Wisdomlit Bubble Fog Machine. The machine is designed for easy cleaning.

1. **Drain Liquids:** After each use, or if the machine will not be used for an extended period, ensure all bubble solution and fog liquid are drained from their respective tanks. The machine features individual drain outlets for each tank.
2. **Clean Tanks:** Rinse the tanks thoroughly with clean water. For best results, you can run a small amount of distilled water through the machine to clear any internal residue, especially for the fog system.
3. **Wipe Exterior:** Clean the exterior of the machine with a damp cloth. Do not use abrasive cleaners or immerse the machine in water.
4. **Storage:** Store the machine in a cool, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter issues with your Wisdomlit Bubble Fog Machine, please refer to the following common troubleshooting steps:

- **No Power / Machine Not Turning On:**
 - Ensure the power cord is securely plugged into both the machine and a working power outlet.
 - Check the power switch on the machine.
 - Verify the power outlet is functional by plugging in another device.
 - Check the fuse. A replacement fuse is included in the box.
- **No Bubbles / No Fog:**
 - Ensure the machine has completed its warm-up cycle (red light off).
 - Check that the respective liquid tanks (bubble solution or fog fluid) are filled to an adequate level.
 - Confirm you are pressing the correct button on the machine or remote for the desired effect (Bubble, Fog Bubble, or Fog).
 - For remote control issues, check the battery.
- **Low Output of Bubbles / Fog:**
 - Ensure the tanks are filled with the correct type and concentration of liquid.
 - Perform a thorough cleaning of the machine, especially the internal pathways, as residue buildup can reduce output.
 - Allow sufficient warm-up time.

If the problem persists after attempting these steps, please contact customer support.

8. Product Specifications

Detailed specifications for the Wisdomlit 3-in-1 Bubble Fog Machine:

LARGER & METAL HOUSING
Create the Exceptional Party with Magical Fog Bubbles

18.6 fl oz / 550 ml
Bubble Liquid Tank Capacity
= Use Time Up To **1 Hour**

10.5 fl oz / 310 ml
Fog Liquid Tank Capacity
= Use Time Up To **2 Hours**

19.3cm/7.59inch
34.4cm/13.54inch
23.1cm/9.09inch

Only Bubbles

3 in ONE
Colorful Bubbles Fog Bubbles Continuous Fog

Only Fog

Image: A visual representation of the machine's dimensions and liquid tank capacities.

Feature	Detail
Model Number	QB-807RF
Power	400W
Bubble Liquid Tank Capacity	550 ml (18.6 Fl Oz) - Up to 1 hour use time
Fog Liquid Tank Capacity	310 ml (10.5 Fl Oz) - Up to 2 hours continuous use time
Warm-up Time	3-5 minutes

Feature	Detail
Control Method	On-board buttons, Wireless Remote Control
Remote Control Range	Approx. 40 feet (12 meters)
Material	Durable Metal Housing
Color	Black
Dimensions (L x W x H)	34.39 x 19.28 x 23.09 cm (approx. 13.54 x 7.59 x 9.09 inches)
Recommended Age	3 years and up
Care Instructions	Wipe with a damp cloth

9. Warranty Information

For specific warranty details regarding your Wisdomlit 3-in-1 Bubble Fog Machine, please refer to the warranty card included with your purchase or contact the seller/manufacturer directly. Warranty terms and conditions may vary based on region and retailer.

10. Customer Support

If you have any questions, require technical assistance, or need further support regarding your Wisdomlit Bubble Fog Machine, please contact the seller through your purchase platform or refer to the manufacturer's official website for contact information.

