

[Manuals.plus](#) /

> [CHENYANENY](#) /

> Instruction Manual for CHENYANENY Power and Volume Button Replacement Kit for Samsung Galaxy S21 Ultra 5G SM-G998

CHENYANENY SM-G998

Instruction Manual

CHENYANENY Power and Volume Button Replacement Kit

PRODUCT OVERVIEW

This product is a replacement kit containing 10 sets of power and volume control buttons designed for the Samsung Galaxy S21 Ultra 5G SM-G998. These parts are intended to replace broken, unresponsive, or damaged original buttons, restoring full functionality to your device.



Image: The replacement power and volume buttons, shown in black.

IMPORTANT SAFETY INFORMATION

Working with electronic components requires caution. Please observe the following:

- Always disconnect power from the device before beginning any repair.
- Use appropriate tools to avoid damaging sensitive components.
- Handle parts carefully to prevent electrostatic discharge (ESD) damage.
- Keep small parts away from children.

PACKAGE CONTENTS

Your package should contain the following items:

- 10 x Power Button Replacement Parts
- 10 x Volume Control Button Replacement Parts

SETUP AND INSTALLATION

This product is a replacement part for internal phone components. Professional installation is highly recommended due to the delicate nature of smartphone repairs. Incorrect installation can lead to further damage to your device.

1. **Verify Compatibility:** Before proceeding, ensure that the replacement parts are compatible with your specific phone model: Samsung Galaxy S21 Ultra 5G SM-G998.
2. **Inspect Parts:** Carefully inspect each power and volume button replacement part for any visible defects or damage before installation. All items are inspected and in good condition before shipment.
3. **Professional Assistance:** It is strongly advised to seek professional assistance for the installation of these replacement parts. Smartphone disassembly and reassembly require specialized tools and knowledge to avoid damaging the device's internal components, screen, or other sensitive parts.
4. **Replacement Process:** The general process involves carefully disassembling the phone, removing the old or damaged button components, and precisely installing the new ones. This typically requires heat application, prying tools, and small screwdrivers.



Image: An illustration indicating the typical location of the power and volume buttons on a smartphone, where these replacement parts would be installed.

Disclaimer: We will not be responsible for any damages to your cellphone/mobile phone that you may cause during the changing of replacement parts. Proceed with caution or consult a professional.

OPERATING THE BUTTONS

Once successfully installed, the new power and volume buttons will function identically to the original components. The power button controls the device's power state (on/off, screen lock/unlock), while the volume buttons adjust the audio output level.

- **Power Button:** Press briefly to lock/unlock the screen. Press and hold to access power options (power off, restart).
- **Volume Buttons:** Press the upper button to increase volume. Press the lower button to decrease volume.

MAINTENANCE

To ensure the longevity and proper function of your new buttons and device:

- Avoid exposing your phone to excessive dust, dirt, or liquids, which can interfere with button mechanisms.
- Do not apply excessive force when pressing the buttons.
- If the phone requires cleaning, use a soft, dry, lint-free cloth. Avoid harsh chemicals.

TROUBLESHOOTING

If the new buttons do not function correctly after installation, consider the following:

- **Re-check Installation:** The most common issue is improper seating or connection of the flex cable during installation. If you performed the installation, carefully review the steps or consult a professional.
- **Component Damage:** Ensure no other components were accidentally damaged during the repair process.
- **Contact Support:** If you have verified the installation and the issue persists, please contact the seller for assistance.

SPECIFICATIONS

Item Weight	0.704 ounces
Manufacturer	CHENYANENY
ASIN	B0DCVLZ5CZ
Compatibility	For Samsung Galaxy S21 Ultra 5G SM-G998

WARRANTY AND SUPPORT

For any questions regarding quality assurance, product functionality, or after-sales service, please contact the seller directly. Your satisfaction is important, and assistance will be provided for any issues encountered with the product. The seller, **CYANUS**, can be reached through the Amazon platform for support related to this purchase.

© 2024 CHENYANENY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question