Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Benkut 27.6 IN-1 Pack

Benkut Modern LED Wall Sconce Instruction Manual

Model: 27.6 IN-1 Pack

Safety Information **Package Contents** **Specifications** **Installation** **Operation** **Maintenance** **Troubleshooting**

1. Safety Information

Please read these instructions carefully before installation and use. Retain this manual for future reference.

- **Electrical Safety:** Always turn off the main power supply at the circuit breaker before installing, servicing, or cleaning the fixture.
- **Qualified Electrician:** Installation should be performed by a qualified electrician or a person with adequate knowledge of electrical wiring to prevent electric shock or fire.
- **Voltage:** Ensure the fixture's voltage rating (110V-220V) matches your power supply.
- **Mounting:** Mount the fixture securely to a structural element of the wall.
- **Indoor Use Only:** This product is designed for indoor use and is not water-resistant. Avoid installation in damp or wet locations.
- **No User-Serviceable Parts:** The LED light strip is built-in and not replaceable by the user. Do not attempt to disassemble the fixture.

2. Package Contents

Verify that all components are present before beginning installation:

- Benkut Modern LED Wall Sconce (1 unit)
- Remote Control (1 unit)
- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual (this document)

3. Product Specifications

General Information

Brand: Benkut

Model: 27.6 IN-1 Pack

Color: Black

Style: Modern

Material: Acrylic, Iron

Finish Type: Painted

Indoor/Outdoor Usage: Indoor

Assembly Required: No

Electrical & Lighting

Input Voltage: 110V-220V

Wattage: 15 Watts

Light Source Type: LED

Brightness: 1200 Lumens

Color Temperature: 3000K-6500K (Adjustable)

Special Feature: Dimmable, Adjustable Color Temperature

Control Method: Remote Control

Dimensions & Weight

Product Dimensions: 4"L x 2.3"W x 27.6"H (11cm W x 70cm H)

Item Weight: 2.5 Pounds

Mounting Type: Wall Mount (Semi Flush Mount)




Figure 3.1: Detailed product specifications including dimensions, voltage, wattage, and material composition.



Figure 3.2: Close-up of the sconce highlighting the acrylic light bars and durable aluminum construction.

4. Installation Instructions

This wall sconce is designed for hard-wiring installation. Follow these steps carefully:

1. **Prepare for Installation:**
    - Turn off the power at the circuit breaker to the wall switch or outlet box where you will install the fixture.
    - Ensure the power is off by testing the circuit with a voltage tester.
    - Unpack all components and inspect for any damage.
2. **Mount the Bracket:**
    - Attach the mounting bracket (included in hardware) to the wall outlet box using the provided screws.
    - Ensure the bracket is securely fastened and level.
3. **Wire Connections:**

- Connect the ground wire (usually green or bare copper) from the fixture to the ground wire from the outlet box using a wire nut.
- Connect the live wire (usually black) from the fixture to the live wire from the outlet box using a wire nut.
- Connect the neutral wire (usually white) from the fixture to the neutral wire from the outlet box using a wire nut.
- Carefully tuck all wires into the outlet box.

4. **Attach the Fixture:**
    - Align the fixture with the mounting bracket and secure it with the provided screws.
    - Ensure the fixture is flush against the wall and stable.
5. **Restore Power:**
    - Turn the power back on at the circuit breaker.
    - Test the light fixture using the wall switch and the remote control.



Figure 4.1: Diagram illustrating the hard-wiring process for the wall sconce, connecting to the outlet box.

5. Operating Instructions

The Benkut LED Wall Sconce features adjustable color temperature and dimming functions controlled by the included remote.

5.1 Remote Control Functions

The remote control allows you to customize your lighting experience:

- **ON/OFF:** Power the light on or off.
- **Brightness Adjustment:** Increase or decrease the light intensity (dimmable from 10% to 100%).
- **Color Temperature Adjustment:** Cycle through color temperatures (3000K Warm White, 4500K Neutral Light, 6500K Daylight).
- **Memory Function:** The fixture will remember the last brightness and color temperature setting when turned off and on via the remote.

Note: *This fixture is designed to work with a standard ON/OFF wall switch and the provided remote control. It is* ***NOT*** *compatible with external dimmable switches.*



Figure 5.1: The wall sconce showcasing its adjustable color temperature and dimming capabilities, alongside the remote control.



Figure 5.2: Visual guide to adjusting color temperature and brightness using the remote control. Highlights compatibility with standard switches only.

5.2 Product Demonstration Video

Your browser does not support the video tag.

Video 5.1: A demonstration of the Benkut LED Wall Sconce in various room settings, highlighting its adjustable color temperature and dimming features controlled by the remote.

6. Care and Maintenance

To ensure the longevity and optimal performance of your Benkut LED Wall Sconce, follow these simple care guidelines:

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth to wipe the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or acrylic.

- **No Bulb Replacement:** The LED light source is integrated and does not require bulb replacement.
- **Avoid Moisture:** Do not expose the fixture to water or excessive moisture.

7. Troubleshooting

If you encounter issues with your wall sconce, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Loose wiring connection. Remote control battery depleted.	Check circuit breaker and wall switch. Ensure all wire connections are secure (power off first). Replace remote control battery.
Light flickers or dims unexpectedly.	Incompatible dimmer switch. Loose wiring.	Ensure a standard ON/OFF switch is used, not an external dimmer. Check wiring connections (power off first).
Remote control not responding.	Battery depleted. Obstruction between remote and fixture.	Replace remote control battery. Ensure clear line of sight to the fixture.
Incorrect color temperature or brightness.	Incorrect remote setting.	Use the remote control to adjust to the desired setting.

If the problem persists after trying these solutions, please contact customer support.

8. Warranty and Support

Benkut products are manufactured to high-quality standards. For warranty information or technical support, please refer to the purchase documentation or contact Benkut customer service through the retailer where the product was purchased.

Contact Information: Please refer to your purchase receipt or the Benkut brand store on Amazon for the most up-to-date contact details.

Online Resources: Visit the Benkut Store on Amazon for additional product information and support.

© 2025 Benkut. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCVPB4TW

More documents and user manuals: **https://manuals.plus/**