Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit CB1220, LT-26975, CB.12.20.02, CB.12.20.19, CB4620, CB.48.20.01, CU358-2-L, JLDP.13.009.000

Kircuit 2-Pin AC DC Adapter User Manual

Brand: Kircuit | Model: CB1220, LT-26975, CB.12.20.02, CB.12.20.19, CB4620, CB.48.20.01, CU358-2-L, JLDP.13.009.000

1. Product Overview

The Kircuit 2-Pin AC DC Adapter is designed to provide reliable power to various Okin adjustable bed control boxes and units. This adapter efficiently converts standard AC wall power into the necessary DC power for your device, ensuring optimal operation and battery charging. It is a portable and essential power source for home, office, or travel use, rigorously tested to guarantee compatibility and performance.



Image 1.1: The Kircuit 2-Pin AC DC Adapter, showing the main power brick and the attached power cords with a 2-pin plug.

2. Safety Information

Please read and follow these safety guidelines to prevent damage to the adapter or injury to yourself.

- Ensure the adapter is compatible with your device's voltage and current requirements before connecting.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impacts.
- Do not attempt to open or modify the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present in the package:

- 1 x Kircuit 2-Pin AC DC Adapter

4. Setup

Follow these steps to set up your AC DC adapter:

1. **Inspect the Adapter:** Before use, visually inspect the adapter and its cables for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Plug the DC output connector of the adapter firmly into the corresponding power input port on your Okin adjustable bed control box or unit. Ensure a secure connection.
3. **Connect to Power Outlet:** Insert the AC input plug of the adapter into a standard wall power outlet (100-240VAC, 50/60Hz).
4. **Verify Power:** Once connected, your device should receive power. Check the device's indicators to confirm it is powered on or charging.

5. Operating Instructions

The Kircuit AC DC Adapter operates automatically once connected to a power source and a compatible device. It provides a stable power supply for continuous operation or charging.

- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Do not cover the adapter during operation.
- If the device is not in use, it is recommended to unplug the adapter from the wall outlet.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly winding the cables to prevent damage.
- **Cable Care:** Regularly check the cables for fraying, cuts, or bends. Replace the adapter if any cable damage is observed.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
No power to device	Adapter not plugged in correctly Faulty power outlet Damaged adapter/cable Incompatible device	Ensure all connections are secure. Test the outlet with another device. Inspect adapter and cable for damage; replace if necessary. Verify device compatibility with adapter specifications.
Adapter feels hot	Normal operation Poor ventilation Overload	Some warmth is normal. Ensure adequate airflow around the adapter. Do not cover the adapter. Ensure it's in an open space. Verify device power requirements do not exceed adapter's output.
Device not charging	Loose connection Device battery issue Adapter issue	Check all connections. Consult your device's manual for battery troubleshooting. If other solutions fail, the adapter may be faulty.

8. Specifications

Key technical specifications for the Kircuit 2-Pin AC DC Adapter:

Feature	Detail
Brand	Kircuit
Input Voltage	100-240VAC, 50/60Hz
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Compatible Devices	Okin Adjustable Bed Control Box CB1220, LT-26975, CB.12.20.02, CB.12.20.19, CB4620, CB.48.20.01, CU358-2-L, JLDP.13.009.000
Connector Type	BARREL
Color	Black
Included Components	1 adapter

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or

contact the manufacturer directly. Kircuit products are designed for reliability, and support is available for any operational queries or issues.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCVSHPSZ

More documents and user manuals: **https://manuals.plus/**