

[Manuals.plus](#) /

› [Asuwish](#) /

› Asuwish Wallet Phone Case for OnePlus 9 5G - User Manual

Asuwish 1Plus-9-FMWSZ-US-Case

Asuwish Wallet Phone Case for OnePlus 9 5G - User Manual

Model: 1Plus-9-FMWSZ-US-Case

INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your Asuwish Wallet Phone Case designed for the OnePlus 9 and OnePlus 9 5G. Please read this manual thoroughly before use to ensure optimal performance and protection for your device.

PACKAGE CONTENTS

- 1 x Asuwish Wallet Phone Case
- 1 x Tempered Glass Screen Protector
- 1 x Detachable Crossbody Shoulder Strap

COMPATIBILITY

This Asuwish phone case is specifically designed for the following models:

- OnePlus 9
- OnePlus 9 5G

Note: This case is NOT compatible with the OnePlus 9 Pro or any other device models.

Compatible with **OnePlus 9 Only**



OnePlus 9



OnePlus 9 Pro

Image: Visual guide for phone model compatibility. The image displays the OnePlus 9 (6.55") with a green checkmark, indicating compatibility, and the OnePlus 9 Pro (6.7") with a red cross, indicating non-compatibility. This helps users visually confirm their phone model.

SETUP INSTRUCTIONS

1. Installing the Phone Case

1. Ensure your OnePlus 9 or OnePlus 9 5G is clean and free of dust.
2. Align the phone with the case, starting with the camera cutout.
3. Gently press the phone into the case, ensuring all edges and corners are securely seated within the soft TPU inner shell.
4. Verify that all buttons and ports are accessible and functional.

2. Applying the Tempered Glass Screen Protector

1. Clean your phone screen thoroughly using the provided cleaning wipes (if included) to remove all dust, smudges, and fingerprints.
2. Peel off the protective film from the adhesive side of the tempered glass screen protector.
3. Carefully align the screen protector with your phone's screen, ensuring the cutouts for the camera and sensors match.
4. Gently lower the screen protector onto the screen. It will adhere automatically.
5. If any bubbles appear, gently push them towards the edges of the screen using a soft cloth or squeegee.

3. Attaching the Crossbody Shoulder Strap

1. Locate the four lanyard holes on the wallet case.
2. Attach the clips of the detachable crossbody shoulder strap to any two of the lanyard holes, depending on your preferred wearing style (e.g., top two for vertical, side two for horizontal).
3. Adjust the strap length using the buckle to achieve a comfortable fit.



Image: A woman wearing the Asuwish phone case with the detachable crossbody strap, demonstrating how the strap can be used for hands-free carrying. The strap is adjustable for various lengths and wearing preferences.

OPERATING INSTRUCTIONS

1. Using the Card Holder

The wallet case features 6 card slots designed to securely hold 4-5 cards and some cash. These slots are located on the inside flap and the exterior of the case.

- Open the magnetic flap to access the interior card slots.
- Slide your cards into the designated slots.
- Use the larger pocket behind the card slots for cash or notes.
- The exterior slot provides quick access for a frequently used card.



Image: Illustration of the wallet function, highlighting the card slots and a compartment for cash or coins. This image demonstrates how cards and money can be organized within the case.

MULTI-CARDS WALLET DESIGN

Suoprt to carry multi-cards when go out or travel,more convenient for your life

CAR SLOTS POCKETS



Image: A detailed view of the multi-card wallet design, showing multiple card slots both inside the flap and on the exterior. Numbered indicators point to different card slots, illustrating the capacity and organization.

2. Using the Kickstand Feature

The case can be folded into a kickstand for hands-free viewing.

1. Open the magnetic flap of the wallet case.
2. Fold the flap backward and position it to support the phone at a comfortable viewing angle.
3. This feature is ideal for watching videos, making video calls, or reading.

KICKSTAND FEATURE

Free your hand when watching videos



Image: The phone case configured as a kickstand, supporting the phone in a horizontal viewing position on a desk. This demonstrates the hands-free viewing capability for media consumption or video calls.

MAINTENANCE

Cleaning the Case

- Wipe the exterior of the PU faux leather case with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or excessive water, as these can damage the material.
- For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, damp cloth.
- Allow the case to air dry completely before reinserting your phone.

Care for the Tempered Glass Screen Protector

- Clean the screen protector with a microfiber cloth to remove fingerprints and smudges.
- For deeper cleaning, use a screen cleaner specifically designed for electronics.
- Avoid sharp objects that could scratch the protector.

TROUBLESHOOTING

Case Not Fitting Correctly

- **Check Compatibility:** Ensure your phone is a OnePlus 9 or OnePlus 9 5G. This case is not compatible with other models, including the OnePlus 9 Pro.
- **Proper Alignment:** Re-align the phone carefully, ensuring the camera module and all buttons are correctly positioned before pressing the phone into the case.

Screen Protector Bubbles

- **Dust Particles:** Bubbles are often caused by dust. If bubbles persist, carefully lift a corner of the protector, use a dust absorber sticker to remove any dust, and reapply.
- **Squeegee Application:** Use a soft card or squeegee to gently push bubbles towards the nearest edge after application.

SPECIFICATIONS

Feature	Detail
Compatible Models	OnePlus 9, OnePlus 9 5G
Material	Durable PU Faux Leather (exterior), Soft TPU (inner shell)
Color	Black
Card Slots	6 (holds 4-5 cards + cash)
Additional Features	Kickstand, Detachable Crossbody Strap, Tempered Glass Screen Protector
Model Number	1Plus-9-FMWSZ-US-Case
Dimensions (approx.)	16 x 10 x 1.5 cm (Parcel Dimensions)
Weight (approx.)	80 g (Parcel Weight)

FULL PROTECTION EARTHQUAKE RESIS TANCE AND FALL PREVENTION



Image: The Asuwish phone case shown protecting a phone, with visual cues suggesting resistance to impacts and falls. This illustrates the protective features of the case, including its durable materials and design for shock absorption.

WARRANTY AND SUPPORT

Asuwish provides dedicated customer service to ensure your satisfaction.

- **Warranty:** We offer *FREE REPLACEMENT* or *FULL REFUND* for defective products.
- **Customer Service:** For any inquiries, doubts, or issues, please contact Asuwish customer service via email. Our team is available 24 hours to provide professional and satisfactory solutions.

For further assistance, please refer to the contact information provided with your purchase or visit the official Asuwish support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question