DEWIN Car Vacuum Cleaner

DEWIN Handheld Cordless 4-in-1 Vacuum Cleaner and Air Duster

Model: Car Vacuum Cleaner

1. Introduction

Thank you for choosing the DEWIN Handheld Cordless 4-in-1 Vacuum Cleaner and Air Duster. This versatile device is designed for efficient cleaning in various environments, including your car, home, and office. It combines powerful suction with effective blowing capabilities, making it an essential tool for maintaining cleanliness in hard-to-reach areas.

Please read this instruction manual thoroughly before operating the device to ensure safe and optimal performance. Keep this manual for future reference.

2. Safety Instructions

- Do not operate the device with wet hands or near water.
- Keep the device away from heat sources and direct sunlight.
- Do not vacuum flammable or combustible materials, hot ashes, or sharp objects.
- Ensure the filter is properly installed before use.
- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- Use only the provided charging cable and accessories.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if needed.
- Store the device in a cool, dry place when not in use.

3. Package Contents

Verify that all items are present in the package:

- DEWIN Handheld Cordless Vacuum Cleaner/Air Duster Unit
- USB-C Charging Cable
- HEPA Filter (pre-installed)
- Spare HEPA Filter

- Long Flat Suction Nozzle
- Brush Suction Nozzle
- Flexible Hose Extension
- Long Blower Nozzle
- Short Blower Nozzle (for inflatables)
- Wide Blower Nozzle
- User Manual



Figure 3.1: All components included in the DEWIN Handheld Cordless Vacuum Cleaner package.

This image displays the main vacuum unit along with its various attachments, including different nozzles for suction and blowing, a flexible hose, a charging cable, and a spare HEPA filter.

4. Product Overview

The DEWIN Handheld Cordless Vacuum Cleaner is a compact and lightweight device designed for ease of use and portability. It features a 4-in-1 design, offering both vacuuming and air duster functionalities, along with specialized

nozzles for various tasks.



Figure 4.1: Main components of the DEWIN Handheld Cordless Vacuum Cleaner.

This diagram highlights the key parts of the vacuum: the dust collection bin, HEPA filter, handle, power switch, air outlet, and charging port.



Figure 4.2: Detailed view of the air outlet, anti-slip handle, one-button switch, and removable head.

This image provides a closer look at the design elements, including the air outlet, the textured anti-slip handle for comfortable grip, the single-button operation, and the removable head for easy attachment changes.

5. Setup

5.1 Charging the Device

1. Before first use, fully charge the vacuum cleaner.
2. Connect the provided USB-C charging cable to the charging port on the device.
3. Plug the other end of the USB-C cable into a compatible USB power source (e.g., car charger, mobile power bank, laptop, wall adapter).
4. The battery indicator lights will illuminate during charging and show progress. A full charge typically takes 3-4 hours.

5.2 Attaching Accessories

The device supports various attachments for both vacuuming and blowing functions. Ensure the device is turned off

before attaching or detaching accessories.

- **For Vacuuming:** Attach the desired suction nozzle (long flat, brush, or flexible hose with attachments) to the front opening of the dust collection bin. Twist gently until it clicks into place.
- **For Blowing/Dusting:** Remove the dust collection bin. Attach the desired blower nozzle (long, short, or wide) to the rear air outlet of the main unit. Twist gently until it clicks into place.

6. Operating Instructions

6.1 Power On/Off and Speed Adjustment

1. To turn on the device, press and hold the power button for 2-3 seconds. The device will start in the default low-speed mode.
2. Press the power button briefly to cycle through the different speed modes (Low, Medium, High).
3. To turn off the device, press and hold the power button for 2-3 seconds.

6.2 Using the Vacuum Function

Attach the appropriate suction nozzle for your cleaning task. The long flat nozzle is ideal for crevices and tight spaces in car interiors, while the brush nozzle is effective for upholstery and carpets.



Figure 6.1: Demonstrating the vacuum function on a car floor mat.

This image shows the vacuum cleaner with a flat nozzle effectively cleaning debris from a car's floor mat, highlighting its strong suction power.

Figure 6.2: Versatile applications of the vacuum cleaner in different environments.

This image illustrates the product's adaptability, showing it used for cleaning a laptop, car interior, chassis, sofa, and storage cabinets, emphasizing its suitability for both home and car use.

6.3 Using the Blower/Duster Function

Attach the appropriate blower nozzle to the rear air outlet. This function is ideal for:

- Blowing dust from computer keyboards, camera lenses, and delicate electronics.
- Inflating small items like swimming rings or air mattresses using the specialized nozzles.
- Cleaning window sills and other areas where suction might not be effective.



Figure 6.3: Using the air duster function to clean a keyboard.

This image demonstrates the blower function, showing the device effectively removing dust and debris from a computer keyboard, highlighting its utility for electronics cleaning.

6.4 Product Versatility



Figure 6.4: Multiple scene applications of the DEWIN Handheld Cordless Vacuum Cleaner.

This image showcases the device's broad utility, depicting its use in a car, for cleaning a keyboard, inflating a pool float, and even dusting inside a freezer, illustrating its adaptability to various cleaning needs.

6.5 Official Product Videos

Your browser does not support the video tag.

Video 6.5.1: "Car Vacuum Portable Cordless" by Vostuve Official. This video demonstrates the portable cordless car vacuum in action, showcasing its various attachments and ease of use for car cleaning and other applications.

Your browser does not support the video tag.

Video 6.5.2: "6000Pa Vacuum Cleaner and Air Duster" by Dewinshop168. This video highlights the powerful 6000Pa suction and air duster capabilities of the device, including demonstrations of its cleaning performance and filter maintenance.

7. Maintenance

7.1 Emptying the Dust Collection Bin

1. Ensure the device is turned off.
2. Twist the dust collection bin counter-clockwise to detach it from the main unit.
3. Carefully empty the collected debris into a trash receptacle.

7.2 Cleaning the HEPA Filter

The HEPA filter is washable and reusable, ensuring efficient suction power. Regular cleaning is recommended to maintain performance.

1. After emptying the dustbin, remove the HEPA filter.
2. Tap the filter gently to dislodge any loose dust.
3. Rinse the filter under clean running water until all debris is removed.
4. Allow the filter to air dry completely before reinserting it into the dust collection bin. Do not use the device with a wet filter.



Figure 7.1: The washable HEPA filter being cleaned under water.

This image shows the HEPA filter being cleaned under running water, illustrating the ease of maintenance for sustained performance.

8. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on	Low battery; Power button not pressed correctly	Charge the device; Press and hold the power button for 2-3 seconds
Weak suction/blowing power	Clogged filter; Full dustbin; Blocked nozzle/hose	Clean or replace filter; Empty dustbin; Clear any blockages
Device stops unexpectedly	Low battery; Overheating	Recharge the device; Allow device to cool down before resuming use
Charging indicator not working	Faulty cable/adapter; Loose connection	Check cable and adapter; Ensure secure connection

9. Specifications

Feature	Detail
Brand	DEWIN
Model Name	Car Vacuum Cleaner
Special Feature	Handheld Car Vacuum Cleaner, Air Duster
Filter Type	HEPA Filter (Washable)
Is Cordless?	Yes
Battery Type	Lithium-Ion (2000mAh)
Charging Time	Approx. 3-4 hours
Run Time	Approx. 30 minutes (depending on speed)
Connectivity Technology	USB-C
Item Weight	0.82 lbs (13.1 ounces)
Product Dimensions	7.48"L x 6.89"W x 2.44"H
Color	Black
Power Levels	3
Indoor/Outdoor Usage	Indoor




Figure 9.1: Detailed dimensions of the main unit and various attachments.

This image provides precise measurements for the main vacuum unit and its accompanying nozzles, aiding in understanding its compact size and the reach of its accessories.

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or reach out to your retailer. Our professional customer service team is available to assist you with any questions or concerns.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question