

[Manuals.plus](#) /

› [KUTCHINA](#) /

› Kutchina Vitara DLX 60 Angular BLDC Chimney User Manual

KUTCHINA Vitara DLX

KUTCHINA Vitara DLX 60 Angular BLDC Chimney

User Instruction Manual

1. INTRODUCTION

Thank you for choosing the KUTCHINA Vitara DLX 60 Angular BLDC Chimney. This appliance is designed to provide efficient ventilation and maintain a clean kitchen environment by effectively removing cooking fumes and odors. Featuring a powerful BLDC motor, 3rd generation dry autoclean technology, and intuitive touch and wave sensor controls, this chimney offers both performance and convenience. Please read this manual thoroughly before installation and operation to ensure safe and optimal use of your new chimney.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, observe the following:

- Ensure the power supply matches the voltage specified on the rating label.
- Installation must be performed by a qualified technician in accordance with all local codes and standards.
- Always disconnect the appliance from the power supply before cleaning or servicing.
- Do not operate the chimney if the power cord or plug is damaged.
- Maintain proper ventilation in the room when the chimney is used simultaneously with gas or other fuel-burning appliances.
- Never leave frying food unattended as grease can ignite.
- Clean grease filters and oil collector regularly to prevent grease accumulation.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

3. WHAT'S IN THE BOX

Carefully unpack your KUTCHINA Vitara DLX 60 Chimney and check for the following components:

- Vitara DLX Chimney Unit

- Installation Kit (mounting brackets, screws, etc.)
- Warranty Book
- User Manual (this document)

If any items are missing or damaged, please contact customer support immediately.

4. SETUP AND INSTALLATION

The KUTCHINA Vitara DLX 60 is a wall-mount chimney designed for ducted ventilation. Professional installation is highly recommended to ensure proper functioning and safety.

1. **Site Preparation:** Ensure the installation area is structurally sound and has access to a suitable power outlet. The chimney should be mounted at the recommended height above your cooking surface (refer to local regulations and product specifications for exact measurements).
2. **Mounting:** Use the provided installation kit to securely mount the chimney to the wall. Follow the detailed instructions in the separate installation guide (if provided with the kit).
3. **Ducting:** Connect the chimney's exhaust outlet to an appropriate ducting system that leads to the outside. Ensure the ducting is properly sealed to prevent air leakage.
4. **Electrical Connection:** Connect the chimney to a grounded electrical outlet. Ensure all electrical connections comply with local codes.
5. **Installation Registration:** For warranty and service purposes, register your installation by calling **18004197333**. Please note that installation and demonstration services are chargeable, and any additional accessories not included in the package will be charged separately.



Image: The Kutchina Vitara DLX 60 chimney seamlessly integrated into a kitchen environment, demonstrating its wall-mounted design.

5. OPERATING INSTRUCTIONS

Your KUTCHINA Vitara DLX 60 chimney features user-friendly touch controls and an advanced wave sensor for convenient operation.

5.1 Control Panel




Image: Overview of the chimney's control panel and key performance indicators, including motor power, suction capacity, noise level, and speed settings.

The control panel typically includes buttons for:

- **Power On/Off:** To switch the chimney on or off.
- **Speed Selection:** To adjust the suction power (typically 3 speeds). Higher speeds are suitable for heavy cooking.
- **Light Control:** To turn the LED lamps on or off.
- **Autoclean Function:** To initiate the automatic cleaning cycle.

5.2 Wave Sensor Control

The wave sensor allows for hands-free operation of certain functions, such as power on/off or speed adjustment.



Image: Illustration of how to use the wave sensor for gesture-based control, alongside the touch control interface and LED lighting.

- **To Turn On/Off:** Wave your hand once in front of the sensor.
- **To Adjust Speed:** Wave your hand multiple times or hold it in front of the sensor (refer to specific model behavior for precise gestures).

The chimney operates with a low noise level of 58 dB, ensuring a peaceful cooking environment.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your KUTCHINA Vitara DLX 60 chimney.

6.1 3rd Generation Dry Autoclean Technology




Image: Visual representation of the chimney's advanced cleaning features, including the autoclean system, oil collector, and filterless design.

This chimney is equipped with 3rd generation dry autoclean technology. To activate:

- Press the dedicated 'Autoclean' button on the control panel.
- The chimney will run a cleaning cycle, heating the internal components to melt and collect grease into the oil collector.
- Perform this cycle regularly, depending on your cooking frequency, to prevent grease buildup.

6.2 Oil Collector

The chimney features an integrated oil collector that gathers the grease removed during the autoclean process. It is crucial to empty and clean the oil collector regularly.

- Locate the oil collector tray, usually at the bottom or rear of the chimney.
- Carefully remove the tray.
- Empty the collected oil and wash the tray with warm, soapy water.

- Ensure the tray is completely dry before reinserting it.

6.3 Exterior Cleaning

- Wipe the exterior surfaces of the chimney with a soft, damp cloth and mild detergent.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.
- Ensure the chimney is switched off and unplugged before cleaning.

7. TROUBLESHOOTING

If you encounter issues with your chimney, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chimney does not turn on.	No power supply; loose connection; faulty switch.	Check power plug and circuit breaker. Ensure connections are secure. Contact service if switch is faulty.
Low suction power.	Oil collector full; blocked ducting; incorrect speed setting.	Empty and clean oil collector. Check ducting for obstructions. Increase fan speed.
Unusual noise during operation.	Loose components; foreign object in fan; motor issue.	Ensure all parts are secure. Disconnect power and check for obstructions (if safe to do so). Contact service if motor issue is suspected.
LED lights not working.	Loose connection; faulty LED bulb.	Check connections. Contact service for bulb replacement.
Autoclean function not working.	Electrical issue; sensor malfunction.	Ensure power supply is stable. Contact customer support for diagnosis.

If the problem persists after attempting these solutions, please contact KUTCHINA customer support.

8. SPECIFICATIONS

Brand	KUTCHINA
Model Number	Vitara DLX
Product Dimensions (D x W x H)	31.5D x 89.5W x 84.5H Centimeters
Colour	Black
Special Features	Auto Clean, LED Lighting, Noise Reduction, Oil Collector, Wave Sensor
Air Flow Capacity	1500 Cubic Meters Per Hour
Noise Level	58 Decibels
Mounting Type	Wall Mount

Controls Type	Touch, Wave Sensor
Voltage	220 Volts (AC)
Number Of Speeds	3
Light Source	LED (2 x 1.25W)
Wattage	150 Watts (Motor)
Filter Type	Mesh (Filterless Technology)
Ventilation Type	Ducted
Material Type	Glass, Mild Steel
Item Weight	22 Kilograms

9. WARRANTY INFORMATION

Your KUTCHINA Vitara DLX 60 Chimney comes with the following warranty:

- **5 Years Warranty** on the product.
- **Lifetime Warranty** on the motor.

Please retain your purchase receipt and warranty book for any warranty claims. The warranty covers manufacturing defects under normal use conditions. For detailed terms and conditions, refer to the warranty book included with your product.

10. CUSTOMER SUPPORT

For any queries, service requests, or technical assistance, please contact KUTCHINA customer support:

- **Toll-Free Number:** 18004197333
- **Email:** customercare@kutchina.com

When contacting support, please have your product model number (Vitara DLX) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question