Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XCWIIE DCL60301BW-T

XCWIIE 60 Inch Smart Ceiling Fan with Light User Manual

Model: DCL60301BW-T

1. Important Safety Information

Read all instructions carefully before installation and use. Retain this manual for future reference.

- **Electrical Safety:** Ensure power is disconnected at the circuit breaker before installation or servicing. All wiring must be in accordance with national and local electrical codes.
- **Mounting:** The ceiling fan must be mounted to a structure capable of supporting the fan's weight (approximately 15 pounds). Use an outlet box marked "Acceptable for Fan Support."
- **Blade Clearance:** Maintain a minimum clearance of 7 feet from the floor to the bottom of the fan blades. Ensure blades do not strike any objects.
- **Damp Location Rated:** This fan is damp rated, suitable for covered outdoor patios, workshops, breezeways, gazebos, and pergolas. It is not suitable for direct exposure to water.
- **Professional Installation:** If you are unsure about wiring or installation, consult a qualified electrician.

2. Product Overview

The XCWIIE 60 Inch Smart Ceiling Fan with Light (Model DCL60301BW-T) is designed for both indoor and covered outdoor use. It features three solid wood blades, an integrated LED light, and multiple control options including remote, app, and voice control.




Image: XCWIIE 60 Inch Smart Ceiling Fan with Light, illustrating its design and control features.

Key Features:

- **Solid Wood Blades:** Three natural solid walnut wood blades, aerodynamically designed for efficient airflow (Max 9660 CFM).
- **Smart Control:** Compatible with Alexa, Google Assistant, and the TUYA App. Also includes a remote control.
- **Energy-Saving DC Motor:** Whisper-quiet DC motor (under 30dB) with 6 speeds and reversible direction for year-round use. Operates efficiently at 32-45W.
- **Dimmable LED Light:** Integrated 18W LED module with 3 adjustable color temperatures (3000K Warm White, 4000K Natural White, 5000K Cool White) and brightness adjustment.
- **Flexible Installation:** Includes 5", 10", and 24" downrods to accommodate various ceiling heights and sloped ceilings up to 20°.

3. Setup and Installation

This section provides general guidance for installing your XCWIIE ceiling fan. Refer to the detailed installation instructions included in your product packaging for specific steps and diagrams.

Pre-Installation Checklist:

- Ensure all components are present: motor assembly, blades, light kit, canopy, downrods (5", 10", 24"), remote control, and mounting hardware.
- Verify the electrical box is securely mounted and rated for fan support.
- Turn off power at the circuit breaker before beginning.

Mounting Options:

The fan supports both standard downrod mounting and angled ceiling installations up to 20 degrees. Select the appropriate downrod (5", 10", or 24") based on your ceiling height to ensure optimal airflow and clearance.



Image: Illustration of downrod and angled mounting options.

Installation Steps (Summary):

1. Secure the mounting bracket to the ceiling electrical box.
2. Assemble the downrod with the canopy and hang the motor assembly onto the mounting bracket.
3. Complete electrical wiring connections (ensure proper grounding).

4. Attach the fan blades to the motor housing.
5. Install the LED light kit.
6. Secure the canopy to the mounting bracket.

For detailed visual instructions, refer to the installation video provided by the manufacturer:

Your browser does not support the video tag.

Video: "How to Control the Ceiling Fans with Tuya APP" - This video also covers initial setup and pairing with the app, which is part of the installation process for smart features.

4. Operating Instructions

Your XCWIIE Smart Ceiling Fan offers multiple ways to control its functions.

Remote Control:

The included remote control allows you to adjust fan speed, light brightness, light color temperature, and set a timer.

- **Fan Speed:** Select from 6 fan speeds.
- **Light Control:** Turn the light on/off, adjust brightness (dimming), and cycle through 3 color temperatures (Warm White, Natural White, Cool White). The fan features a memory function for light settings.
- **Timer:** Set a timer for 1, 4, or 8 hours.
- **Reversible Motor:** Switch between summer mode (downward airflow for cooling) and winter mode (upward airflow for heat circulation).



Image: Remote control and app interface demonstrating fan functions and seasonal modes.

App Control (TUYA App):

Download the TUYA app from your smartphone's app store. The app allows for advanced control, including adjusting fan speeds, brightness, color temperature, and setting timers. The fan requires a 2.4Ghz Wi-Fi connection for app control.

Pairing with TUYA App:

1. Ensure your fan is powered on.
2. Open the TUYA app and select "Add Device".
3. On the remote control, **long press the "8HR" button** until the fan beeps to enter pairing mode.
4. In the app, select the "BLE+WIFI" ceiling fan type.
5. Follow the on-screen prompts to connect to your 2.4Ghz Wi-Fi network.

Your browser does not support the video tag.

Video: "How to Control the Ceiling Fans with Tuya APP" - Demonstrates the process of connecting the fan to the Tuya app.

Voice Control (Alexa, Google Assistant):

Once paired with the TUYA app, you can link your fan to Alexa or Google Assistant for voice commands. Refer to the respective voice assistant's app for instructions on linking smart home devices.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing regularly with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Blade Inspection:** Periodically check the fan blades for any signs of warping or damage. Ensure all blade screws are tight.
- **Light Kit:** The integrated LED light module is designed for long life and typically does not require replacement. If issues arise, contact customer support.
- **Motor:** The DC motor is sealed and requires no lubrication.

Note: *As the blades are made of natural solid wood, avoid prolonged exposure to excessive moisture to prevent warping. This fan is damp-rated for covered outdoor areas, not wet locations.*

6. Troubleshooting

If you encounter issues with your XCWIIE ceiling fan, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power, loose wiring, remote not paired.	Check circuit breaker. Ensure all wire connections are secure. Re-pair remote control (refer to Operating Instructions).
Fan wobbles	Loose blade screws, unbalanced blades, loose mounting.	Tighten all blade screws. Ensure mounting bracket is secure. Check for any bent blades.
Light does not work	Loose wiring, light switch off.	Check light wiring connections. Ensure light is turned on via remote or app.
Cannot connect to App	Incorrect pairing method, 5Ghz Wi-Fi, fan not in pairing mode.	Ensure you are using a 2.4Ghz Wi-Fi network. Long press the "8HR" button on the remote until the fan beeps to enter pairing mode. Select "BLE+WIFI" in the Tuya app.
Fan is noisy	Loose screws, motor issue.	Check and tighten all screws. If noise persists, contact customer support.

7. Specifications

Feature	Detail
Brand	XCWIIE
Model Number	DCL60301BW-T

Feature	Detail
Product Dimensions	60"D x 60"W x 20"H
Blade Length	60 inches
Number of Blades	3
Blade Material	Solid Walnut Wood
Motor Type	Brushless DC
Wattage	32-45 Watts
Voltage	110.01 Volts
Air Flow Capacity	9660 CFM (Max)
Number of Speeds	6
Noise Level	30 dB
Light Kit	Integrated 18W LED, Dimmable, 3 Color Temperatures (3000K, 4000K, 5000K)
Control Method	Remote Control, App Control (TUYA), Voice Control (Alexa, Google Assistant)
Downrod Lengths Included	5", 10", 24"
Sloped Ceiling Compatibility	Up to 20°
Indoor/Outdoor Usage	Indoor, Covered Outdoor (Damp Rated)
Certifications	ETL, FCC, RoHS

8. Warranty and Support

XCWIIE provides customer support for its products. If you experience any issues or require assistance, please contact the seller or manufacturer directly.

- **Damaged or Missing Parts:** If the ceiling fan arrives damaged or with missing parts, a free replacement service is offered.
- **Longer Downrods:** If you require downrods longer than the included 24 inches (e.g., 40 inches), contact the seller for assistance.
- **Contacting Support:** Refer to your purchase details for seller contact information. Typically, this can be found by checking your order details and selecting "Problem with Order" or "Contact Seller."

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCYYH6GQ

More documents and user manuals: **https://manuals.plus/**